

OMRON

model KM-N3-FLK

On-Panel Power Monitor

INSTRUCTION MANUAL

Thank you for purchasing the On-panel Power Monitor, model KM-N3-FLK (referred to as model KM-N3 in this manual). This manual describes the functions, performance, and application methods needed for optimum use of model KM-N3. Please observe the following when using model KM-N3.

- This product is designed for use by qualified personnel with a knowledge of electrical systems.
Before using the product, thoroughly read and understand this manual to ensure correct use.
Keep this manual in a safe location so that it is available for reference whenever required.

TRACEABILITY INFORMATION:

Importer in EU: Omron Europe B.V.
Manufacturer: Omron Corporation,
Wegalaan 67-69, 2132 JD Hoofddorp, The Netherlands

The following notice applies only to products that carry the CE mark: This is a class A product. In residential areas it may cause radio Interference, in which case the user may be required to take adequate measures to reduce interference

OMRON SOCIAL SOLUTIONS CO.,LTD.

© OMRON Corporation

5371687-8 G

For detailed instructions, download "Model KM-N3-FLK User's Manual" (catalog no. N214-E1-01) from our website.

PRECAUTIONS ON SAFETY

Key to Warning Symbols

CAUTION Indicates a potentially hazardous situation which, if not avoided, will result in minor or moderate injury, or there may be property damage.

Table with 2 columns: Warning symbol and description. Includes symbols for fire, explosion, breakdown, electric shock, and minor electric shock.

* CT: Current Transformer

PRECAUTIONS FOR SAFE USE

Observe the following to ensure safe use of model KM-N3.

- Do not use or store the product in any of the following locations:
Locations subject to shock or vibration
Unstable locations where the user might fall/tumble down
Locations subject to temperatures or humidity outside rated ranges
Locations subject to condensation as the result of severe changes in temperature
Outside or otherwise exposed to direct sunlight and weather
Locations subject to static electricity or other forms of noise
Locations exposed to electromagnetic fields
Locations subject to exposure to water or oil.
Locations subject to exposure to salt water spray.
Locations subject to corrosive gases (in particular, sulfide gas and ammonia gas).
Locations subject to dust (including iron dust).
Locations subject to exposure to solvents

- Be sure to wire properly with the terminals with correct symbols.
Use AWG20 to 16 (with a cross-section of 0.5 to 1.5mm²) to wire the power supply terminals.
Use AWG18 to 14 (with a cross-section of 0.75 to 2.0mm²) to wire the CT and measurement voltage terminals.
Use twisted or solid wire AWG24 to 16 (with a cross-section of 0.25 to 1.5mm²) to wire communication terminals.
Before using or maintaining the product, thoroughly read and understand this manual.
Understand the user manual before setting the device.
Do not pull cables.

For compliance with standards and safety, in order to protect against overcurrent, install a branch circuit protector with a rated current of 1A conforming to the voltage at which the device is used and the appropriate standards of the country where the device is used (US: UL Listed, Canada: cUL Listed, and other countries: for example, IEC60947-1 and IEC60947-2). Failure to do so may lead to an electric shock or fire. Install the branch circuit protector on the (1) L+ terminal of this product and the Line side of the power supply.

- Before using the device, be sure to check the wiring before turning on the power.
Electric shock, injury, accident, or malfunction may occasionally occur because defective wiring.
Do not touch any of the terminals while the power is being supplied.
Do not install the product close to heat-producing devices (those using coil elements, for instance).
Separate the product wiring from high-voltage or high-current power lines to prevent inductive noise.
Do not place the product wiring parallel to or in the same ducts or conduits as power lines.
Use separate ducts, separate conduits, or shielded cables to prevent noise.
This is a "class A" product. In residential areas it may cause radio interference. The user may be required to take adequate measures to reduce interference if this occurs.
Use the product by incorporating it in a panel 1 to 8 mm thick. If the panel thickness is not appropriate or the mounting method is not appropriate, the product might be come off.

PRECAUTIONS FOR CORRECT USE

- This product is not categorized as "a specified measuring instrument" officially approved by an organization specified in relevant measurement acts.
Set the parameters of the product so that they are suitable for the system being measured.
Use this product in an overvoltage category II environment.
In a power supply system where it is unearthed neutral, a varistor cannot be installed between the voltage input terminal and the ground.
This product cannot be used to measure the inverter's secondary side.
Ensure that the rated voltage is reached within 2 seconds of turning the power on.
When cleaning the unit, make sure the power is off and wipe the surface of the unit with a soft dry cloth.
Do not use chemicals including solvents such as thinners, benzine, or alcohol.
Use a CT whose secondary output is 1A or 5A.
The data for active energy is saved at 5 minute intervals.
Dispose of this product appropriately as industrial refuse in accordance with local and national regulations.

사용자 안내문

이 기기는 업무용 환경에서 사용할 목적으로 적합성평가를 받은 기기로서 가정용 환경에서 사용하는 경우 전파간섭의 우려가 있습니다.

Features

This product is an electric energy monitor mounted on the panel of the control board. It complies with the international IEC accuracy standards and can be connected using general-purpose CTs. One unit can measure a maximum of four circuits. The unit can measure the power of each point accurately.

Main unit specifications

Table with 3 columns: Item, Content. Lists specifications such as Rated input voltage (AC100 to 240V), Power consumption (7VA or less), and Insulation resistance.

Measurement specifications

Table with 3 columns: Item, Content. Lists Active power (0.5%), Reactive power (2%), and Measurement frequency (80ms at 50Hz).

*IEC62053 is an international standard dealing with electricity metering.

*This does not include the measuring error margin of the generic CT.

Measurement input specifications

Table with 3 columns: Item, Content. Lists applicable circuit types (3-phase 4-wire, 1-phase 2-wire, etc.) and rated input voltages for various configurations.

* Use a CT with a rated load of 1.0 VA or more.

Regarding the compliance with CT standards


Table showing compliance status for UL and CSA standards across different model variants (KM-NCT, KM20-CTN, KM20-CTF).

Output specifications

Table with 3 columns: Item, Content. Lists Pulse output (4 points), RS-485 protocol (Modbus, CompoWay/F), and communication speed (38400, 19200, etc.).

Attaching the body of the unit


- Create an opening on the panel according to the panel machining dimensions.
In order to make the unit waterproof, with the accessory waterproof packing on the front of the panel, insert the unit into the panel opening.
Fit the attached mounting adapter into the fixing grooves on the top and bottom faces of the rear case.
Push in the mounting adapter from the terminal side until it contacts the panel to fix the main unit tentatively.
Fasten the fixing screws of the top and bottom mounting adapter alternately as keeping balance little by little.



Wiring of power supply, CT, and measurement voltage input


Wiring the power supply

- For safety purposes, turn off the mains power and the breaker to ensure there is no power supply while you are working.
The terminal is the push-in type.
To wire with the power supply terminal, use AWG20-16 wire (with a cross-section of 0.5 to 1.5 mm²).
Peel the wire-coating by 10 mm when using a ferrule terminal and by 8 mm when not using it.
Use a ferrule terminal with a conductor portion 8mm long.



Wiring the CTs

- For safety purposes, turn off the mains power and the breaker to ensure there is no power supply while you are working.
You will need 3 CTs to measure 3-phase 4-wire, 2 CTs to measure 1-phase 3-wire or 3-phase 3-wire, and 1 CT to measure 1-phase 2-wire.
CTs have polarity, so confirm the current directions at the power supply side (K) and load side (L) before wiring the CTs.



- To wire the CT input terminals, use AWG18-14 wire (with a cross-section of 0.75 to 2.0 mm²) and crimping terminals of the round shape or Y-shape (5.8mm wide or less) compatible with the M3 screw.
The recommended torque for screwing the 3mm screws onto the terminal panel is 0.5 to 0.58 N·m. Make sure the crimping terminal is pushed all the way in and tightened firmly.

Wiring the measurement voltage input

- For safety purposes, turn off the mains power and the breaker to ensure there is no power supply while you are working.
Wire correctly so the phase sequence is correct.
To wire with the measurement voltage input terminal, use AWG18-14 electric wire (with a cross-section of 0.75-2.0mm²) and crimping terminals of the round shape or Y-shape (5.8mm wide or less) compatible with the M3 screw.
The recommended fastening torque of the M3 terminal screw is 0.5 to 0.58 N·m. Make sure the ferrule terminal is pushed all the way in and tightened firmly.


Wiring diagrams

- The below table shows the wiring of voltage input terminals and CT input terminals with each phase and wire type (3-phase 4-wire, 1-phase 2-wire, 1-phase 3-wire, and 3-phase 3-wire). Wire the device according to the phase and wire type.


Table showing wiring diagrams for different configurations: 3-phase 4-wire, 1-phase 2-wire, 1-phase 3-wire, and 3-phase 3-wire. Columns include VR, VS, VT, VN, CT-R, CT-S, CT-T.

(wiring example for 3-phase 4-wire)
P1/P2: Primary
S1/S2: Secondary

- The diagram at right shows the relationship between the wiring table and the terminals on the main unit.
For details about how to wire the CTs, connect the S1 terminal to the CT power supply side (K) and the S2 terminal to the CT load side (L).




Pulse output wiring



- This unit is equipped with 4 pulse output terminals.
The terminal is the push-in type.
Do not directly connect an external power source to OUT or COM.
To wire with the pulse output terminal, use AWG24-16 twisted or solid wire (with a cross-section of 0.25 to 1.5 mm²).
Peel the wire-coating by 10 mm when using a ferrule terminal and by 8 mm when not using it.
Use a ferrule terminal with a conductor portion 8mm long.
To avoid the influence of noise, use separate wiring for the signals and for the power.
Output for circuit A is allocated to OUT1, circuit B to OUT2, circuit C to OUT3, and circuit D to OUT4, and these allocations are fixed.

RS-485 wiring

- The configuration of the connection should be either 1:1 or 1:N.
The terminal is the push-in type.



- There is no FG terminal on KM-N3.
Use twisted pair cables.
To wire with the RS-485 terminal, use twisted or solid wire of AWG24-16 (with a cross-section of 0.25 to 1.5 mm²).
Peel the wire-coating by 10 mm when using a ferrule terminal and by 8 mm when not using it.
Use a ferrule terminal with a conductor portion 8mm long.
To avoid the influence of noise, use separate wiring for the RS-485 communications and for the power.
The maximum transmission distance is 1200m.
Irrespective of the transmission distance and number of units connected, perform communications checks with the actual units.

Termination settings


- This unit is equipped with a terminating resistor inside the main unit.
If the host device you are using does not have its own built in terminating resistor, connect a terminating resistor to the host device.
Do not wire in a terminating resistor terminal on KM-N3 that are along the transmission path.

Table with 2 columns: Warning symbol and text. Text includes Safety standard compatibility and Meaning of the warning symbols on the product.


Multi-address system

This unit makes it possible to have a maximum of 4 measuring circuits in one unit. The measuring circuits act as independent power monitors, each able to measure, each having different settings, and each allocated different communications addresses. You can easily change the number of circuits by enabling or disabling the measuring circuits.

1-Phase 2-wire (4 circuits max.)




1-phase 3-wire, 3-Phase 3-wire (2 circuits max.)



Mode configuration

This model has three modes: measuring mode, setting mode, and communication setting mode.

- Measuring mode : The measured values or alarm details of each circuit are displayed.
- Setting mode : By operating keys on the body of the unit you can change settings for each of the circuits, and make common settings for communications, output, the display, etc.
- Communication setting mode : Make settings on the units using RS-485 communication.



- In the measuring mode and setting mode, the circuit B to D items are displayed by switch the enable/disable settings for each of the circuits to "ON" (enabled). (The circuits indicated inside the dotted lines are "OFF" (disabled) in the default state.)
- The alarm screen is displayed when an alarm has occurred.

Switching between the measuring mode and the setting mode
Switch between the measuring mode and setting mode by pressing and holding the [MODE-⟨⟩] key.
• "Press and hold" means pressing the key for 1 or more seconds.

How to enter the password


- When moving from the measuring mode to the setting mode, you need to enter the password that has been set.
- The default password is "0001".
- You can set a password of 4 numerals between 0000 and 9999. Change the password as necessary.
- You will be unable to reset the password if you forget it. Take care to note the password carefully when changing it.
- There is no functionality to disable the password setting.
- If you forget the password, contact the place of purchase or the manufacturer.

Measuring mode


Measurement display

When the [MODE-⟨⟩] key is pressed, the measuring items are displayed after the screen for showing the destination circuit.
• By pressing the [I/V/F/PF], [P/Q], [E1], or [E2] key, the measuring items are switched.
• When an alarm has occurred, the screen transitions to not only the screen displaying the measured values but also the screen displaying the alarm details.

(1P2W display example)



(Display of circuit A measured values)



- * By pressing the [I/V/F/PF] or [P/Q] key, the instantaneous value display is switched.
- * By pressing the [E1] or [E2] key, the integrated value display is switched.

Measurement display list

key	Item	Instantaneous value display	Integrated value display	units
1	Current	0.000 to 9999	-----	A
2	Voltage A *1	0.000 to 9999	-----	V/kV
3	Voltage B *2	0.000 to 9999	-----	V/kV
4	Frequency	45.0 to 65.0	-----	Hz
5	Power factor	-1.00 to 1.00	-----	PF
1	Active power (each phase)	-9999 to 9999	-----	kW/MW
2	Active power (total)	-9999 to 9999	-----	kW/MW
3	Reactive power (each phase)	-9999 to 9999	-----	kvar/Mvar
4	Reactive power (total)	-9999 to 9999	-----	kvar/Mvar
1	Active energy (import)	-----	0 to 999999	kWh/MWh
2	Active energy (export)	-----	0 to 999999	kWh/MWh ("—" is lit)
3	Cumulative total reactive power	-----	0 to 999999	kvarh/Mvarh ("Total Q" is lit)
4	Reactive energy (import)	-----	0 to 999999	kvarh/Mvarh ("—" is lit)
5	Reactive energy (export)	-----	0 to 999999	kvarh/Mvarh ("—" is lit)
6	T1 active energy (import)	-----	0 to 999999	kWh/MWh
7	T2 active energy (import)	-----	0 to 999999	kWh/MWh
8	T3 active energy (import)	-----	0 to 999999	kWh/MWh
9	T4 active energy (import)	-----	0 to 999999	kWh/MWh
1	Active energy (import) (resettable)	-----	0 to 999999	kWh/MWh ("RESETTING" is lit)
2	Active energy (export) (resettable)	-----	0 to 999999	kWh/MWh ("—" is lit) ("RESETTING" is lit)
3	Cumulative total reactive power (resettable)	-----	0 to 999999	kvarh/Mvarh ("Total Q" is lit) ("RESETTING" is lit)
4	Reactive energy (import) (resettable)	-----	0 to 999999	kvarh/Mvarh ("—" is lit) ("RESETTING" is lit)
5	Reactive energy (export) (resettable)	-----	0 to 999999	kvarh/Mvarh ("—" is lit) ("RESETTING" is lit)
6	T1 active energy (import) (resettable)	-----	0 to 999999	kWh/MWh ("RESETTING" is lit)
7	T2 active energy (import) (resettable)	-----	0 to 999999	kWh/MWh ("RESETTING" is lit)
8	T3 active energy (import) (resettable)	-----	0 to 999999	kWh/MWh ("RESETTING" is lit)
9	T4 active energy (import) (resettable)	-----	0 to 999999	kWh/MWh ("RESETTING" is lit)
10	Conversion value	-----	0 to 999999	N/A

- * The unit such as k or M is switched automatically.
- * Although the indication value of the model KM-N3 main unit is returned to zero when the integrated value has reached the maximum, the unit continues to integrate the measured value. Correct values can be obtained by using the communication function.


- *1 Voltage A: The phase voltage and line voltage of the each phase and wire type are displayed.
- *2 Voltage B: The line voltage is displayed only for the three-phase four-wire type.

Setting mode

Setting item list

	MENU No.	Setting Item	Main display Display of options and input values	Default Value
Circuit A	A1	Phase and wire type	3P4W / 1P2W / 1P3W / 3P3W / 1P2W2 / 1P3W2	3P4W
	A2	Communication address	Modbus : --, 01 to 99 CompoWay/F : -- 00 to 99	01
	A3	Current on the CT secondary side	1A / 5A	5A
	A4	Current on the CT primary side	1 to 99999	5
	A5	Voltage assignment	V R / V T / V R-T	V R
	A6	Pulse output ON/OFF	ON / OFF	OFF
	A7	Active energy reset	-----	-----
Circuit B	B0	Circuit B ON/OFF	ON / OFF	OFF
	B1	Phase and wire type	The phase and wire type set by menu No. A1 is displayed.	
	B2	Communication address	Modbus : --, 01 to 99 CompoWay/F : -- 00 to 99	Automatic S/N
	B3	Current on the CT secondary side	1A / 5A	5A
	B4	Current on the CT primary side	1 to 9999	5
	B5	Voltage assignment	V R / V T / V R-T	V R
	B6	Pulse output ON/OFF	ON / OFF	OFF
B7	Active energy reset	-----	-----	
Circuit C	C0	Circuit C ON/OFF	ON / OFF	OFF
	C1	Phase and wire type	The phase and wire type set by menu No. A1 is displayed.	
	C2	Communication address	Modbus : --, 01 to 99 CompoWay/F : -- 00 to 99	Automatic S/N
	C3	Current on the CT secondary side	1A / 5A	5A
	C4	Current on the CT primary side	1 to 9999	5
	C5	Voltage assignment	V R / V T / V R-T	V R
	C6	Pulse output ON/OFF	ON / OFF	OFF
Circuit D	D0	Circuit D ON/OFF	ON / OFF	OFF
	D1	Phase and wire type	The phase and wire type set by menu No. A1 is displayed.	
	D2	Communication address	Modbus : --, 01 to 99 CompoWay/F : -- 00 to 99	Automatic S/N
	D3	Current on the CT secondary side	1A / 5A	5A
	D4	Current on the CT primary side	1 to 9999	5
	D5	Voltage assignment	V R / V T / V R-T	V R
	D6	Pulse output ON/OFF	ON / OFF	OFF
Common CMMN	D7	Active energy reset	-----	-----
	00	Protocol	MODBS / COMPF	MODBS
	01	Communication speed	1.2K / 2.4K / 4.8K 9.6K / 19.2K / 38.4K (bps)	9.6K
	02	Data length	7 / 8	8
	03	Stop bit	1 / 2	1
	04	Parity	NONE / ODD / EVEN	EVEN
	05	Transmission wait time	00 to 99	20
06	VT ratio	1.00 to 999.99	1.00	
07	Conversion rate	0.000 to 99.999	10.000	
Others ETC	08	Pulse output units	1 / 10 / 100 / 1K / 5K 10K / 50K / 100K (Wh)	100
	09	Automatic LCD off	OFF / 1.0 / 5.0 / 10.0 (minutes)	OFF
	0A	Alarm display with negative effective power value ON/OFF	ON / OFF	ON
	0B	Tariff ON/OFF	ON / OFF	OFF
	0C	Change password	0000 to 9999	0001
	90	Software version display	V.1.0.0	
	91	All active energy reset	-----	-----
92	Initialize	-----	-----	
93	Restart	-----	-----	

Setting example



To measure, you first need to make settings in the settings mode for the circuits and communications. Example settings are shown for the following conditions.

Circuit A	Circuit C
• Phase and wire type : 1P3W	• Circuit C ON/OFF : ON
• Current on the CT secondary side : 1A	• Phase and wire type : 1P3W
• Current on the CT primary side : 100A	• Current on the CT secondary side : 5A
• Communication address : 15	• Current on the CT primary side : 250A
• Pulse output ON/OFF : ON (automatically allocated to OUT1)	• Communication address : 16 (numbered starting from circuit A)
	• Pulse output ON/OFF : ON (automatically allocated to OUT3)

Items that have a minimum setting are as follows:

Circuit A settings	Circuit C settings
• Phase and wire type : MENU A1	• Circuit C ON/OFF : MENU C0
• Address number : MENU A2	• Current on the CT primary side : MENU C4
• Current on the CT secondary side : MENU A3	• Pulse output ON/OFF : MENU C6
• Current on the CT primary side : MENU A4	
• Pulse output ON/OFF : MENU A6	* The secondary current for CTs (MENU C3) does not need to be changed.

RS-485 communication settings	Pulse output settings
• Protocol : MENU 00	• Pulse output units : MENU 08
• Communication speed : MENU 01	
• Data length : MENU 02	
• Stop bit : MENU 03	
• Parity : MENU 04	
• Transmission wait time : MENU 05	

① Moving to the setting mode

- Press and hold the [MODE-⟨⟩] key to move to the password entry screen.




- Enter the password. Change the values using the [↵] and [⇩] keys. Press the [MODE-⟨⟩] to change the place. (Password default: 0001)
- Press the [ENTER] key to confirm the value. OK is displayed if the password is correct and the screen moves to the setting mode.
- * If you press the [ESC] key before press the [ENTER] key, current input is canceled. (Same for other settings.)


② Communications protocol settings (common settings)

Set to CompoWay/F

- Press the [MODE-⟨⟩] key to move to the common settings "CMMN" screen.



- Press the [⇩] key to move to the common settings items. "Protocol (MENU 00)" is displayed.
- Press the [ENTER] key to enter the setting mode. The setting value in the main display flashes.
- Press the [↵][⇩] keys to select "COMPF".
- Press the [ENTER] key to confirm your selection.




- * Make other communications settings to suit the host device.

③ Pulse output units settings (common settings)

Set to 10kWh/pulse


- Press the [MODE-⟨⟩] key to move to the common settings "CMMN" category display screen.
- From the common setting items, press the [↵][⇩] keys to move to "Pulse output units (MENU 08)".
- Press the [ENTER] key to enter the setting mode. The setting value in the main display flashes.
- Press the [↵][⇩] keys to select "10k".
- Press the [ENTER] key to confirm your selection.



④ Circuit A settings

Set the phase and wire type to 1P3W

- Press the [MODE-⟨⟩] key to move to the circuit A setting items.
- "Phase and wire type (MENU A1)" is displayed.
- Press the [ENTER] key to enter the setting mode. The setting value in the main display flashes.
- Press the [↵][⇩] keys to select "1P3W" (1-phase 3-wire).
- Press the [ENTER] key to confirm the selected items.



Set communication address of circuit A to 15

- On the setup items of circuit A, press [↵] or [⇩] key to move to the "Communication address (MENU A2)".
- Press the [ENTER] key to enter the setup mode. The ones place of the main display blinks.
- Press the [↵] or [⇩] key to change the numerical value to "15."

- By pressing the [MODE-⟨⟩] key, the cursor moves left by one digit.
- By pressing the [⇐] key at the leftmost digit, the cursor moves to the rightmost digit.
- Press the [ENTER] key to determine the settings.

*1 The communication address settings are assigned to circuit A. When multi-address is used, the values on the table below are assigned automatically.

*2 The communication addresses of circuits B-D cannot be set up individually.

	Circuit A	Circuit B	Circuit C	Circuit D
3-phase 4-wire	Setting value	---	---	---
1-phase 2-wire, 1-phase 2-wire voltage selected	Setting value	Setting value +1	Setting value +2	Setting value +3
1-phase 3-wire, 3-phase 3-wire	Setting value	---	Setting value +1	---
1-phase 3-wire composite	Setting value	---	Setting value +1	Setting value +2

Set the CT secondary side current to 1A

- From the circuit A setting item, press the [↵][⇩] keys to move to "CT secondary side current (MENU A3)".
- Press the [ENTER] key to enter the setting mode. The setting value in the main display flashes.
- Press the [↵][⇩] keys to select "1A".
- Press the [ENTER] key to confirm the selected items.




Set the CT primary side current to 100A

- From the circuit A setting item, press the [↵][⇩] keys to move to "CT primary side current (MENU A4)".
- Press the [ENTER] key to enter the setting mode. The digit in the ones place on the main display flashes.
- Press the [↵][⇩] keys to change the value to "100".
- Press the [MODE-⟨⟩] key to move one place to the left.
- If you press the [MODE-⟨⟩] key on the end at the left, the cursor moves to the right end.
- Press the [ENTER] key to confirm your change.





- From the circuit A setting item, press the [↵][⇩] keys to move to "Pulse output ON/OFF (MENU A6)".
- Press the [ENTER] key to enter the setting mode.
- Press the [↵][⇩] keys to select "ON".
- Press the [ENTER] key to confirm the selected items.



⑤ Circuit C settings

Enables circuit C

- Press the [MODE-⟨⟩] key to move to the settings screen for circuit C.
- Press the [⇩] key to move to the circuit C setting item. "Circuit C ON/OFF (MENU C0)" is displayed.
- Press the [ENTER] key to enter the setting mode. The setting value in the main display flashes.
- Press the [↵][⇩] keys to select "ON".
- Press the [ENTER] key to confirm the selected items.



Set CT primary side

- From the circuit C setting item, press the [↵][⇩] keys to move to "CT primary side current (MENU C4)".
- Set the same as for circuit A after this.




Setting pulse output ON or OFF

- From the circuit C setting item, press the [↵][⇩] keys to move to "Pulse output ON/OFF (MENU C6)".
- Set the same as for circuit A after this.

⑥ Reflecting the settings

- Press and hold the [MODE-⟨⟩] key to finish the settings and restart.
- * When the settings have been changed, the changes are saved when moving to the measurement mode and the unit restarts. Settings are not saved if the unit is turned off while still in the setting mode.



General agreement regarding use

Omron Products are designed and manufactured as general-purpose products for use in general industrial products. They are not intended to be used in the applications described below, therefore if you use Omron products in these applications, Omron provides no warranty for Omron products. However, this excepts cases where Omron has specified that it agrees to provide a warranty, even when used in the following applications.

- Applications with stringent safety requirements (For example, nuclear power control equipment, combustion equipment, aerospace equipment, railway equipment, elevator and lift equipment, amusement equipment, medical equipment, safety equipment, and other applications that could cause physical injury or result in the loss of life.)
- Applications that require high reliability (For example, supply systems for gas, water and electricity, etc., 24 hour continuous operating systems, financial settlement systems and other applications that handle rights and property.)
- Applications under severe conditions or in severe environments (For example, outdoor equipment, equipment exposed to chemical contamination, equipment exposed to electromagnetic interference and equipment exposed to vibration and shocks.)
- Applications under conditions or environments not described in catalogs or other publications.

In addition to the applications listed in (a) to (d), the products in this publication are not intended for use in automobiles (including for two-wheeled vehicles, and this description applies hereafter). Do not use for applications involving fitting to automobiles. Consult Omron staff for information about products suitable for use in automobiles.

The above are some of the conditions for use of this product. Please carefully read the warranties and limitations of liabilities printed in our most up-to-date catalogs and manuals, including accompanying catalogs and datasheets.

OMRON Corporation Tokyo, JAPAN	Industrial Automation Company Contact: www.ia.omron.com
Regional Headquarters OMRON EUROPE B.V. Sensor Business Unit Carl-Benz-Str. 4, D-71154 Nürtingen, Germany Tel: (49) 7032-811-0/Fax: (49) 7032-811-199	OMRON ASIA PACIFIC PTE. LTD. No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967 Tel: (65) 6835-3011/Fax: (65) 6835-2711
OMRON ELECTRONICS LLC 2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900/Fax: (1) 847-843-7787	OMRON (CHINA) CO., LTD. Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, Pudong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200