

Data Flow Controller DX-series Web UI

Operation Manual

DX100-0010

CPU Unit



V242-E1-02

NOTE

1. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of OMRON.
2. No patent liability is assumed with respect to the use of the information contained herein. Moreover, because OMRON is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice.
3. Every precaution has been taken in the preparation of this manual. Nevertheless, OMRON assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

Trademarks

- Microsoft, Windows, Excel, Visual Basic, and Microsoft Edge are either registered trademarks or trademarks of Microsoft Corporation in the United States and other countries.
- ODVA, CIP, CompoNet, DeviceNet, and EtherNet/IP are trademarks of ODVA.
- SpeedBee Synapse is a trademark of SALTYSTER Co., Ltd.
- Grafana is a trademark of Grafana Labs.

Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.

Copyrights

- Microsoft product screen shots used with permission from Microsoft.
- This product incorporates certain third party software. The license and copyright information associated with this software is available at https://www.fa.omron.co.jp/product/tool/dx-info/index_en.html.

Data Flow Controller DX Series Web UI Operation Manual

None

OMRON Corporation

Copyright © OMRON Corporation 2025 All Rights Reserved.

Table of contents

1. Introduction	3
1.1 Intended Audience	3
1.2 Safety Precautions	3
2. Initial Setup Procedure	4
2.1 First Login	4
2.2 Initial Setup	4
3. Description of Various Functions	9
3.1 Description of Various Functions	9
3.2 Overview of Web UI Functions	10
3.3 Mode Settings	14
3.4 Monitoring	16
3.5 Application Management	19
3.6 Utility Management	21
3.7 Account Management	53
3.8 System Settings	68
3.9 System Information	97
3.10 Shutdown Management	100
3.11 REST API	102
4. Secure Usage Guide	107
4.1 Managing Users	107
4.2 Strict Management of Tokens	107
5. Appendix	108

1. Introduction

This manual describes how to operate Data Flow Controller DX Series Web UI. By utilizing Data Flow Controller, it is possible to collect data from equipment on the manufacturing floor and integrate it with other systems.

1.1 Intended Audience

This manual is intended for the following users.

- Those who manage this Controller
- Those who actually configure and operate this Controller

1.2 Safety Precautions

The following functions allow changes to this Controller's network settings and system information. As a result, these changes may affect the behavior of installed applications and connected equipment.

Before using these functions, ensure that you thoroughly consider and verify any equipment impact.

2. Initial Setup Procedure

This section describes the initial setup procedure for introducing Data Flow Controller.

2.1 First Login

DFCadmin is the user registered by default in Data Flow Controller. The default set values for the DFCadmin user are as follows.

Item	Description
Login ID	DFCadmin
Permissions	Administrator
Password	omron

1. On the login screen, enter DFCadmin for id and omron for password, and press Login.

2.2 Initial Setup

After the first login, configure the settings on the initial setup screen.

The initial setup items are as follows.

Item	Description
Activate	Enter the activation code. for activating the product.
Change Initial Password	Change the password of the default user.
System Time Settings	Set the system time of the Controller.

Data Flow Controller Initial Setup Global - English ▾

Activate

Activation Code *

Update Initial Password

New Password *

New Password (Re-enter) *

System Time Settings

Time Zone * ▾

Date & Time *

[Terms of Use](#) : Agree to the Terms of Use and start using

2.2.1 Activate

Activate the product.

1. In the Serial No field under Activate, enter the serial No.

Activate

Activation Code *

2.2.2 Change Initial Password

Change the DFCadmin user's password from the default set value.

1. In the New Password and New Password (re-enter) fields under Update Initial Password, enter a desired password different from the one used during the first login.

Update Initial Password

New Password *

New Password (Re-enter) *

2.2.3 System Time Settings

Set the system time.

System Time Settings

Time Zone ▼
Tokyo·Osaka·Sapporo (UTC+09:00)

Date & Time ▼
mm/dd/yyyy --:--:-- --

Select Time Zone

1. Select the desired time zone from Time Zone in the System Time Settings field.

System Time Settings

Time Zone ▼
Tokyo·Osaka·Sapporo (UTC+09:00)

- Tokyo·Osaka·Sapporo (UTC+09:00)
- Shanghai·Beijing (UTC+08:00)
- Jakarta (UTC+07:00)
- Dhaka (UTC+06:00)
- New Delhi·Mumbai (UTC+05:30)
- Karachi (UTC+05:00)

SET TIME MANUALLY

1. Enter the system time in Date & Time.
2. By pressing the Get Current Time button, you can set the current date and time in Date & Time.

System Time Settings

Time Zone ▼
Tokyo·Osaka·Sapporo (UTC+09:00)

Date & Time ▼
mm/dd/yyyy --:--:-- --

2.2.4 Save Initial Setup

1. After reviewing the Terms of Use, check the Agree to the terms of use and start using box.
2. Press the Save button.

Data Flow Controller Initial Setup Global - English ▾

Activate

Activation Code

Update Initial Password

New Password

New Password (Re-enter)

System Time Settings

Time Zone

Date & Time

[Terms of Use](#) : Agree to the Terms of Use and start using

3. In the confirmation dialog, press the OK button.

Confirmation ✕

Initial settings will be saved.
Are you sure?

4. In the message dialog, press the OK button.

Message ✕

Initial setup completed.
Proceeding to network settings screen.

5. You will be navigated to the Network Settings screen. Refer to [Network Settings](#) and configure the network settings for this Controller.

Data Flow

Interface List operating

operating | DFCAdmin Administrator | Global - English

Interface List | TCP/IP Settings | DNS Settings | mDNS Settings | Proxy Settings

Interface List

Interface Name	Status	IP Address	Actions
eth0	up	192.168.1.100	Update

Note

After completing the initial setup, the Controller operates in setup mode. setup is the mode for changing the settings of the Controller. It is not the mode for running applications.

To run applications, you need to change the operating mode to operating mode. To change to operating mode, refer to [Mode Settings](#) and change the operating mode.

Alternatively, by restarting, it will start in operating mode from the next time onward. To restart, refer to [Restart](#) and perform the restart.

3. Description of Various Functions

3.1 Description of Various Functions

This section describes various functions.

The contents are as follows.

1. [Overview of Web UI Functions](#)
2. [Mode Settings](#)
3. [Monitoring](#)
4. [Application Management](#)
5. [Utility Management](#)
6. [Account Management](#)
7. [System Settings](#)
8. [System Information](#)
9. [Shutdown Management](#)
10. [REST API](#)

3.2 Overview of Web UI Functions

This section describes the overview of the Web UI.

3.2.1 Web UI Functions List

The Web UI provides the screen of Data Flow Controller that the user operates.

The Web UI provides the following functions.

Item	Description
Mode Settings	<p>Provides the following functions to set the operating mode of Data Flow Controller.</p> <ul style="list-style-type: none"> • Displaying the operating mode • Setting the operating mode <p>Refer to Mode Settings for details.</p>
Monitoring	<p>You can monitor the load status of Data Flow Controller.</p> <p>Provides the following functions for reviewing the SpeedBee Synapse/Grafana/dashboard generator settings and determining the USB memory replacement timing.</p> <ul style="list-style-type: none"> • Viewing the CPU, memory, and network usage • Viewing the storage usage status <p>Refer to Monitoring for details.</p>
Application Management	<p>Provides the following functions for managing applications.</p> <ul style="list-style-type: none"> • Viewing the application information • Viewing the application logs <p>Refer to Application Management for details.</p>
Utility Management	<p>Provides the following functions necessary for system operation.</p> <ul style="list-style-type: none"> • Viewing the logs • Managing the USB memory for application data storage • Managing the certificates and keys for enhanced security, and configuring TLS for reverse proxy using them <p>Refer to Utility Management for details.</p>
Account Management	<p>Provides the following functions for managing user accounts.</p> <ul style="list-style-type: none"> • Adding/Deleting user accounts • Changing user account roles • Resetting user account passwords <p>Refer to Account Management for details.</p>
System Settings	<p>System Settings provides the following functions.</p> <ul style="list-style-type: none"> • Configuring the network settings • Setting the time • Updating the firmware <p>Refer to System Settings for details.</p>
System Information	<p>Provides the following information related to Data Flow Controller.</p> <ul style="list-style-type: none"> • Production Information • System Information • License Information <p>Refer to System Information for details.</p>
Shutdown Management	<p>Shutdown Management provides the following functions.</p> <ul style="list-style-type: none"> • System shutdown • Restart <p>Refer to Shutdown Management for details.</p>
REST API	<p>Provides the following functions for operating Data Flow Controller from an external system.</p> <ul style="list-style-type: none"> • REST API <p>Refer to REST API for details.</p>

Data Flow

Monitoring setup setup DFCAdmin Administrator Global - English

- Monitoring
- Applications
- Application Management
- Utility
- Log Management
- Certificate & Key Management
- USB Port Management
- Reverse Proxy Settings
- Account Settings
- User Management
- System Settings
- Network Settings
- Date & Time
- Firmware
- System Information

CPU Usage

CPU Usage 9.56%

Memory Usage

Total: 3.73GB
Used: 0.52GB
Free: 2.27GB
Cache: 0.89GB

Memory Usage 14.06%

Storage

/dev/mmcblk0 normal

/dev/sda unsupported

/dev/sda1

Capacity 0.00GB / 0.00GB

Read: 0.00MB Write: 0.00MB

- Change Password
- Shutdown
- Restart
- Logout

3.3 Mode Settings

This section describes the mode settings.

The displayed items are as follows.

Item	Description
Mode Display	Displays the current operating mode.
Mode Setting	Sets the operating mode.



3.3.1 Mode Display

Displays the operating mode of the controller.

The displayed items are as follows.

Item	Description
setup	The setup state.
operating	The operating state. Indicates that the application is running.




3.3.2 Mode Setting

Sets the operating mode of the controller.

Mode Setting Method

Follow these steps to set the operating mode.

1. Press the Mode Setting button displayed on the right side of the header.



2. From the list of displayed items, select the mode you want to set.

*In this example, the mode is being changed from setup to operating.




3.4 Monitoring

This section describes the monitoring.

Monitoring items are retrieved every 5 seconds and displayed on the screen.

The monitoring items are as follows.

Item	Description
CPU Usage	Displays the CPU usage status of the Controller.
Memory Usage	Displays the memory usage status of the Controller.
Storage	Displays the storage usage status of the Controller.
Network Usage	Displays the network usage status of the Controller.



3.4.1 CPU Usage

The following items can be monitored in the CPU usage display area.


Item	Description
CPU Usage	Displays the CPU usage as a percentage and as a bar graph.



3.4.2 Memory Usage

The following items can be monitored in the memory usage display area.


Item	Description
Total	Displays the total memory capacity.
Used	Displays the used memory capacity.
Free	Displays the free memory capacity.
Cache	Displays the memory cache usage.
Memory Usage	Displays the memory usage as a percentage and as a bar graph.



3.4.3 Storage

The following items can be monitored per disk or partition in the storage display area.


Item	Description
Health Status	Displays the Health status of the embedded ROM.
Capacity	Displays the usage and capacity of the target partition, and shows the capacity as a bar graph.
Read	Displays the read speed of the target partition.
Write	Displays the write speed of the target partition.



3.4.4 Network Usage

The following items can be monitored per physical interface in the network usage display area.

Item	Description
Received	Displays the receive speed of the target interface.
Transmitted	Displays the transmit speed of the target interface.



3.5 Application Management

This section describes the application management.
The displayed items are as follows.

Item	Description
Application List	Displays a list of applications provided on the Controller.
Log Management	Display and download application logs.

Application Management operating operating DFCadmin Administrator Global - English

Application List Refresh

Status	Application Name	Version Info	Service	Action
running	/dashgen	dashboard-generator:release-20250822	Connect	View Logs Download Logs
running	/grafana	grafana-oss:11.6.2r2s	Connect	View Logs Download Logs
running	/synapse	speedbeesynapse:4.9.4-r0r2s	Connect	View Logs Download Logs

Log

```

2025-09-10T06:57:59.972836840Z INFO: Started server process [1]
2025-09-10T06:57:59.977550760Z INFO: Waiting for application startup.
2025-09-10T06:57:59.989067080Z resources sub directory created
2025-09-10T06:57:59.992192280Z INFO: Application startup complete.
2025-09-10T06:58:00.003455240Z INFO: Uvicorn running on http://0.0.0.0:8000 (Press CTRL+C to quit)

```

3.5.1 Application List

Displays a list of applications provided on this Controller.
The displayed items are as follows.

Item	Description
Refresh button	Operation button to refresh and re-display the application list
Status	Displays the operating status.
Application Name	Displays the application name.
Version Information	Displays the version information.
Service	Connect link
Action	View Logs button, Download Logs button

Pressing the Connect link button opens a new browser tab for accessing the corresponding application.
Pressing the View Logs button displays the target application log in the log display area. Pressing the Download Logs button downloads the target application log file.

Application Management operating operating DFCadmin Administrator Global - English

Application List Refresh

Status	Application Name	Version Info	Service	Action
running	/dashgen	dashboard-generator:release-20250822	Connect	View Logs Download Logs
running	/grafana	grafana-oss:11.6.2r2s	Connect	View Logs Download Logs
running	/synapse	speedbeesynapse:4.9.4-r0r2s	Connect	View Logs Download Logs

Log

```

2025-09-10T06:57:59.972836840Z INFO: Started server process [1]
2025-09-10T06:57:59.977550760Z INFO: Waiting for application startup.
2025-09-10T06:57:59.989067080Z resources sub directory created
2025-09-10T06:57:59.992192280Z INFO: Application startup complete.
2025-09-10T06:58:00.003455240Z INFO: Uvicorn running on http://0.0.0.0:8000 (Press CTRL+C to quit)
    
```

3.5.2 Log Management

Displays the logs of the application selected from the Application List.

Item	Description
Log display area	Displays the contents of application logs.

Application Management operating operating DFCadmin Administrator Global - English

Application List Refresh

Status	Application Name	Version Info	Service	Action
running	/dashgen	dashboard-generator:release-20250822	Connect	View Logs Download Logs
running	/grafana	grafana-oss:11.6.2r2s	Connect	View Logs Download Logs
running	/synapse	speedbeesynapse:4.9.4-r0r2s	Connect	View Logs Download Logs

Log


```

2025-09-10T06:57:59.972836840Z INFO: Started server process [1]
2025-09-10T06:57:59.977550760Z INFO: Waiting for application startup.
2025-09-10T06:57:59.989067080Z resources sub directory created
2025-09-10T06:57:59.992192280Z INFO: Application startup complete.
2025-09-10T06:58:00.003455240Z INFO: Uvicorn running on http://0.0.0.0:8000 (Press CTRL+C to quit)
    
```

3.6 Utility Management

This section describes the utility management.
The configurable items are as follows.


Item	Description
Log Management	Manage the logs of this Controller.
Certificate & Key Management	Manage certificates and private keys for reverse proxy.
USB Port Settings	Manage the USB ports of this Controller.
Reverse Proxy Settings	Configure the TLS settings of the reverse proxy of this Controller.



3.6.1 Log Management

Manage the logs of this Controller. The target management logs are as follows.


Item	Description
System Logs	Configure system log rotation settings and acquires logs.
Operation Logs	Acquires operation logs.



System Logs

Manage the system logs. The log setting items are as follows.

Item	Description
Log Filter	Performs filtering for acquiring system logs. View and download the acquired logs.
Log display area	This is a display area for viewing system logs.



LOG FILTER

Performs filtering for acquiring system logs. The setting items are as follows.

Item	Description
Log Level	Pulldown for selecting the log level of logs to acquire
Start Date/Time	From date of the log file to acquire
End Date/Time	To date of the log file to acquire
View Log button	Operation button to display the target log in the log display area
Download Log button	Operation button to download the log file

Log Filter

Log Level *

Start Date/Time *

End Date/Time *

VIEW LOG

You can view system logs by the following procedure.

1. Enter all values for log level, start date/time, and end date/time.

After entering them, press the View Log button.


Log Filter

Log Level *

Start Date/Time *

End Date/Time *

2. In the message dialog, press the OK button.



3. Check the contents of the log file in the Log display area.

Log

```

2025-09-10T15:57:22.995770+09:00 dx1 kernel: Booting Linux on physical CPU 0x0000000000 [0x410fd034]
2025-09-10T15:57:22.995971+09:00 dx1 kernel: Machine model: LS1043A RDB Board
2025-09-10T15:57:22.995977+09:00 dx1 kernel: earlycon: uart8250 at MMIO 0x00000000021c0500 (options '')
2025-09-10T15:57:22.995982+09:00 dx1 kernel: printk: bootconsole [uart8250] enabled
2025-09-10T15:57:22.995986+09:00 dx1 kernel: ef1: UEFI not found.
2025-09-10T15:57:22.995991+09:00 dx1 kernel: Reserved memory: created DMA memory pool at 0x00000008ffc00000, size 4 MiB
2025-09-10T15:57:22.996001+09:00 dx1 kernel: OF: reserved mem: initialized node qman-fqd, compatible id shared-dma-pool
2025-09-10T15:57:22.996006+09:00 dx1 kernel: Reserved memory: created DMA memory pool at 0x00000008fc000000, size 32 MiB
2025-09-10T15:57:22.996010+09:00 dx1 kernel: OF: reserved mem: initialized node qman-pfdr, compatible id shared-dma-pool
2025-09-10T15:57:22.996015+09:00 dx1 kernel: Reserved memory: created DMA memory pool at 0x00000008fe000000, size 16 MiB
2025-09-10T15:57:22.996019+09:00 dx1 kernel: OF: reserved mem: initialized node bman-fbpr, compatible id shared-dma-pool
2025-09-10T15:57:22.996024+09:00 dx1 kernel: NUMA: No NUMA configuration found
2025-09-10T15:57:22.996033+09:00 dx1 kernel: NUMA: Faking a node at [mem 0x0000000080000000-0x00000008fffffff]
2025-09-10T15:57:22.996038+09:00 dx1 kernel: NUMA: NODE_DATA [mem 0x8ff40a0c0-0x8ff40bfff]


```

DOWNLOAD LOG

You can download system logs by the following procedure.

1. Enter all values for log level, start date/time, and end date/time.
After entering them, press the Download Log button.

2. In the message dialog, press the OK button.



3. Confirm that the target log file has been downloaded.

Operation Logs

Manage the operation logs.

The log setting items are as follows.

Item	Description
Log Filter	Performs filtering for acquiring operation logs. View and download the acquired logs.
Log display area	This is a display area for viewing operation logs.

Web Operation Logs setup setup DFCadmin Administrator Global - English

System Logs **Web Operation Logs**

Log Filter

Start Date/Time End Date/Time

View Download

Log

```

2025-08-30T03:10:54.056320+09:00 Start Method:fwLicensesActivate Params:{"serial":"0100"}
2025-08-30T03:10:54.061256+09:00 End Method:fwLicensesActivate Result:{"result":"failure","errorCode":100,"params":{}}
2025-08-30T03:11:34.423938+09:00 2025-08-29 18:11:34.411 [INFO] POST /api/v1/system/initialize - 401 - 3ms - User: unknown -
{"userId":"unknown","method":"POST","path":"/api/v1/system/initialize","statusCode":401,"duration":3,"ip":"192.168.1.6","userAgent":"Mozilla
/5.0 (Windows NT 10.0; Win64; x64) AppleWebKit/537.36 (KHTML, like Gecko) Chrome/139.0.0.0 Safari/537.36","requestBody":
{"serial":"0010","system_datetime":{"manualDateTime":"2025-08-29 18:10:53","timeZone":"Asia/Tokyo","ntp":{"enabled":false}},"password":"
[REDACTED]"},"responseBody":{"success":false,"message":"not found user id in session"}}
2025-08-30T03:11:41.187943+09:00 2025-08-29 18:11:41.173 [INFO] POST /api/v1/login - 200 - 691ms - User: DFCadmin -
{"userId":"DFCadmin","method":"POST","path":"/api/v1/login","statusCode":200,"duration":691,"ip":"192.168.1.6","userAgent":"Mozilla/5.0
(Windows NT 10.0; Win64; x64) AppleWebKit/537.36 (KHTML, like Gecko) Chrome/139.0.0.0 Safari/537.36","requestBody":{"id":
{"version":"hybrid-
vi#","encryptedKey":"#BceKL8n7vF/eUTLw90uNBkfqA1Fs+teIpMd57IX4mjLTmMrzUuap6RRtFdmS/EHM2vB7A+7QeamlzEU0omG5dRWB64D1wBMtDNSuM+07DohJskR5+IG
NmQ1OV4kTKBtgr27PwEmJoo+C2f3rgPcVnYfLORcIDz9pL00qLxsMJUkEu8JJjOmOziLNI47AcZqHjisy2Ye3Hz61YY0bmVEdCeb2SdzNiFW26Wpc4CtItwcardujkLmhjsrIoDaV4A
xmWrlYf/jnm2w7ezX1bwIv3F9mbn2HwoxxWmGysSvStaxQmZZvltn8j5/Qm4QJQ9z98g90QZv7BLw8b+n1Zhrq==#","i#":"3j8JDU0rKvC89P9#","data":"ia/z01CLFH
MovlHXcNhpCh3iucnNSw#"},"password":"[REDACTED]"},"responseBody":{"success":true,"data":{"user":
{"id":"upjRc0P0J1fYp8ChDuzg0cd/IZts9dd20QjNln1PUFnf01","binded_roles":
["Administrator"],"enabled":true,"first_user":true,"force_change_password":true,"fixed_user":false,"latest":"2025-08-
29T09:10:39.413Z"},"initialized":false}}}
2025-08-30T03:11:56.293634+09:00 Start Method:hostOsSetTimeParams Params:{"manualDateTime":"2025-08-29
18:12:07","timeZone":"Asia/Tokyo","ntp":{"enabled":false}}
    
```

LOG FILTER

Performs filtering for acquiring operation log files. The setting items are as follows.

Item	Description
Start Date/Time	From date of the log file to acquire
End Date/Time	To date of the log file to acquire
View Log button	Operation button to display the target log in the log display area
Download Log button	Operation button to download the log file

Log Filter


Start Date/Time End Date/Time

View Download


VIEW LOG

You can view operation logs by the following procedure.

1. Enter all values for start date/time, and end date/time.
After entering them, press the View Log button.



2. In the message dialog, press the OK button.



3. Check the contents of the log file in the Log display area.



DOWNLOAD LOG

You can download operation logs by the following procedure.

1. Enter all values for start date/time, and end date/time.
After entering them, press the Download Log button.


Log Filter

Start Date/Time * 2025/08/29 22:02:46

End Date/Time * 2025/08/31 23:02:46

View Download

2. In the message dialog, press the OK button.



3. Confirm that the target log file has been downloaded.

3.6.2 Certificate & Key Management

Manage certificates and private keys for reverse proxy.

Certificate & Key Management setup DFAdmin Administrator Global - English

Reverse Proxy [Reverse Proxy Settings](#) Register Certificate

Certificate Key

Certificate Name	Enabled/Disabled	Creation Method	Type ↑	Algorithm	Certificate Key Length	Status	Action
dx1-dxc.crt	Disabled	Imported	Public	sha512WithRSAEncryption	2057	Available	...
SSLCertificate	Enabled	Imported	unknown	unknown	381	active	...

Certificate Management

Displays the registered certificates in list form.
The displayed items are as follows.

Item	Description
Register Certificate button	Operation button to register a certificate
Certificate Name	Certificate Name
Enabled/Disabled	Displays whether the certificate is enabled/disabled.
Creation Method	Displays the creation type of the certificate.
Type	Displays the type of the certificate.
Algorithm	Displays the algorithm of the certificate.
Key Length	Displays the length of the certificate key.
Status	Displays the status of the certificate.
Action	Displays operation categories using the three-dot leader. Refer to the table below for each operation category.

There are four operation categories.
Press to perform each operation.

Operation category	Description
Enable	Enable the selected certificate.
Update	Update the certificate.
Download	Downloads the certificate file.
Delete	Delete the certificate.

Certificate & Key Management setup DFAdmin Administrator Global - English


Reverse Proxy [Reverse Proxy Settings](#) Register Certificate

Certificate		Key					
Certificate Name	Enabled/Disabled	Creation Method	Type	Algorithm	Certificate Key Length	Status	Action
dxc-dx1.crt	Disabled	Imported	Public	sha512WithRSAEncryption	2057	Available	...
SSLCertificate	Enabled	Imported	unknown	unknown	381	acti	<ul style="list-style-type: none"> Enable Update Download Delete

REGISTER CERTIFICATE


You can register a certificate by the following procedure.

1. Press the Register Certificate button on the certificate management screen.




2. In the displayed Register Certificate dialog, enter all of the following items. After entering them, press the OK button.


Item	Description
Certificate Name	Field to enter the certificate name
Certificate File	Select the certificate file to register from the file dialog.



3. In the confirmation dialog, press the OK button.



4. In the message dialog, press the OK button.



CHANGING CERTIFICATE'S ENABLED/DISABLED STATUS

You can enable/disable a certificate by the following procedure.

1. Click the three-dot leader in the Actions Column of the certificate displayed in the certificate list and press Disable.

*In this example, the status is changed from Enabled to Disabled.

Certificate & Key Management setup setup DFCadmin Administrator Global - English

Reverse Proxy [Reverse Proxy Settings](#) Register Certificate

Certificate		Key					
Certificate Name	Enabled/Disabled	Creation Method	Type	Algorithm	Certificate Key Length	Status	Action
dx1-dx1.crt	Disabled	Imported	Public	sha512WithRSAEncryption	2057	Available	...
SSLCertificate	Enabled	Imported	unknown	unknown	381	act	<div style="border: 1px solid red; padding: 2px;">Enable</div> Update Download Delete

2. In the confirmation dialog, press the OK button.

Confirmation ×

Certificate will be enabled.
Are you sure?

Cancel OK

3. In the message dialog, press the OK button.

Message ×


Certificate enablement completed.

OK

UPDATE CERTIFICATE


You can update a certificate by the following procedure.

1. Click the three-dot leader in the Actions Column of the certificate displayed in the certificate list and press Update.




2. In the displayed Update Certificate dialog, enter the following item. After entering them, press the OK button.


Item	Description
Certificate File	Select the certificate file to register from the file dialog.



3. In the confirmation dialog, press the OK button.



4. In the message dialog, press the OK button.



DOWNLOAD CERTIFICATE

You can download a certificate file by the following procedure.

1. Click the three-dot leader in the Actions Column of the certificate displayed in the certificate list and press Download.

Certificate & Key Management setup setup DFCadmin Administrator Global - English

Reverse Proxy [Reverse Proxy Settings](#) [Register Certificate](#)

Certificate		Key						
Certificate Name	Enabled/Disabled	Creation Method	Type	Algorithm	Certificate Key Length	Status	Action	
dx1-dx1.crt	Disabled	Imported	Public	sha512WithRSAEncryption	2057	Available	...	
SSLCertificate	Enabled	Imported	unknown	unknown	381	active	Enable Update Download Delete	

DELETE CERTIFICATE

You can delete a certificate by the following procedure.

1. Click the three-dot leader in the Actions Column of the certificate displayed in the certificate list and press Delete.

Certificate & Key Management setup setup DFCadmin Administrator Global - English

Reverse Proxy [Reverse Proxy Settings](#) Register Certificate

Certificate		Key						
Certificate Name	Enabled/Disabled	Creation Method	Type	Algorithm	Certificate Key Length	Status	Action	
dxc-dx1.crt	Disabled	Imported	Public	sha512WithRSAEncryption	2057	Available	...	
SSLCertificate	Enabled	Imported	unknown	unknown	381	active	Enable Update Download Delete	

2. In the confirmation dialog, press the OK button.

Confirmation ×

Certificate will be deleted.
Are you sure?

Cancel OK

3. In the message dialog, press the OK button.

Message ×

Certificate deletion completed.

OK

Key Management

Displays the registered private keys in list form.
The displayed items are as follows.

Item	Description
Issue Key button	Operation button to issue a private key
Register Key button	Operation button to register a private key
Key Name	Name of the private key
Enabled/Disabled	Displays whether the private key is enabled/disabled.
Creation Method	Displays the creation type of the private key.
Type	Displays the type of the private key.
Algorithm	Displays the algorithm of the private key.
Key Length	Displays the length of the private key.
Status	Displays the status of the private key.
Action	Displays operation categories using the three-dot leader. Refer to the table below for each operation category.

There are four operation categories.
Press to perform each operation.

Operation category	Description
Enable	Enable the selected private key.
Update	Update the private key.
Download	Download the private key file.
Delete	Delete the key.

Certificate & Key Management setup DFCadmin Administrator Global - English

Reverse Proxy [Reverse Proxy Settings](#) + Issue Key Register Key


Certificate Key

Key Name	Enabled/Disabled	Creation Method	Type	Algorithm	Length	Status	Action
dx-c-dx1.key	Disabled	Imported	Public	RSA	3272	Available	...
Privatekey001	Enabled	Self-created	private key	RSA	1704	active	<ul style="list-style-type: none"> Enable Update Download Delete

ISSUE KEY


You can register a private key by the following procedure.

1. Press the Issue Key button on the certificate management screen.




2. In the displayed Issue Key dialog, enter the following item.
After entering them, press the OK button.


Item	Description
Key Name	Field to enter the private key name



3. In the confirmation dialog, press the OK button.




4. In the message dialog, press the OK button.



REGISTER KEY


You can register a private key by the following procedure.

1. Press the Register Key button on the key management screen.




2. In the displayed Register Key dialog, enter all of the following items. After entering them, press the OK button.


Item	Description
Key Name	Field to enter the private key name
Key File	Select the private key file to register from the file dialog.



3. In the confirmation dialog, press the OK button.



4. In the message dialog, press the OK button.



CHANGING KEY'S ENABLED/DISABLED STATUS

You can enable/disable a private key by the following procedure.

1. Click the three-dot leader in the Actions Column of the private key displayed in the key list and press Disable.
*In this example, the status is changed from Disabled to Enabled.

Certificate & Key Management setup setup DFCadmin Administrator Global - English

Reverse Proxy [Reverse Proxy Settings](#) + Issue Key Register Key

Certificate Key

Key Name	Enabled/Disabled	Creation Method	Type	Algorithm	Length	Status	Action
dx-c-dx1.key	Disabled	Imported	Public	RSA	3272	Available	...
Privatekey001	Enabled	Self-created	private key	RSA	1704	active	<div style="border: 1px solid red; padding: 2px;">Enable</div> Update Download Delete

2. In the confirmation dialog, press the OK button.

Disabled Imported Public RS

Confirmation ×

Key will be enabled.
Are you sure?

Cancel OK

3. In the message dialog, press the OK button.

Disabled Imported Public RS

Message ×


Key enablement completed.

OK

UPDATE KEY


You can update a private key by the following procedure.

1. Click the three-dot leader in the Actions Column of the private key displayed in the key list and press Update.




2. In the displayed Update Private Key dialog, enter the following item. After entering them, press the OK button.


Item	Description
Key File	Select the private key file to register from the file dialog.



3. In the confirmation dialog, press the OK button.



4. In the message dialog, press the OK button.



DOWNLOAD KEY

You can download a private key file by the following procedure.

1. Click the three-dot leader in the Actions Column of the private key displayed in the key list and press Download.

Certificate & Key Management setup setup DFCadmin Administrator Global - English

Reverse Proxy [Reverse Proxy Settings](#) + Issue Key Register Key

Certificate Key

Key Name	Enabled/Disabled	Creation Method	Type	Algorithm	Length	Status	Action
dx1-dx1.key	Disabled	Imported	Public	RSA	3272	Available	⋮
Privatekey001	Enabled	Self-created	private key	RSA	1704	active	<ul style="list-style-type: none"> Enable Update Download Delete

UPDATE KEY

You can delete a private key by the following procedure.

1. Click the three-dot leader in the Actions Column of the private key displayed in the key list and press Delete.

The screenshot shows the 'Certificate & Key Management' interface. At the top, there are tabs for 'Certificate' and 'Key'. Below the tabs is a table with columns: Key Name, Enabled/Disabled, Creation Method, Type, Algorithm, Length, Status, and Action. The table contains two rows: 'dxc-dx1.key' (Disabled, Imported, Public, RSA, 3272, Available) and 'Privatekey001' (Enabled, Self-created, private key, RSA, 1704, active). The 'Privatekey001' row is selected, and its context menu is open, showing options: Enable, Update, Download, and Delete. The 'Delete' option is highlighted with a red box.

2. In the confirmation dialog, press the OK button.

The screenshot shows a 'Confirmation' dialog box with a close button (X) in the top right corner. The text inside the dialog reads: 'Key will be deleted. Are you sure?'. At the bottom right, there are two buttons: 'Cancel' and 'OK'. The 'OK' button is highlighted with a red box.

3. In the message dialog, press the OK button.

The screenshot shows a 'Message' dialog box with a close button (X) in the top right corner. The text inside the dialog reads: 'Key deletion completed.'. At the bottom right, there is one button: 'OK'. The 'OK' button is highlighted with a red box.


3.6.3 USB Port Management

Manage the USB ports of this Controller.

USB Port List

Displays the USB ports of this Controller in list form.
The displayed items are as follows.


Item	Description
Port Name	USB port name
Port Status	Toggle switch for enable/disable control of the target USB port




Changing USB Port Status

You can change the Port Status (Enabled/Disabled) by the following procedure.

1. Press the Port Status toggle switch for the port displayed in the USB Port List.
*In this example, the status is changed from Enabled to Disabled.



2. In the message dialog, press the OK button.



3. Confirm that the Port Status has been changed.

3.6.4 Reverse Proxy Settings

Configure the reverse proxy settings of this Controller.

Reverse Proxy Settings operating

operating ▾

DFCadmin
Administrator ▾

Global - English ▾

Enable TLS Settings [Certificate & Key Management](#)

Enable TLS Disable TLS

Apply

TLS Setting Method

You can configure the enable/disable setting for TLS by the following procedure.

1. Select either Enable TLS or Disable TLS using the TLS Enable radio button.

*In this example, Enable TLS is set.

Reverse Proxy Settings setup setup DFCadmin Administrator Global - English

Enable TLS Settings [Certificate & Key Management](#)

Enable TLS Disable TLS

Apply

2. Press Apply.

Reverse Proxy Settings setup setup DFCadmin Administrator Global - English

Enable TLS Settings [Certificate & Key Management](#)

Enable TLS Disable TLS

Apply

3. In the confirmation dialog, press the OK button.

Confirmation ×

TLS settings will be saved.
Do you want to proceed?

Cancel OK

4. In the message dialog, press the OK button.

Message ×

TLS settings have been enabled.
Please log in again.

OK

5. Confirm that the TLS settings have been changed.

Reverse Proxy Settings

operating

operating ▾

DFCadmin
Administrator ▾

Global - English ▾

Enable TLS Settings [Certificate & Key Management](#)

Enable TLS Disable TLS

Apply

3.7 Account Management

This section describes the account management.

3.7.1 Viewing User List

Displays a list of Web UI users. The displayed items are as follows.

Item	Description
User ID	User ID
Permissions	Permissions
Status	Toggle switch for enabling/disabling a user
Last Login	Last login date and time
Access Token	Access token for external integration, display control switch, copy button
Action	Edit button, Delete button

User Management operating operating ▾ DFCadmin Administrator ▾ Global - English ▾


User List ⓘ Current Number of Users: 4users (Limit100users) + Create User

User ID	Permissions	Status	Last Login	Access Token	Actions
DFCadmin	Administrator	Enabled <input type="checkbox"/>	2025/09/10 12:54	-	Edit Delete
de1	Designer	Enabled <input checked="" type="checkbox"/>	-	<input type="text" value="....."/> <input type="checkbox"/> <input type="checkbox"/>	Edit Delete
ma1	Maintainer	Enabled <input checked="" type="checkbox"/>	-	-	Edit Delete
admin	Administrator	Enabled <input checked="" type="checkbox"/>	-	<input type="text" value="....."/> <input type="checkbox"/> <input type="checkbox"/>	Edit Delete

3.7.2 Adding User

You can add a user by the following procedure.

1. Press the Create User button on the User Management screen.



2. In the displayed Create New User dialog, enter all of the following items. After entering them, press the OK button.

Item	Description
User ID	This is an ID entered on login.
New Password	This is a password entered on login.
Confirm Password	This is an input item for confirming the password entered on login.
Permissions	Refer to the table below.
Access Token	Select whether to create an access token.
Force password change on next login	This is an input item to force a password change on the next login.

There are three types of user permissions.

Permission	Description
Administrator	All operations are available. It is assigned to the initial user "DFCadmin" and at least one person is required.
Designer	Operations other than user management and firmware management are available.
Maintainer	Monitoring, application management, and some utility management are available.

Create New User ✕

User ID *

New Password * 👁


Confirm Password * 👁

Permissions * ▼

Access Token * ▼


Force password change on next login

3. In the confirmation dialog, press the OK button.



The image shows a 'Create New User' dialog box with a confirmation message overlay. The dialog box has a title bar with 'Create New User' and a close button (X). The fields are: 'User ID' with the value 'Sampleuser001', 'New Password' (masked with dots), 'Confirm' (masked with dots), 'Permissions' with a dropdown menu showing 'Admin', and 'Access Token' with a dropdown menu showing 'Not generate'. There is a checkbox for 'Force password change on next login' which is checked. At the bottom right of the dialog box are 'Cancel' and 'OK' buttons. The confirmation message overlay is a white box with a title bar 'Confirmation' and a close button (X). The message text is 'User will be added. Are you sure?'. At the bottom right of the confirmation message are 'Cancel' and 'OK' buttons, with the 'OK' button highlighted by a red square.

4. In the message dialog, press the OK button.



The image shows a 'Message' dialog box with a title bar 'Message' and a close button (X). The message text is 'User has been added'. At the bottom right of the dialog box is an 'OK' button, which is highlighted by a red square.

5. Confirm that the user has been added.

User Management operating operating ▾ DFCadmin Administrator ▾ Global - English ▾


User List ⓘ Current Number of Users: 5users (Limit100users) + Create User

User ID	Permissions	Status	Last Login	Access Token	Actions
DFCadmin	Administrator	Enabled <input type="checkbox"/>	2025/09/10 12:54	-	Edit Delete
de1	Designer	Enabled <input checked="" type="checkbox"/>	- <input type="checkbox"/> <input type="checkbox"/>	Edit Delete
ma1	Maintainer	Enabled <input checked="" type="checkbox"/>	-	-	Edit Delete
admin	Administrator	Enabled <input checked="" type="checkbox"/>	- <input type="checkbox"/> <input type="checkbox"/>	Edit Delete
Sampleuser001	Administrator	Enabled <input checked="" type="checkbox"/>	-	-	Edit Delete

3.7.3 Changing User Information

You can change a user by the following procedure.

1. Press the Edit button for the user you want to edit in the User List.



2. In the displayed Edit User dialog, enter the following items you want to change.

*In this example, the permission is changed from Administrator to Designer.

After entering them, press the OK button.

Item	Description
New Password	This is a password entered on login.
Confirm Password	This is an input item for confirming the password entered on login.
Permissions	Refer to the table below.
Access Token	Choose to create, update, or delete the access token.
Force password change on next login	This is an input item to force a password change on the next login.

There are three types of user permissions.

Permission	Description
Administrator	All operations are available. It is assigned to the initial user "admin" and at least one person is required.
Designer	Operations other than user management and firmware management are available.
Maintainer	Monitoring, application management, and some utility management are available.

Edit User ✕

User ID *

New Password * 👁

Confirm Password * 👁


Permissions * ▼

Access Token * ▼

Force password change on next login


Cancel **OK**

3. In the confirmation dialog, press the OK button.



The image shows a screenshot of the 'Edit User' form. The form has several fields: 'User ID' with the value 'Sampleuser001', 'New Password' (masked with dots), 'Confirm' (masked with dots), 'Permissions' with a dropdown menu showing 'Design', and 'Access Token' with a dropdown menu showing 'Keep unchanged'. There is a checkbox labeled 'Force password change on next login' which is checked. At the bottom right of the form are 'Cancel' and 'OK' buttons. A white confirmation dialog box is overlaid on top of the form. The dialog box has a title 'Confirmation' and a close button 'X'. The text inside the dialog box reads 'User information will be updated. Are you sure?'. At the bottom of the dialog box are 'Cancel' and 'OK' buttons. The 'OK' button in the dialog box is highlighted with a red square.

4. In the message dialog, press the OK button.



The image shows a screenshot of a 'Message' dialog box. The dialog box has a title 'Message' and a close button 'X'. The text inside the dialog box reads 'User information has been updated'. At the bottom right of the dialog box is an 'OK' button, which is highlighted with a red square.

5. Confirm that the user information has been changed.

User Management operating operating DFCadmin Administrator Global - English

User List ⓘ Current Number of Users: 5users (Limit100users) + Create User

User ID	Permissions	Status	Last Login	Access Token	Actions
DFCadmin	Administrator	Enabled <input type="checkbox"/>	2025/09/10 14:11	-	Edit Delete
de1	Designer	Enabled <input checked="" type="checkbox"/>	- <input type="checkbox"/> <input type="checkbox"/>	Edit Delete
ma1	Maintainer	Enabled <input checked="" type="checkbox"/>	-	-	Edit Delete
admin	Administrator	Enabled <input checked="" type="checkbox"/>	- <input type="checkbox"/> <input type="checkbox"/>	Edit Delete
Sampleuser001	Designer	Enabled <input checked="" type="checkbox"/>	-	-	Edit Delete

3.7.4 Deleting User Information

You can delete a user by the following procedure.

1. Press the Delete button for the user displayed in the User List.

*In this example, SampleUser001 is deleted.

User Management operating operating DFCadmin Administrator Global - English

User List ⓘ Current Number of Users: 5users (Limit100users) + Create User

User ID	Permissions	Status	Last Login	Access Token	Actions
DFCadmin	Administrator	Enabled <input type="checkbox"/>	2025/09/10 12:54	-	Edit Delete
de1	Designer	Enabled <input checked="" type="checkbox"/>	- <input type="checkbox"/> <input type="checkbox"/>	Edit Delete
ma1	Maintainer	Enabled <input checked="" type="checkbox"/>	-	-	Edit Delete
admin	Administrator	Enabled <input checked="" type="checkbox"/>	- <input type="checkbox"/> <input type="checkbox"/>	Edit Delete
Sampleuser001	Administrator	Enabled <input checked="" type="checkbox"/>	-	-	Edit Delete

2. In the confirmation dialog, press the OK button.

Confirmation ×

User will be deleted. Are you sure?

Cancel OK

3. In the message dialog, press the OK button.

Message ×

User has been deleted

OK

4. Confirm that the user has been deleted.

User Management operating operating DFCadmin Administrator Global - English

User List ⓘ Current Number of Users: 4users (Limit100users) + Create User

User ID	Permissions	Status	Last Login	Access Token	Actions
DFCadmin	Administrator	Enabled <input type="checkbox"/>	2025/09/10 12:54	-	Edit Delete
de1	Designer	Enabled <input checked="" type="checkbox"/>	- <input type="checkbox"/> <input type="checkbox"/>	Edit Delete
ma1	Maintainer	Enabled <input checked="" type="checkbox"/>	-	-	Edit Delete
admin	Administrator	Enabled <input checked="" type="checkbox"/>	- <input type="checkbox"/> <input type="checkbox"/>	Edit Delete

3.7.5 Changing User Status

You can change the user status (Enabled/Disabled) by the following procedure.

1. Press the Status toggle switch for the user displayed in the User List.

*In this example, the status is changed from Enabled to Disabled.

User Management operating operating DFCadmin Administrator Global - English

User List ⓘ Current Number of Users: 5users (Limit100users) + Create User

User ID	Permissions	Status	Last Login	Access Token	Actions
DFCadmin	Administrator	Enabled <input type="checkbox"/>	2025/09/10 12:54	-	Edit Delete
de1	Designer	Enabled <input checked="" type="checkbox"/>	- 👁 📄	Edit Delete
ma1	Maintainer	Enabled <input checked="" type="checkbox"/>	-	-	Edit Delete
admin	Administrator	Enabled <input checked="" type="checkbox"/>	- 👁 📄	Edit Delete
Sampleuser001	Administrator	Enabled <input checked="" type="checkbox"/>	-	-	Edit Delete

2. In the message dialog, press the OK button.

Message ×

User has been disabled

OK

3. Confirm that the user status has been changed.

User Management operating operating DFCadmin Administrator Global - English

User List ⓘ Current Number of Users: 5users (Limit100users) + Create User

User ID	Permissions	Status	Last Login	Access Token	Actions
DFCadmin	Administrator	Enabled <input type="checkbox"/>	2025/09/10 14:11	-	Edit Delete
de1	Designer	Enabled <input checked="" type="checkbox"/>	- 👁 📄	Edit Delete
ma1	Maintainer	Enabled <input checked="" type="checkbox"/>	-	-	Edit Delete
admin	Administrator	Enabled <input checked="" type="checkbox"/>	- 👁 📄	Edit Delete
Sampleuser001	Designer	Disabled <input type="checkbox"/>	-	-	Edit Delete

3.7.6 About Access Token

If you choose to Create an access token in the Create New User dialog or the Edit User dialog, the access token will also be issued simultaneously with user creation or change.

Create New User ✕

User ID *

New Password *

Confirm Password *

Permissions * ▼
Administrator

Access Token * ▲
Generate

Not generate

Generate

Cancel
OK

The issued access token can be used with the [REST API](#).

User Management operating operating ▼ DFCadmin Administrator ▼ Global - English ▼

User List ⓘ Current Number of Users: 5users (Limit100users)


+ Create User

User ID	Permissions	Status	Last Login	Access Token	Actions
DFCadmin	Administrator	Enabled <input type="checkbox"/>	2025/09/10 14:11	-	Edit Delete
de1	Designer	Enabled <input checked="" type="checkbox"/>	-	<input type="text" value="....."/> 👁️ 📄	Edit Delete
ma1	Maintainer	Enabled <input checked="" type="checkbox"/>	-	-	Edit Delete
admin	Administrator	Enabled <input checked="" type="checkbox"/>	-	<input type="text" value="....."/> 👁️ 📄	Edit Delete
Sampleuser001	Designer	Enabled <input checked="" type="checkbox"/>	-	-	Edit Delete

3.8 System Settings

This section describes the system settings.
The configurable items are as follows.

Item	Description
Networks	Configure the network-related settings of this Controller.
Date & Time	Set the system time of this Controller.
Firmware	Update the firmware.



3.8.1 Network Settings

Configure the network-related settings of this Controller.
The network setting items are as follows.

Item	Description
Interface List	Displays the set values of network interfaces in list form.
TCP/IP Address Settings	Set the IP addresses per network interface.
DNS Settings	Configure the DNS settings of this Controller.
mDNS Settings	Configure the mDNS settings of this Controller.
Proxy Settings	Configure the proxy settings of this Controller.

Interface List operating operating ▾ DFCadmin Administrator ▾ Global - English ▾

Interface List
TCP/IP Settings
DNS Settings
mDNS Settings
Proxy Settings

Interface List			
Interface Name	Status	IP Address	Actions
eth0	up	192.168.1.100	Update

Interface List

Displays the set values of network interfaces of this Controller in list form.
The displayed items are as follows.

Item	Description
Interface Name	Physical interface name
Status	Displays the operating status.
IPv4 Address	IP address set for the corresponding interface
Action	Edit button: Pressing this navigates you to the TCP/IP Settings tab of the corresponding interface.

Interface List operating operating ▾ DFCadmin Administrator ▾ Global - English ▾

Interface List TCP/IP Settings DNS Settings mDNS Settings Proxy Settings

Interface Name	Status	IP Address	Actions
eth0	up	192.168.1.100	Update

TCP/IP Address Settings

Set the IP addresses for network interfaces.

When the IP address is automatically set by DHCP, the setting items are displayed as follows.

Item	Input method	Description
Interface	Pulldown	List of physical interface names
IP setting method	Radio button	Select whether to set the IP address by DHCP or manually.
IP Address	Label	IP address set for the corresponding interface
Subnet Mask	Label	Subnet mask set for the corresponding interface
Default Gateway	Label	Default gateway set for the corresponding interface

TCP/IP Settings operating operating ▾ DFCadmin Administrator ▾ Global - English ▾

Interface List **TCP/IP Settings** DNS Settings mDNS Settings Proxy Settings

Interface Selection

Select Interface
eth0 - 192.168.1.100 ▾

TCP/IP Settings

Use DHCP (Automatic) Set Static IP

Current Settings

IP Address	192.168.1.100 (Obtained from DHCP)
Subnet Mask	255.255.255.0 (Obtained from DHCP)
Default Gateway	192.168.1.1 (Obtained from DHCP)

[Apply](#)

When the IP address is manually set, the setting items are displayed as follows.

Item	Input method	Description
Interface	Pulldown	List of physical interface names
IP setting method	Radio button	Select whether to set the IP address by DHCP or manually.
IP Address	Text	IP address set for the corresponding interface
Subnet Mask	Text	Subnet mask set for the corresponding interface
Default Gateway	Text	Default gateway set for the corresponding interface

TCP/IP Settings operating operating ▾ DFCadmin Administrator ▾ Global - English ▾

Interface List **TCP/IP Settings** DNS Settings mDNS Settings Proxy Settings

Interface Selection

Select Interface
eth0 - 192.168.1.100 ▾

TCP/IP Settings

Use DHCP (Automatic) Set Static IP

Static IP Settings

IP Address *
192.168.1.100

Subnet Mask *
255.255.255.0

Default Gateway
192.168.1.1

Apply

IP ADDRESS SETTING METHOD

You can use the following procedure to set the IP address for the target interface.

 **WARNING**

If you change the IP address or hostname, communication with the Controller may become impossible and an error screen may be displayed. Please access it again with the new address.

1. Select the target interface from the pulldown list.

Interface Selection

Select Interface
eth0 - 192.168.1.100

2. Select the IP address setting method.

TCP/IP Settings

Use DHCP (Automatic) Set Static IP

Static IP Settings

IP Address
192.168.1.100

Subnet Mask
255.255.255.0

Default Gateway
192.168.1.1

Apply

3. If Set Static IP is selected, enter the following items.

Item	Input method	Description
IP Address	Text	IP address to be set for the corresponding interface
Subnet Mask	Text	Subnet mask to be set for the corresponding interface
Default Gateway	Text	Default gateway to be set for the corresponding interface

TCP/IP Settings

Use DHCP (Automatic) Set Static IP

Static IP Settings

IP Address
192.168.1.100

Subnet Mask
255.255.255.0

Default Gateway
192.168.1.1

Apply

4. Press the Apply button.

TCP/IP Settings

Use DHCP (Automatic) Set Static IP

Static IP Settings

IP Address *
192.168.1.100

Subnet Mask *
255.255.255.0

Default Gateway
192.168.1.1

Apply

5. In the confirmation dialog, press the OK button.

Confirmation

TCP/IP settings will be applied. Are you sure?

Cancel OK

6. In the message dialog, press the OK button.

Message

TCP/IP settings completed.

OK

DNS Settings

Configure the DNS settings of this Controller.

DNS Settings operating operating ▾ DFCadmin Administrator ▾ Global - English ▾

Interface List TCP/IP Settings **DNS Settings** mDNS Settings Proxy Settings

DNS Settings


Primary DNS *

Secondary DNS

DNS SETTING METHOD


You can set the DNS information by the following procedure.

1. Enter the address in Primary DNS.




The screenshot shows the 'DNS Settings' page in a web interface. At the top, there are navigation elements: 'operating' status, 'DFCadmin Administrator' user, and 'Global - English' language. Below this is a menu with 'Interface List', 'TCP/IP Settings', 'DNS Settings' (selected), 'mDNS Settings', and 'Proxy Settings'. The main content area is titled 'DNS Settings' and contains two input fields: 'Primary DNS' and 'Secondary DNS'. The 'Primary DNS' field contains the value '8.8.8.8' and is highlighted with a red rectangular box. The 'Secondary DNS' field is empty. An 'Apply' button is located at the bottom right of the settings area.

2. Enter the address in Secondary DNS.




This screenshot is similar to the previous one, but now the 'Secondary DNS' field contains the value '8.8.4.4' and is highlighted with a red rectangular box. The 'Primary DNS' field still contains '8.8.8.8'. The 'Apply' button remains at the bottom right.

3. Press Apply.




This screenshot shows the 'DNS Settings' page with both the 'Primary DNS' (8.8.8.8) and 'Secondary DNS' (8.8.4.4) fields filled. The 'Apply' button at the bottom right is now highlighted with a red rectangular box, indicating it should be pressed.

4. In the confirmation dialog, press the OK button.



5. In the message dialog, press the OK button.



mDNS Settings

Configure the mDNS settings of this Controller.

mDNS Settings operating operating DFCadmin Administrator Global - English

Interface List TCP/IP Settings DNS Settings **mDNS Settings** Proxy Settings

mDNS (Hostname) Settings

Enable mDNS
 Please enter the information provided by your network administrator.

Enter mDNS Name

Hostname (mDNS) .local


MDNS SETTING METHOD

You can set the mDNS information by the following procedure.

 **WARNING**


If you change the IP address or hostname, communication with the Controller may become impossible and an error screen may be displayed. Please access it again with the new address.

1. Turn the Set mDNS toggle switch to ON.




The screenshot shows the 'mDNS Settings' page. At the top, there are tabs for 'Interface List', 'TCP/IP Settings', 'DNS Settings', 'mDNS Settings', and 'Proxy Settings'. The 'mDNS Settings' tab is selected. Below the tabs, there is a section titled 'mDNS (Hostname) Settings'. In this section, the 'Enable mDNS' toggle switch is turned ON and is highlighted with a red square. Below this, there is a section titled 'Enter mDNS Name' with a text input field containing 'dx1' and '.local'. An 'Apply' button is located at the bottom right of the page.

2. Enter the mDNS name in Hostname (mDNS).




The screenshot shows the 'mDNS Settings' page. The 'Enable mDNS' toggle switch is now turned OFF. The 'Enter mDNS Name' section has a text input field containing 'dx1' and '.local', which is highlighted with a red square. An 'Apply' button is located at the bottom right of the page.

3. Press Apply.




The screenshot shows the 'mDNS Settings' page. The 'Enable mDNS' toggle switch is turned OFF. The 'Enter mDNS Name' section has a text input field containing 'dx1' and '.local'. The 'Apply' button at the bottom right is highlighted with a red square.

4. In the confirmation dialog, press the OK button.



5. In the message dialog, press the OK button.



Proxy Settings

Configure the proxy settings of this Controller.

- Interface List
- TCP/IP Settings
- DNS Settings
- mDNS Settings
- Proxy Settings**

Use Proxy

Use proxy server

Please enter the information provided by your network administrator.



Enter Proxy Server Settings

Script URL

http://proxy.example.com/config.pac

http

http://proxy.example.com:8080

https

https://proxy.example.com:8443

ftp

ftp://proxy.example.com:2121

Enter No Proxy Settings

Addresses not to use proxy

localhost,127.0.0.1

Authentication Settings

No authentication Use authentication

Apply

PROXY SETTING METHOD

You can set the proxy information by the following procedure.

1. Turn the Use proxy server toggle switch to ON.

Use Proxy

Use proxy server
Please enter the information provided by your network administrator.



2. Enter the following items for proxy server settings.

Item	Input method	Description
Proxy Auto-Configuration (PAC) URL	Text	URL for auto-configuration script
http Proxy	Text	Address for http connection
https Proxy	Text	Address for https connection
ftp Proxy	Text	Address for ftp connection

Enter Proxy Server Settings

Script URL
Script URL

http
http

https
https

ftp
ftp

3. To configure No Proxy settings, enter the address in Proxy exclusion hosts.

Enter No Proxy Settings

Addresses not to use proxy
Addresses not to use proxy

4. Select whether to use proxy authentication.

Authentication Settings

No authentication Use authentication

To set authentication information, click "Enter Authentication Information".

Enter Authentication Information

User Information

Username: Configured

Password: Configured

Apply

5. If Use authentication is selected, press the Enter Authentication Information button.

Authentication Settings

No authentication Use authentication

To set authentication information, click "Enter Authentication Information".

Enter Authentication Information

User Information

Username: **Configured**

Password: **Configured**

Apply

6. In the displayed Enter Authentication Information dialog, enter the following items.

Item	Input method	Description
Proxy Authentication User	Text	User ID for proxy server connection
Proxy Authentication Password	Text	Password for proxy server connection

Addresses not to use proxy

Add

Authentication Information Settings ✕

Username

Password 👁

User Information

Cancel **Save**

7. Press the Save button in the dialog.

Addresses not to use proxy

Add

Authentication Information Settings ✕

Username

Password 👁

User Information

Cancel **Save**

8. Press Apply.

Proxy Settings operating operating DFCadmin Administrator Global - English

Interface List TCP/IP Settings DNS Settings mDNS Settings **Proxy Settings**

Use Proxy

Use proxy server
Please enter the information provided by your network administrator.

Enter Proxy Server Settings

Script URL
http://proxy.example.com/config.pac

http
http://proxy.example.com:8080

https
https://proxy.example.com:8443

ftp
ftp://proxy.example.com:2121

Enter No Proxy Settings

Addresses not to use proxy
localhost,127.0.0.1

Authentication Settings

No authentication Use authentication
To set authentication information, click "Enter Authentication Information".


Enter Authentication Information

User Information


Username:	Configured
Password:	Configured

Apply

9. In the confirmation dialog, press the OK button.



10. In the message dialog, press the OK button.



3.8.2 Time Settings

Set the system time of this Controller.

The system time setting items are as follows.

Item	Input method	Description
Time Zone	Pulldown	Displays a list of selectable time zones.
NTP usage setting	Radio button	Select whether to set the time by NTP synchronization or manually.
Date & Time	Text box	When performing manual setting, enter the date and time to be set.
NTP Server 1	Text	When using NTP, directly enter the NTP server information to be used.
NTP Server 2	Text	When using NTP, directly enter the NTP server information to be used. (Optional)

System Time Settings

Time Zone ▾
Tokyo·Osaka·Sapporo (UTC+09:00) ▾

Sync with NTP Server Set Time Manually

Date & Time ▾
2025/06/14 14:30:00

NTP Server Address (Primary) ▾
ntp.example.com

NTP Server Address (Secondary) ▾
ntp2.example.com

Apply

Time Setting Method

You can set the system time by the following procedure.

1. Select the desired time zone from Time Zone in the System Time Settings field.

Date & Time operating operating DFCadmin Administrator Global - English

System Time Settings

Time Zone *

Sync with NTP Server Set Time Manually

Date & Time *

NTP Server Address (Primary) *

NTP Server Address (Secondary)

Apply

2. Select either Sync with NTP Server or Set Time Manually using the radio button.

Date & Time operating operating DFCadmin Administrator Global - English

System Time Settings

Time Zone *

Sync with NTP Server Set Time Manually

Date & Time *

NTP Server Address (Primary) *

NTP Server Address (Secondary)

Apply

3. If Sync with NTP Server is selected using the radio button, enter one or more NTP server URLs in NTP Server.

Date & Time operating operating DFCadmin Administrator Global - English

System Time Settings

Time Zone *
Tokyo·Osaka·Sapporo (UTC+09:00) ▼

Sync with NTP Server Set Time Manually

Date & Time *
2025/06/14 14:30:00

NTP Server Address (Primary) *
ntp.example.com

NTP Server Address (Secondary)
ntp2.example.com

Apply

4. If Set Time Manually is selected using the radio button, enter the system time in Date & Time.

Date & Time operating operating DFCadmin Administrator Global - English

System Time Settings

Time Zone *
Tokyo·Osaka·Sapporo (UTC+09:00) ▼

Sync with NTP Server Set Time Manually

Date & Time *
2025/06/14 14:30:00 📅

NTP Server Address (Primary) *
ntp.example.com

NTP Server Address (Secondary)
ntp2.example.com

Apply

5. Press the Apply button.

Date & Time operating operating DFCadmin Administrator Global - English

System Time Settings

Time Zone •
Tokyo·Osaka·Sapporo (UTC+09:00) ▼

Sync with NTP Server Set Time Manually

Date & Time •
2025/06/14 14:30:00

NTP Server Address (Primary) •
ntp.example.com

NTP Server Address (Secondary)
ntp2.example.com

Apply

6. In the confirmation dialog, press the OK button.

Sync with NTP Server Set Time Manually

Date & Time •
2025/06/14

NTP Server Address
ntp.example.com

NTP Server Address (Secondary)
ntp2.example.com

Confirmation ×

Date and time settings will be saved.
Are you sure?

Cancel **OK**

7. In the message dialog, press the OK button.

Sync with NTP Server Set Time Manually

Date & Time •
2025/06/14

NTP Server Address
ntp.example.com

NTP Server Address (Secondary)
ntp2.example.com

Message ×

Date and time settings completed.

OK

3.8.3 Firmware Management

Manage the firmware update of this Controller.

Update setup

setup ▾

DFCadmin
Administrator ▾

Global - English ▾

Update File List

Current Version

Target Version

Action

1.0.0

0.4.2

[Start Update](#)

How to Update the Firmware


You can update the firmware by the following procedure.

1. Press the Start Update button for the target bundle version.


*In this example, the version is updated to v0.3.5 .

Update File List		
Current Version	Target Version	Action
1.0.0	0.3.5	Start Update


2. In the displayed system update dialog, press the Execute button.



3. The update process is executed. Wait until the update is complete.



4. Check the message displayed in the dialog, power off the controller.



3.9 System Information

This section describes the system information.
The displayed items are as follows.

Item	Description
Product Manual	Displays a link to the operation manual of the Controller.
Production Information	Displays the production information of the Controller.
System Information	Displays the system information of the Controller.
License	Displays the OSS information used by the Controller.

System Information operating
operating ▾ DFCAdmin Administrator ▾ Global - English ▾

Product Manual

[View Manual](#) [View Tutorial Video](#)

Production Information

Model Type	DX100-0010
Production Factory	K01
Lot No.	14725
Serial No.	0010
Hardware Version	/A

System Information

Unit Version	1.0.0
Cumulative Operation Time	3820minutes
Continuous Operation Time	69minutes
Hostname	dx1
Architecture	ARM64
Network Interface	eth0 (00-00-0A-B1-9E-4E) eth1 (00-00-0A-B1-9E-4F)

License

[@babel/helper-string-parser@7.25.9 - The Babel Team \(MIT\)](#)
<https://github.com/babel/babel>

[@babel/helper-validator-identifier@7.25.9 - The Babel Team \(MIT\)](#)
<https://github.com/babel/babel>

[@babel/parser@7.27.0 - The Babel Team \(MIT\)](#)
<https://github.com/babel/babel>

[@babel/types@7.27.0 - The Babel Team \(MIT\)](#)
<https://github.com/babel/babel>

[@esbuild/linux-arm64@0.25.2 \(MIT\)](#)
<https://github.com/evaneos/esbuild>

[@eslint-community/eslint-utils@4.5.1 - Toru Nagashima \(MIT\)](#)
<https://github.com/eslint-community/eslint-utils>

[@eslint-community/eslint-utils@4.7.0 - Toru Nagashima \(MIT\)](#)
<https://github.com/eslint-community/eslint-utils>

[@eslint-community/regexpp@4.12.1 - Toru Nagashima \(MIT\)](#)
<https://github.com/eslint-community/regexpp>

RAUC - RAUC (LGPL-2.1)
<https://github.com/rauc/rauc>

3.9.1 Product Manual

Displays a link to the operation manual of the Web UI.
Clicking the link will display the manual in a separate tab.

Product Manual

[View Manual](#) [View Tutorial Video](#)

3.9.2 Production Information

The following items are displayed in the production information display area.

Item
Model Type
Production Factory
Lot No.
Serial No.
Hardware Version

Production Information	
Model Type	DX100-0010
Production Factory	K01
Lot No.	14725
Serial No.	0010
Hardware Version	/A

3.9.3 System Information

The following items are displayed in the system information display area.

Item	Description
Unit Version	Displays the unit version of the Controller.
Cumulative Operation Time	Displays the cumulative operation time of the Controller.
Continuous Operation Time	Displays the continuous operation time of the Controller.
Hostname	Displays the hostname of the Controller.
Architecture	Displays the CPU architecture provided on the Controller.
Network Interface	Displays the interface name of the Controller.

System Information	
Unit Version	1.0.0
Cumulative Operation Time	3820minutes
Continuous Operation Time	69minutes
Hostname	dx1
Architecture	ARM64
Network Interface	eth0 (00-00-0A-B1-9E-4E) eth1 (00-00-0A-B1-9E-4F)

3.9.4 License

The OSS information used by the Controller is displayed in the license display area.

License

@babel/helper-string-parser@7.25.9 - The Babel Team (MIT)
<https://github.com/babel/babel>

@babel/helper-validator-identifier@7.25.9 - The Babel Team (MIT)
<https://github.com/babel/babel>

@babel/parser@7.27.0 - The Babel Team (MIT)
<https://github.com/babel/babel>

@babel/types@7.27.0 - The Babel Team (MIT)
<https://github.com/babel/babel>

@esbuild/linux-arm64@0.25.2 (MIT)
<https://github.com/esome/esbuild>

@eslint-community/eslint-utils@4.5.1 - Toru Nagashima (MIT)
<https://github.com/eslint-community/eslint-utils>

@eslint-community/eslint-utils@4.7.0 - Toru Nagashima (MIT)
<https://github.com/eslint-community/eslint-utils>

@eslint-community/regexpp@4.12.1 - Toru Nagashima (MIT)
<https://github.com/yujs/core>

RAUC - RAUC (LGPL-2.1)
<https://github.com/rauc/rauc>

3.10 Shutdown Management

This section describes the shutdown management.

3.10.1 Shutdown

Shuts down the system of this Controller.


Shutdown Procedure

Use the following procedure to shut down the Controller.


1. Press the username displayed at the right part of the header.




2. From the displayed list, press Shutdown.



3. In the confirmation dialog, press the OK button.



4. Wait until the shutdown is complete.



3.10.2 Restart

Restarts the system of this Controller.


Restart Procedure

Use the following procedure to restart the Controller.


1. Press the username displayed at the right part of the header.




2. From the displayed list, press Restart.



3. In the confirmation dialog, press the OK button.



4. Wait until the restart is complete.



3.11 REST API

3.11.1 Introduction to the API

Some operations of Data Flow Controller can be performed externally using the API.

3.11.2 How to Execute the API

Here, we describe how to execute the API using the curl command as an example.

If curl is not installed, download it from the official curl website and install it on your machine.

1. Open an environment to execute the curl command. On Linux, open the terminal; on Windows, open the command prompt.
2. Copy the Request using the curl command of each API in [API Specifications](#) and paste it into the environment to execute the curl command.
*Some parts of the Request using the curl command need to be replaced. Refer to [Common Items](#) for details.
3. Pressing the Enter key will execute the API, and the response will be displayed.
Refer to the Response of each API in [API Specifications](#) for details of the response.

The Request using the curl command of each API in [API Specifications](#) specifies the following items.
When executing the API using a method other than the curl command, the same items need be specified.

Item	Description
HTTP method	Specified in the form of -X "~~~".
Request URL	This is a URL starting with "http://".
HTTP header	Specified in the form of -H "~~~".
Data transmitted with PUT method or POST method	Specified in the form of -d "~~~".

3.11.3 API Specifications

Provides a list of operations that can be performed using the API, along with their request methods and responses. By understanding the API specifications and transmitting identical requests from various programs, usage across various programming languages and integration with control programs are enabled.

Refer to [API Interface](#) for the document of detailed API specifications.

Common Items

The following list contains common items for the contents provided in the subsequent request examples.

- should be replaced with the host and port where Data Flow Controller is running.
- should be replaced with the access token issued in [About Access Token](#).
- If a reverse proxy is configured, access via https.

Retrieving Main Unit Information

- Introduction

Retrieves the main unit status of Data Flow Controller.

- Request URL

```
http://<Data Flow Controller host:port>/api/v1/fwGetStatus
```

- Request using the curl command

Linux Windows

```
$ curl -X "GET" "http://<Data Flow Controller host:port>/api/v1/fwGetStatus" -H "accept: application/json" -H "X-API-Token: <Access Token>"
```

```
$ curl.exe -X "GET" "http://<Data Flow Controller host:port>/api/v1/fwGetStatus" -H "accept: application/json" -H "X-API-Token: <Access Token>"
```

- Response

Code	Description
200	Normal (OK)
400	Request error (Bad Request)
401	Authentication error (Unauthorized)
403	Authentication error (Forbidden)
404	Nonexistence error (Not Found)
409	Request conflict (Conflict)
429	Request limit exceeded (Too Many Requests)
500	Server error (Internal Server Error)
503	Service unavailable (Service Unavailable)

The normal response is in the following format.

```
{
  "success": "Completion flag (boolean value)",
  "data": {
    "state": "Main unit status of Data Flow Controller",
    "abnormalState": "Main unit abnormal status of Data Flow Controller",
    "activated": "Status of activation (boolean value)",
    "restartRequired": "Restart required flag (boolean value)",
  }
}
```

Updating Main Unit Information

- Introduction

Update the main unit status of Data Flow Controller.

- Request URL

```
http://<Data Flow Controller host:port>/api/v1/fwSetStatus
```

- Request using the curl command

Linux Windows

```
$ curl -X "POST" "http://<Data Flow Controller host:port>/api/v1/fwSetStatus" -H "accept: application/json" -H "X-API-Token: <Access Token>" -d "{ \"state\": \"<Main unit status code>\" }"
```

```
$ curl.exe -X "POST" "http://<Data Flow Controller host:port>/api/v1/fwSetStatus" -H "accept: application/json" -H "X-API-Token: <Access Token>" -d "{ \"state\": \"<Main unit status code>\" }"
```

- Response

Code	Description
200	Normal (OK)
400	Request error (Bad Request)
401	Authentication error (Unauthorized)
403	Authentication error (Forbidden)
404	Nonexistence error (Not Found)
409	Request conflict (Conflict)
429	Request limit exceeded (Too Many Requests)
500	Server error (Internal Server Error)
503	Service unavailable (Service Unavailable)

The normal response is in the following format.

```
{
  "success": "Completion flag (boolean value)",
  "data": {}
}
```

Shutdown

- Introduction

Transmits the shutdown request of Data Flow Controller.

- Request URL

```
http://<Data Flow Controller host:port>/<subpath>/api/v1/shutdownStart
```

- Request using the curl command

Linux	Windows
-------	---------

```
$ curl -X "POST" "http://<Data Flow Controller host:port>/api/v1/shutdownStart" -H "accept: application/json" -H "X-API-Token: <Access Token>"
```

```
$ curl.exe -X "POST" "http://<Data Flow Controller host:port>/api/v1/shutdownStart" -H "accept: application/json" -H "X-API-Token: <Access Token>"
```

- Response

Code	Description
200	Normal (OK)
400	Request error (Bad Request)
401	Authentication error (Unauthorized)
403	Authentication error (Forbidden)
404	Nonexistence error (Not Found)
409	Request conflict (Conflict)
429	Request limit exceeded (Too Many Requests)
500	Server error (Internal Server Error)
503	Service unavailable (Service Unavailable)

The normal response is in the following format.

```
{
  "success": "Completion flag (boolean value)",
  "data": {}
}
```

Restart

- Introduction

Transmits the restart request of Data Flow Controller.

- Request URL

```
http://<Data Flow Controller host:port>/<subpath>/api/v1/rebootStart
```

- Request using the curl command

Linux	Windows
-------	---------

```
$ curl -X "POST" "http://<Data Flow Controller host:port>/api/v1/rebootStart" -H "accept: application/json" -H "X-API-Token: <Access Token>"
```

```
$ curl.exe -X "POST" "http://<Data Flow Controller host:port>/api/v1/rebootStart" -H "accept: application/json" -H "X-API-Token: <Access Token>"
```

• Response

Code	Description
200	Normal (OK)
400	Request error (Bad Request)
401	Authentication error (Unauthorized)
403	Authentication error (Forbidden)
404	Nonexistence error (Not Found)
409	Request conflict (Conflict)
429	Request limit exceeded (Too Many Requests)
500	Server error (Internal Server Error)
503	Service unavailable (Service Unavailable)

The normal response is in the following format.

```
{
  "success": "Completion flag (boolean value)",
  "data": {}
}
```

4. Secure Usage Guide

This section describes how to use Data Flow Controller securely.

4.1 Managing Users

This section describes how to manage users in order to enhance the security level.

Disabling the admin user

The admin user is a default user registered in Data Flow Controller. This user is granted all permissions. To prevent abuse through unauthorized access, it is recommended to disable it unless necessary. Before disabling it, ensure that another user with system administrator permissions has been added.

For how to disable users, refer to [Account Management](#).

Strong password policy

It is desirable that the passwords registered for users be strong. Examples of the strong password policy are shown below. When using a tool to generate passwords automatically, you are recommended to generate a password that meets the following criteria.

- Contains at least 8 characters in length
- Contains at least one uppercase letter, one lowercase letter, one number, and one symbol
- Different from passwords used for other accounts
- Cannot be guessed from personal information such as names
- Does not use English words as they are
- Does not use easily guessable patterns or simple combinations of them

4.2 Strict Management of Tokens

[Access tokens](#) represent access permission to access resources when connecting to Data Flow Controller from external sources.

If a malicious attacker abuses any access token, there is a risk of unauthorized access to the resources of Data Flow Controller. It is recommended to manage access tokens strictly to prevent them from falling into the hands of third parties.

5. Appendix

- API Interface

Data Flow Controller API Specification (1.0.0)

System

Returns the firmware status

This operation can be executed with any roles.

HEADER PARAMETERS

→ X-API-Token required	string Example: <code>your-token-here</code> API authentication token
----------------------------------	---

Responses

✓ **200 OK**

RESPONSE SCHEMA: `application/json`

└ success	boolean
└ data >	object

— **400** Bad Request

— **401** Unauthorized

— **403** Forbidden

— **404** Not Found

— 409 Conflict

— 429 Too Many Requests

— 500 Internal Server Error

— 503 Service Unavailable

GET /fwGetStatus

Response samples

200

Content type

application/json

Copy Expand all Collapse all

```
{
  "success": true,
  "data": {
    "state": "string",
    "abnormalState": "string",
    "activated": true,
    "restartRequired": true
  }
}
```

Updates the firmware status

This operation can be executed with any roles.

HEADER PARAMETERS

→ X-API-Token **required** string
Example: `your-token-here`
API authentication token

REQUEST BODY SCHEMA: application/json
required

state string
required Enum: "operating" "setup"
The firmware mode to set

Responses

✓ 200 OK

RESPONSE SCHEMA: application/json

success boolean
data object

— 400 Bad Request

— 401 Unauthorized

— 403 Forbidden

— 404 Not Found

— 409 Conflict

— 429 Too Many Requests

— 500 Internal Server Error

— 503 Service Unavailable

POST /fwSetStatus

Request samples

Payload

Content type

application/json

Copy

```
{
  "state": "operating"
}
```

Response samples

200

Content type

application/json

Copy Expand all Collapse all

```
{
  "success": true,
  "data": { }
}
```

Shuts down the Controller

This operation can be executed with any roles.

HEADER PARAMETERS

→ X-API-Token required string
Example: `your-token-here`
API authentication token

Responses

✓ 200 OK

RESPONSE SCHEMA: application/json

└ success boolean

data

object

— 400 Bad Request

— 401 Unauthorized

— 403 Forbidden

— 404 Not Found

— 409 Conflict

— 429 Too Many Requests

— 500 Internal Server Error

— 503 Service Unavailable

POST /shutdownStart



Response samples

200

Content type
application/json

Copy Expand all Collapse all

```
{
  "success": true,
  "data": { }
}
```

Restarts the Controller

This operation can be executed with any roles.

HEADER PARAMETERS

→ X-API-Token
required

string

Example: `your-token-here`

API authentication token

Responses

✓ 200 OK

RESPONSE SCHEMA: application/json

└─ success	boolean
└─ data	object

— 400 Bad Request

— 401 Unauthorized

— 403 Forbidden

— 404 Not Found

— 409 Conflict

— 429 Too Many Requests

— 500 Internal Server Error

— 503 Service Unavailable

POST /rebootStart



Response samples

200

Content type
application/json

Copy Expand all Collapse all

```
{  
  "success": true,  
  "data": { }  
}
```

OMRON Corporation Industrial Automation Company

Kyoto, JAPAN

Contact : www.ia.omron.com



Tutorial Video

<https://www.fa.omron.co.jp/dx1/video-manual/en/>



Authorized Distributor:

©OMRON Corporation 2025 - 2026 All Rights Reserved.
In the interest of product improvement,
specifications are subject to change without notice.

Cat. No. V242-E1-02 0226