

# Safety Laser Scanner OS32C Series

# **User's Manual**



P/N 99863-0010 Rev.S Manual No. Z296-E1-16

# **Original Detailed Instructions**

#### Introduction

Thank you for purchasing the OS32C Safety Laser Scanner (herein after referred to as the "OS32C" ). This is the instruction Manual describing the use of the OS32C. Always take into account the following points when using the OS32C:

Make sure OS32C is handled by a "Responsible Person" who is well aware of and familiar with the machine to be installed. The term "Responsible Person" used in this Instruction Manual means the person qualified, authorized and responsible to secure "safety" in each process of the design, installation, operation, maintenance services and disposition of the machine. It is assumed that the OS32C will be used properly according to the installation environment, performance and function of the machine. A responsible Person should conduct a risk assessment of the machine and determine the suitability of this product before installation. Read this Manual thoroughly and understand its contents.

#### **Trademarks**

- Windows, Windows XP, Windows 7, Windows 8.1 and Windows 10 are either registered trademarks or trademarks of Microsoft Corporation in the USA and other countries.
- ODVA and EtherNet/IP™ are trademarks of ODVA, Inc.
- Other company names and product names in this document are the trademarks or registered trademarks of their respective companies.
- Microsoft product screen shot(s) reprinted with permission from Microsoft Corporation.

# Legislation and Standards

- 1. Application of an OS32C sensor by itself cannot receive the type approval provided by Article 44-2 of the Labor Safety and Health Law of Japan. It is necessary to apply it as a system. Therefore, when using this product in Japan as a "safety system for presses and shearing machines" as prescribed in Article 42 of the Labor Safety and Health Law, the complete system must receive the type approval.
- 2. (1) This product is electro-sensitive protective equipment (ESPE) in accordance with European Union (EU) Machinery Directive Index Annex V, Item 2.
  - (2) This product complies with the following legislation and standards:

1) EU legislation Machinery Directive 2006/42/EC

EMC Directive 2014/30/EU

2) European & International EN IEC 61496-1 (Type 3 ESPE)

Standards EN ISO 13849-1

IEC 61496-1 (Type 3 ESPE) IEC 61496-3 (Type 3 AOPDDR) IEC 61508, Parts 1-7 (SIL-2)

EN 60204-1 ISO 13849-1

- 3) North American Standards: per UL File E241445, US and C-UL approvals (CNN: NIPM/NIPM7).
  - ANSI/UL 508 (Industrial Control Equipment)
  - ANSI B11.19
  - ANSI/RIA R15.06
  - NFPA 79
  - Code of Federal Regulations CFR29
  - IEC 61496-1 (Type 3 ESPE)
  - IEC 61496-3 (Type 3 AOPDDR)
  - UL 1998 (Software in Programmable Components)
  - IEC 61508 (Functional Safety of Electrical/Electronic/Programmable Electronic Safety-Related Systems)
  - IEC 61508-3 (Functional Safety of Electrical/Electronic/Programmable Electronic Safety-Related Systems Part 3: Software Requirements)
  - CAN/CSA-C22.2 No. 14 (Industrial Control Equipment)
  - CAN/CSA-C22.2 No. 0.8 (Safety Functions Incorporating Electronic Technology)
- 4) JIS standards
- JIS B 9704-1, JIS B 9704-3 (Type3 ESPE)
- (3) This product received the following approvals from TÜV Rheinland of the EU.
  - -EC Type-Examination in accordance with the EU Machinery Directive, Type 3 ESPE (IEC 61496-1), Type 3 AOPDDR (IEC 61496-3)
- (4) By using OS32C sensor, you can build a safety control system that meets the followings.
  - -Requirements for SIL 2 (Safety Integrity Level 2) in IEC 61508, EN IEC 62061, (Functional Safety of Electrical/Electronic/Programmable Electronic Safety-related Systems)
  - -Requirements for PLd (Performance Level d) and for safety category 3 in EN ISO 13849-1

# **Terms and Conditions Agreement**

#### Warranties.

- (a) Exclusive Warranty. Omron's exclusive warranty is that the Products will be free from defects in materials and workmanship for a period of twelve months from the date of sale by Omron (or such other period expressed in writing by Omron). Omron disclaims all other warranties, express or implied.
- (b) Limitations. OMRON MAKES NO WARRANTY OR REPRESENTATION, EXPRESS OR IMPLIED, ABOUT NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE PRODUCTS. BUYER ACKNOWLEDGES THAT IT ALONE HAS DETERMINED THAT THE PRODUCTS WILL SUITABLY MEET THE REQUIREMENTS OF THEIR INTENDED USE.

Omron further disclaims all warranties and responsibility of any type for claims or expenses based on infringement by the Products or otherwise of any intellectual property right. (c) Buyer Remedy. Omron's sole obligation hereunder shall be, at Omron's election, to (i) replace (in the form originally shipped with Buyer responsible for labor charges for removal or replacement thereof) the non-complying Product, (ii) repair the non-complying Product, or (iii) repay or credit Buyer an amount equal to the purchase price of the non-complying Product; provided that in no event shall Omron be responsible for warranty, repair, indemnity or any other claims or expenses regarding the Products unless Omron's analysis confirms that the Products were properly handled, stored, installed and maintained and not subject to contamination, abuse, misuse or inappropriate modification. Return of any Products by Buyer must be approved in writing by Omron before shipment. Omron Companies shall not be liable for the suitability or unsuitability or the results from the use of Products in combination with any electrical or electronic components, circuits, system assemblies or any other materials or substances or environments. Any advice, recommendations or information given orally or in writing, are not to be construed as an amendment or addition to the above warranty.

See http://www.omron.com/global/ or contact your Omron representative for published information.

#### Limitation on Liability; Etc.

OMRON COMPANIES SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, LOSS OF PROFITS OR PRODUCTION OR COMMERCIAL LOSS IN ANY WAY CONNECTED WITH THE PRODUCTS, WHETHER SUCH CLAIM IS BASED IN CONTRACT, WARRANTY, NEGLIGENCE OR STRICT LIABILITY. Further, in no event shall liability of Omron Companies exceed the individual price of the Product on which liability is asserted.

#### Suitability of Use.

Omron Companies shall not be responsible for conformity with any standards, codes or regulations which apply to the combination of the Product in the Buyer's application or use of the Product. At Buyer's request, Omron will provide applicable third party certification documents identifying ratings and limitations of use which apply to the Product. This information by itself is not sufficient for a complete determination of the suitability of the Product in combination with the end product, machine, system, or other application or use. Buyer shall be solely responsible for determining appropriateness of the particular Product with respect to Buyer's application, product or system. Buyer shall take application responsibility in all cases.

NEVER USE THE PRODUCT FOR AN APPLICATION INVOLVING SERIOUS RISK TO LIFE OR PROPERTY OR IN LARGE QUANTITIES WITHOUT ENSURING THAT THE SYSTEM AS A WHOLE HAS BEEN DESIGNED TO ADDRESS THE RISKS, AND THAT THE OMRON PRODUCT(S) IS PROPERLY RATED AND INSTALLED FOR THE INTENDED USE WITHIN THE OVERALL EQUIPMENT OR SYSTEM.

#### **Programmable Products.**

Omron Companies shall not be responsible for the user's programming of a programmable Product, or any consequence thereof.

#### Performance Data.

Data presented in Omron Company websites, catalogs and other materials is provided as a guide for the user in determining suitability and does not constitute a warranty. It may represent the result of Omron's test conditions, and the

user must correlate it to actual application requirements. Actual performance is subject to the Omron's Warranty and Limitations of Liability.

#### Change in Specifications.

Product specifications and accessories may be changed at any time based on improvements and other reasons. It is our practice to change part numbers when published ratings or features are changed, or when significant construction changes are made. However, some specifications of the Product may be changed without any notice. When in doubt, special part numbers may be assigned to fix or establish key specifications for your application. Please consult with your Omron's representative at any time to confirm actual specifications of purchased Product.

#### **PATENTS**

Elements of the electronics and optics essential to meet the specifications and performance standards of Omron controls are covered by one or more of the following U.S. Patents Numbers: 6,665,621; 6,753,776; 6,493,653; 6,587,811; 7,965,384. Additional patents pending.

#### **Errors and Omissions.**

Information presented by Omron Companies has been checked and is believed to be accurate; however, no responsibility is assumed for clerical, typographical or proofreading errors or omissions.

# **Safety Precautions**

The Alert symbols and their meanings ensure safe use of the products

In order to use the OS32C safely, the precautions listed in this manual are indicated by alert symbols. The descriptions must be followed, failure to follow all precautions and alerts may result in an unsafe installation or operation.

The following indictions and symbols are used.



Indicates a potentially hazardous situation which, if not avoided, will result in minor or moderate injury, or may result in serious injury or death. Additionally there may be significant property damage.



Indicates a potentially hazardous situation which, if not avoided, will result in minor or moderate injury, or there may be property damage.

#### Meanings of Alert Symbols



Indicates prohibited actions.



Indicates mandatory actions.

#### Alert Statements in this Manual

### **⚠** WARNING

An OS32C is an electro-sensitive protective equipment designed to guard personnel working around hazardous machinery.



Whether a specific machine application and the OS32C system installation complies with safety regulations depends on the proper application, installation, maintenance and operation of the OS32C system. These items are the responsibility of the purchaser, installer and user.



User

### **MARNING**

The administrator is responsible for the selection and training of personnel to properly install, operate, and maintain the machine and its safeguarding systems.



An OS32C system should only be installed, verified and maintained by a qualified person. A qualified person is defined as "an individual who understands, is trained on, and demonstrates competence with the construction, operation or maintenance of the machinery and the hazards involved." (ANSI/PMMI B155.1-2006)



#### The machine requirements

### **↑** WARNING

The guarded machine must be able to stop anywhere in its cycle. Do not use an OS32C on a press with a full-revolution clutch.



The guarded machine must have a consistent stopping time and adequate control mechanisms.



All safety-related machine control elements must be designed so that an alarm in the control logic or failure of the control circuit does not lead to a failure to danger.



Do not use the auxiliary output or warning output for safety applications. A human body may not be detected even if a failure of OS32C occurs, resulting in serious injuries.



#### Installation

### **! WARNING**

The main unit must be securely mounted and its cable connectors must be tightly attached.



The OS32C must not be mounted behind glass or within a secondary enclosure. Failure to do so will cause a reduction in detection capability, which can cause serious injury or death.



A start switch to release interlock must be installed where an operator can observe the monitored/guarded zone as a whole and cannot operate the switch within the hazardous zone.



Per the International standard IEC 61496-3, area scanners used in applications where the angle of approach exceeds +/- 30 degrees with respect to the detection plane, must use reference boundary monitoring (RBM) of the detection zone.



Make sure to remove any retro-reflector from the field of view of the OS32C when in RBM mode.



A protective mechanism must be installed to prevent a hazardous condition in the event of a subsequent machine component failure. The OS32C does not protect against ejected flying material.



Severe smoke and particulate matter may degrade the efficiency of an OS32C, causing it to unexpectedly enter a Machine Stop state.



Use of mirrors or mirror-like objects in the protection plane must be avoided, as they can hide part of the area to be monitored/guarded.



Additional guarding may be required to prohibit access to dangerous areas not covered by the OS32C system.



Perform the test procedure in this document at installation, after maintenance, adjustment, repair or modification to the machine controls, tooling or the OS32C system. See page 162. Perform only the test and repair procedures outlined in this manual. Additional measurement error resulting from reflective backgrounds may need to be added to the measurement error of the OS32C. To use the protective function of the OS32C, a safety zone must be properly defined and configured. If the response time is changed, re-calculation of the safety distance is required. This may require re-configuration of the safety zones or re-installation of the OS32C. If the safety distance is not appropriate for the application, the machine may not stop before contact with the hazardous part, resulting in serious injuries or death. The activation of RBM Only mode will increase the response time. This additional time must be taken into consideration when calculating the safety guarding distance. When using more than one OS32C, mutual interference should be prevented. This may require different scanner positions or physical shields to be installed. To ensure a protection degree of IP65, DO NOT use this product without proper sealing of the cable connector, I/O block, and scan window. If the external zone switching device momentarily exceeds the configured number of active zone set select inputs during the zone switch, an additional Zone Delay may be incurred in the event that wiring of a zone set select input fails. The external zone switching device must properly sequence so the configured number of active inputs is not exceeded in order to guarantee that failed zone set select input wiring will be detected within the normal Zone Switching Time described below. If an insufficient Zone Delay is used for the actual worst case switching time of the installation, the scanner might start monitoring the wrong zone during the switching period. Also, if an insufficient Zone Delay is used for the actual worst case switching time of the installation, there might be a fault condition during the zone switching period. If tstart (switching start time) is configured without consideration of TmaxReaction (total maximum reaction time), object detection within the new safety zone after switching and turning OFF of the safety outputs may be delayed. Monitoring zone parameters are subject to a number of constraints that include projective consistency, maximum radius, and angle limits. As a result, an imported zone may not correspond exactly to the zone defined in the file. The user must visually verify the imported zone when the zone coordinate import process is complete. Refer to Checkout and Test Procedure Log on page 162. The installer is responsible for assessing the risk and to ensure that the zone of limited detection does not create a safety hazard. If a hazard exists additional countermeasure must be taken, this

may require additional guarding measures.

#### Wiring Connections

### **∴** WARNING

Do not connect the OS32C to a power supply with more than 24VDC + 25% / -30%. Do not supply AC power to the OS32C, this may result in electrical shock.



For the OS32C to meet IEC 61496-1 and UL 508, its DC power supply unit must satisfy all of the following conditions:



- Within rated line voltage (24 VDC +25% / -30%)
- Complying with EMC directives (industrial environments)
- · Double-insulation or reinforced insulation between primary and secondary circuits
- Automatic return for overcurrent protection
- · Output retention time of 20 ms or longer
- Satisfying output characteristics requirements of Class 2 circuit or limited voltage/current circuit defined in UL 508.
- Power supply complying with regulations and standards of EMC and safety of electrical equipment in a country or a region where OS32C is used. (Example: In EU, a power supply must comply with the EMC and Low Voltage Directives.)

To prevent electrical shock, use double-insulation or reinforced insulation from hazardous voltage (such as 230 VAC).



Cable extensions must be within the specified lengths, otherwise it may result in a failure of the safety functions.



To use this product for a category 3 safety system, both safety outputs must be connected to the safety system. Configuring a safety system with only one safety output may result in serious injuries due to output circuit fault and a failure of the machine to stop.



Protection of Cable at Installation:

Care should be taken when installing the OS32C cable. The cable must be properly routed and secured to ensure that damage does not occur.



Functional Earth:

The OS32C system requires a functional earth connection.



Do not connect Functional Earth to a positive ground system. If it is connected to positive ground, the guarded machine to be controlled may NOT stop, resulting in severe operator injury.

#### Signal Connector Isolation:

The connectors used during installation <u>must</u> provide sufficient signal separation in order to prevent a short circuit condition of the input power and system signals.



#### **♠** CAUTION

When wiring the OS32C to external devices, make sure to follow the color and coding schemes per EN 60204-1.



#### Others

### **⚠** WARNING

Do not modify the main unit of the OS32C. Do not replace or fix any component of the OS32C other than the ones specified in this manual. Doing so may result in a failure of this device to function correctly.



If there is any damage to the window, replace it as soon as possible. Otherwise it may result in a failure of the OS32C. Take preventive measures when performing replacement work so that dust does not enter the OS32C.



Always detach all cables from the OS32C before replacing the scan window. Otherwise the motor may start rotating, resulting in injuries.



The window replacement procedure must only be performed by qualified personnel in a clean environment at ambient temperature (5 to 35°C) to prevent the internal optical surface from contamination. Make sure the inside and the outside of the replacement window is clean and free from scratch, dust, and finger print.



The calibration procedure must only be performed by qualified personnel. Before performing window calibration of the new scan window, make sure the window is clean and free from scratch, dust, and finger print. The window calibration procedure must be performed at ambient temperature 5 to 35°C. Failure to inspect the window or set the proper environmental condition during window calibration procedure may cause a reduction in the detection capability of the scanner.



The tests outlined in the Test Procedure (See "Checkout and Test Procedure Log" in p.162) must be performed at time of installation, according to the employer's regular inspection program and after any maintenance, tooling change, set up, adjustment, or modification to the OS32C system or the guarded machine. Where a guarded machine is used by multiple operators or shifts, it is suggested that the test procedure be performed at each shift or operation change and also if there is a change in the OS32C operating mode or defined zone sets. Testing ensures that the safety laser scanner and the machine control system are working properly to stop the machine. Failure to test properly could result in serious injury to personnel.

If the OS32C is operated under automatic start, make sure that the machine stops and does not restart as long as an object is detected in a safety zone. Check the operation by placing a test piece into the safety zone. It is recommended to perform the test at least after a shift change or 24 hours of operation.



If the safety system or the machine fails any of these tests, do not run the machine. Immediately tag or lock out the machine to prevent its use and notify the appropriate supervisor.



System and zone status parameters monitored over EtherNet/IP are to be used for diagnostic purposes only, and must not be used in safety-critical functions.



Measurement data monitored over EtherNet/IP are to be used for diagnostic purposes only, and must not be used in safety-critical functions.



#### **Security Measures**

#### **Anti-virus protection**

Install the latest commercial-quality antivirus software on the computer connected to the control system and maintain to keep the software up-to-date.



#### Security measures to prevent unauthorized access

Take the following measures to prevent unauthorized access to our products.

- · Install physical controls so that only authorized personnel can access control systems and equipment.
- · Reduce connections to control systems and equipment via networks to prevent access from untrusted devices.
- · Install firewalls to shut down unused communications ports and limit communications hosts and isolate control systems and equipment from the IT network.



- · Adopt multifactor authentication to devices with remote access to control systems and equipment.
- Set strong passwords and change them frequently.
- Scan virus to ensure safety of USB drives or other external storages before connecting them to control systems and equipment.

#### Data input and output protection

Validate backups and ranges to cope with unintentional modification of input/output data to control systems and equipment.

- Checking the scope of data
- · Checking validity of backups and preparing data for restore in case of falsification and abnormalities
- · Safety design, such as emergency shutdown and fail-soft operation in case of data tampering and abnormalities



#### Data recovery

Backup data and keep the data up-to-date periodically to prepare for data loss.



When using an intranet environment through a global address, connecting to an unauthorized terminal such as a SCADA, HMI or to an unauthorized server may result in network security issues such as spoofing and tampering.



You must take sufficient measures such as restricting access to the terminal, using a terminal equipped with a secure function, and locking the installation area by yourself.

When constructing an intranet, communication failure may occur due to cable disconnection or the influence of unauthorized network equipment.



Take adequate measures, such as restricting physical access to network devices, by means such as locking the installation area.



### **A** CAUTION

When transferring data from the PC to the OS32C and more than one OS32C is connected to the network, it is necessary to visually check the diagnostic code on the status/diagnostic display. It is recommended that the OS32C be installed in a position where the status/diagnostic display will be visible.



Before sending the changes to the sensor, verify that the safety parameters are configured as intended for the application.



Take precautions to prevent dirt, dust or debris from entering the sensor and I/O block connectors. It is recommended that this be done on a clean workstation as contaminants may degrade the performance of the OS32C.



Adhesion of dust to the scan window may cause a false operation. The OS32C will require periodic cleaning of the scan window and dust detection surface.



Operation of the OS32C may be affected by light in the environment, such as incandescent light, strobe light and light from a photosensor using infrared light.



Operation of the OS32C may be affected by substances in the environment, such as fog, smoke, steam and other small particles.



Ensure the measurement report configuration of the OS32C-xxx-DM matches the expected measurement data format.



# **Precautions for Safe Use**

Make sure to follow all the safety precautions that are necessary to ensure safe use of the product.

- Thoroughly read this installation manual and understand the installation, operation checks, and maintenance procedures before using the product.
- · Loads must satisfy both of the following conditions:
  - Not short-circuited
  - Not used with a current that is higher than the OSSD rating (250 mA sourcing)
- The main unit must be properly mounted with the proper mounting hardware.
- Do not drop the product, serious damage will occur.
- Comply with all the laws, regulations, and standards of the country/region where the product is used.
- Dispose of the product in accordance with the relevant rules and regulations of the country/region where the product is used.

### **Precautions for Correct Use**

Observe the precautions described below to prevent operation failure, malfunctions, or undesirable effects on product performance.

#### ■ Installation environment

Do not install the OS32C in the following types of environments:

- Areas where OS32C may be exposed to intense interference light, such as direct sunlight
- · Areas with high humidity where condensation is likely to occur
- Areas subject to condensation resulting from severe changes in temperature
- · Areas where corrosive gases are present
- · Areas exposed to vibration or shock levels higher than in the specification provisions
- · Areas where the product may come into contact with water
- · Areas where the product may get wet with oil
- · Areas where smoke and/or water vapor exists on the laser scanning plane
- Keep the OS32C far enough from devices that generate high frequency noise or eliminate the noise.
- Be sure to route the OS32C cable separate from high-potential power lines or route through an
  exclusive conduit.

This is a class A product. In residential areas it may cause radio interference, in which case the Responsible Person may be required to take adequate measures to reduce interference.

#### Wiring and installation

- Make sure to perform wiring while the power supply is OFF. Otherwise, the OS32C may fail to operate due to the diagnostics function.
- Properly perform the wiring after confirming the signal names of all the terminals.
- Do not operate the control system until 14 seconds or more after turning ON the power of the OS32C.
- Be sure to route the OS32C cable separate from high-potential power lines or through an exclusive conduit.
- When using a commercially available switching regulator power supply, make sure to ground the FG terminal (frame ground terminal).
- Sharing the power supply with other devices may cause the OS32C to be affected by noise or voltage drop. It is recommended that the safety-related devices use a dedicated power supply, not shared with other devices.

### ■ Cleaning

Do not use thinner, benzene, or acetone for cleaning. They will adversely affect the product's resin parts and paint on the case.

### ■ Object detection

The OS32C has a configurable minimum object resolution of 30mm, 40mm, 50mm, or 70mm. It cannot detect transparent or translucent objects, or objects with reflective surfaces, of less than 1.8% reflectivity.

### LASER SAFETY

- Precautions on Handling
  - OS32C radiates light laser. Do not directly look into beam.
  - In the case of releasing beam, avoid the optical path to be at eye level.
- Laser safety regulations vary according to the country where LED devices are used.
- 1) Use in Japan

JIS C 6802 regulates safety protection measures to the user according to classes of laser products. OS32C is classified as Class 1.

2) Use in the United States

This product is subjected to the U.S. FDA (Food and Drug Administration) laser regulations.

This product is classified into Class I by the regulations of 21 CFR 1040.10, 1040.11 of the FDA standard.

Labels related to lasers

Products are labeled in accordance with FDA technical standards.

#### Certification label



Model:
P/N:
S/N:
MAC Address:
Input: 24VDC +25%/-30%, 5W max, 4W typical (No Load)
Response Time: <80ms to 784ms (Adj.)
AOPDDR Type 3 (IEC 61496-3)
SIL-2 (IEC 61508)
Environmental: IP 65 Country Of Origin: US,

3) Usage in countries other than U.S. and Japan

This product is classified into Class 1 by the IEC 60825-1:2014, EN 60825-1:2014+A11:2021 standard.

# **How to Read This Manual (Explanation of Symbols)**



Indicates the description of an essential function, such as operation or advice on how to properly use this product .



Indicates the page number for related content.

# **Configuration Tool Features and Compatibility**

Please refer to the table below for supported features and compatibility with OS32C versions. Refer to the product labels to determine the OS32C version.

For information on the OS32C-DM model, please refer to the OS32C-DM Addendum available on the Omron's website at

http://www.omron.com/global/

#### NOTE:

• Only the version of the sensor block and the configuration tool were updated to support the new features. No changes were made to the I/O block.

• The part numbers have changed:

OS32C-SN: 40591-0010 (old), 40591-0020 (current)

OS32C-SN-DM: 40591-0040 (current)
OS32C-SN-4M: 40603-0020 (current)
OS32C-SN-DM-4M: 40603-0040 (current)

	OS32C Versions		OS32C-DM	OS32C-4M	OS32C-DM-4M
✓ : Supported	40591-0010	40591-0020	40591-0040	40603-0020	40603-0040
Configurable minimum object resolution		~	~	~	<b>~</b>
Standby mode with laser shutoff		~	~	~	<b>✓</b>
Copy & paste zones and zone sets		~	~	~	<b>~</b>
Record system monitoring		~	~	~	<b>~</b>
Playback system monitoring		~	~	~	~
Support for inverting 7-segment display		~	~	~	<b>~</b>
Display configuration filename in config tool header		~	~	~	~
Additional zone shapes (180° semi-circle, 180° rectangle, 180° polygon)		~	~	~	~
Config tool support for switching between default OS32C configuration and the user's current working configuration		•	•	~	~
Troubleshooting tips displayed in fault log		~	~	~	<b>✓</b>
Configuration checksum, safety checksum	<b>✓</b> *1	<b>✓</b> *1	<b>✓</b> *1	<b>✓</b> *1	<b>✓</b> *1
Windows 7 support		~	~	~	<b>✓</b>
Non-safety checksum	<b>✓</b> *2	<b>✓</b> *2	<b>✓</b> *2	<b>✓</b> *2	<b>✓</b> *2
Single Import & Export Zone Coordinate Data	<b>✓</b> *2	<b>✓</b> *2	<b>✓</b> *2	<b>✓</b> *2	<b>✓</b> *2
Maintenance access level		<b>✓</b> *3	<b>✓</b> *2	<b>✓</b> *2	<b>✓</b> *2
Rotation of monitor screen view	<b>✓</b> *4	<b>✓</b> *4	<b>✓</b> *4	<b>✓</b> *4	<b>✓</b> *4
French, German, Italian & Spanish Languages	<b>✓</b> *4	<b>✓</b> *4	<b>✓</b> *4	<b>✓</b> *4	<b>✓</b> *4
Multiple Import & Export Zone Coordinate Data	<b>✓</b> *4	<b>✓</b> *4	<b>✓</b> *4	<b>✓</b> *4	<b>✓</b> *4

	OS32C Versions		OS32C-DM	OS32C-4M	OS32C-DM-4M
✓ : Supported	40591-0010	40591-0020	40591-0040	40603-0020	40603-0040
EtherNet/IP and Measurement Data			<b>~</b>		>
Pollution Tolerance Mode		<b>✓</b> *6	<b>✓</b> *6	<b>✓</b> *5	<b>✓</b> *5
Variable response time settings		<b>✓</b> *6	<b>✓</b> *6	<b>✓</b> *5	<b>✓</b> *5
4 meter safety/ 15 meter warning zone				<b>✓</b> *5	<b>✓</b> *5
Status information during monitor mode		<b>✓</b> *6	<b>✓</b> *6	<b>✓</b> *5	<b>✓</b> *5
Confirmation of Safety parameters		<b>✓</b> *6	<b>✓</b> *6	<b>✓</b> *5	<b>✓</b> *5
Warning Zone changed via Ethernet/IP capability			<b>✓</b> *6		<b>✓</b> *5
Windows 10 support		<b>✓</b> *7	<b>✓</b> *7	<b>✓</b> *7	<b>✓</b> *7

<sup>\*1.</sup> Requires Configuration Tool Version 1.4.0 and up

<sup>\*7.</sup> Requires Configuration Tool Version 2.2.8 and up

	Configuration Tool Version					
✓ : Supported	before 1.4.0	1.4.0 and up	1.6.0 and up	1.8.0 and up	2.0.0 and up	2.2.8 and up
Configurable minimum object resolution		~	~	~	~	~
Standby mode with laser shutoff		~	~	~	~	~
Copy & paste zones and zone sets		~	~	~	~	~
Record system monitoring		~	~	~	~	~
Playback system monitoring		~	~	~	~	~
Support for inverting 7-segment display		~	~	~	~	<b>✓</b>
Display configuration filename in config tool header		•	•	•	•	~
Additional zone shapes (180° semi-circle, 180° rectangle, 180° polygon)		•	~	•	~	~
Config tool support for switching between default OS32C configuration and the user's current working configuration		•	•	•	•	~
Troubleshooting tips displayed in fault log		~	~	~	~	~
Configuration checksum, safety checksum		•	~	•	•	~
Windows 7 support		~	~	~	~	~
Non-safety checksum			~	•	~	~
Single Import & Export Zone Coordinate Data			~	•	•	~
Maintenance access level			~	~	~	<b>✓</b>

<sup>\*2.</sup> Requires Configuration Tool Version 1.6.0 and up

<sup>\*3.</sup> If serial number of the sensor block is higher than AS08300 and Configuration Tool is version 1.6.0 and up

<sup>\*4.</sup> Requires Configuration Tool is Version 1.8.0 and up

<sup>\*5</sup> Requires Configuration Tool is Version 2.0.0 and up

<sup>\*6</sup> If serial number of the sensor block is higher than AS17500 and Configuration Tool is Version 2.0.0 and up

	Configuration Tool Version					
✓ : Supported	before 1.4.0	1.4.0 and up	1.6.0 and up	1.8.0 and up	2.0.0 and up	2.2.8 and up
Rotation of monitor screen view				>	~	~
French, German, Italian & Spanish Languages				<b>&gt;</b>	•	•
Multiple Import & Export Zones Coordinate Data				<b>&gt;</b>	•	•
Pollution Tolerance Modes					~	~
Variable response time settings					~	~
4 meter safety/ 15 meter warning zone					~	~
Status information during monitor mode					~	~
Confirmation of Safety parameters					~	~
Warning Zone changed via Ethernet/IP capability					•	~
Windows 10 support						~

Note: The configuration data file extension is \*.cf2 until Configuration Tool Version 1.8.0 and \*.cf3 from Version 2.0.0.

#### ✓ : Supported

Model Sensor Head P/		Configuration Tool Version					
Wiodei	Selisoi Fleau F/N	before 1.4.0	1.4.0 and up	1.6.0 and up	1.8.0 and up	2.0.0 and up	
OS32C-SN	40591-0010	~	~	~	~	~	
OS32C-SN	40591-0020		~	~	~	~	
OS32C-SN-DM	40591-0040			~	~	~	
OS32C-SN-4M	40603-0020					~	
OS32C-SN-DM-4M	40603-0040					~	

# **Contents**

	Legislation and Standards	
	Terms and Conditions Agreement	i
	Safety Precautions	iv
	Precautions for Safe Use	Х
	Precautions for Correct Use	х
	LASER SAFETY	xii
Cha	apter1 Description of Use and Features	1
	Theory of Operation	2
	Features	3
	System Components	4
	Application Examples	5
	Applying the OS32C to fixed stationary applications	5
	Applying the OS32C on Automated Guided Vehicles (AGV)	7
	Rating/Performance	10
Cha	apter2 Operating States & Output Modes	13
	Operating States	14
	Operating Mode	17
	Automatic Start	17
	Start Interlock	17
	Start/Restart Interlock	17
	Power Reserve Mode	18
	Parameter Configuration	19
	Safety Critical Parameters	19
	Non-Safety Critical Parameters	20
	Safety Outputs	21
	Auxiliary & Warning Outputs	21
	Reference Boundary Monitoring (RBM)	23
	Pollution Tolerance Mode (PTM)	24
	Zone Set Selection	26
	Zone Set Input Selection	26
	Zone Set Switching	28
Cha	apter3 Basic Operation of Configuration Tool	33
	Getting Started	35
	Installing Configuration Tool	35
	How to Start	36

Description of Screen	37
Menu	37
Tool Bars	39
Information Bar	40
Offline Mode	40
Connection to the OS32C	41
Connecting the PC and the OS32C	41
Forced DHCP mode	42
Changing the IP address of the PC (Windows XP)	42
Changing the IP address of the PC (Windows 7)	44
Changing the IP address of the PC (Windows 8.1 and Windows 10)	44
Logging on to the OS32C	45
Detecting the OS32C on the network	45
Logging On	46
Logging OFF	46
Changing Password	46
Forgot the Password?	47
Changing Ethernet Configuration of OS32C	48
Receiving OS32C Configuration Information	49
Configuring New OS32C Property and Monitoring Zone	49
Default Configuration Settings	49
Creating a New Configuration	50
Saving OS32C Configuration to PC	55
Import & Export Zone Coordinate Data	57
File Format	57
Importing Zone Coordinate Data	60
Exporting Zone Coordinate Data	62
Zone Set Selection and Configuration	64
Add a Zone	64
Copy and Paste Zones	65
Delete a Zone	67
Zone Set Input Selection	68
Editing Properties	69
Editing Monitor Zones	73
Sculpting & Reference Boundary Monitoring	76
Monitor Mode	81
Record System Monitoring	82
Playback System Monitoring	84
Read Fault Log	85
Window Calibration	86
Changing Options of Configuration Tool	88
Caution on Safety Zone Configuration	89

	Reset to Default Configuration	90
Cha	apter4 Installation	93
	Mounting Considerations	94
	Configuring Multiple OS32C Scanners	94
	Distance from Wall	96
	Stationary Installation and Configuration	97
	Installation for Stationary Area Scanning	97
	Configuration	98
	Configuration Example: Installation on a Machine (1)	99
	Configuration Example: Installation on a Machine (2)	101
	Configuration Example: Entry Access Protection	101
	Configuration Example: Hand Detection Protection	103
	Mobile Installation and Configuration	105
	Applying OS32C on Automated Guided Vehicles (AGV)	105
	Configuration for Automated Guided Vehicles (AGV)	107
	Configuration Example: Use of an AGV	108
	AGV Standards	109
	External Dimensional Drawings	110
	Ethernet Cable	119
	XS5 OMRON Smartclick™ Connection	120
Cha	apter5 Wiring	121
	Power Supply Unit	122
	Additional Wiring Information	123
	Input/Output Signal	124
	Example of Safety Circuit	125
Cha	apter6 Checkout	129
	Checkout and Test Procedures	130
	Checkout and Test Procedures	130
	Testing Safety Zone	131
	Detection Capability	133
Cha	apter7 Appendix	135
	Troubleshooting	136
	Troubleshooting	136
	OS32C Status Check	139
	Additional Error due to Reflective Background	142

Conditions of Background Influence	142
Using Other Safety Device in Combination	144
Sensor Replacement	145
Checking the Firmware Version	145
Sensor and I/O Block Replacement	147
How to Recover from a Fault Code 60	148
Scan Window Replacement Procedure	151
Window Replacement Procedure	151
OS32C Maintenance	153
Warning Zone Object Resolution	154
Additional Zone Set Switching Strategies	155
Glossary	159
Accessories	161
Checkout and Test Procedure Log	162
Declaration of Conformity	163
Revision History	167

# **Chapter1 Description of Use and Features**

Theory of Operation	2
Features	3
System Components	4
Application Examples	5
Applying the OS32C to fixed stationary applications	5
Applying the OS32C on Automated Guided Vehicles (AGV)	7
Rating/Performance	10

# **Theory of Operation**

The OS32C safety laser scanner is an optical safety sensor that uses diffuse reflection of a pulsed laser light to determine the location of objects entering a predefined monitoring zone. Internally, a spinning mirror assembly scans a monitoring zone by sending a pulse of light which reflects off the first object in its path. The distance from the sensor to the object is determined by measuring the time that the light requires to return from the sensed object.

This method of sensing allows for standard, simple or irregular shapes to be used as the predetermined sensed monitoring zones. It also allows for the monitoring zone to be changed if the hazardous area changes. Using diffused reflection of light back to the OS32C precludes the need for a traditional transmitter/receiver pair.

Within the sensing range of the OS32C, three fields can be monitored simultaneously: One safety zone and two warning zones.


- One Safety Zone is used to detect personnel or other objects entering an area that has been determined to be a hazard. Upon sensing that the object is within the Safety Zone, the OS32C will send a stop signal to the control circuitry of the machine being guarded.
- Two Warning Zones can be defined with a longer distance than a safety zone, allowing a configuration to detect objects that are closely approaching the hazardous area of the Safety Zone before the actual Safety Zone is encroached.

Applications for the OS32C include mobile applications on automatic guided vehicles (AGV) or transfer carts as well as stationary use, such as within a robotic work cell, in front of a press or around other hazardous machinery.

# **Features**

- Can detect intrusions within the safety zone with a radius of up to 4 m (min. obj. resolution of 70mm) and two warning zones with a radius of 15 m, covering a maximum scan angle of 270°.
- When an object is detected within the safety zone, individual sector indicators immediately turn on (8 red indicators), indicating the object's position of intrusion.
- Seventy sets of safety zone and warning zone combinations are available, supporting complicated changes of working environments.
- The configuration tool allows easy to use monitoring zone configuration.
- A safety relay can be directly monitored by the external device monitoring function.
- The physical mounting position of the safety laser scanner can be monitored by the reference boundary monitoring function.
- Compact design allows for low-clearance installations.

# **System Components**






Fig. 1-1 System Components

Number	Component	Function
(1)	RUN indicator (green)	Will turn ON when safety zone is clear and OSSDs are ON.
(2)	Interlock Indicator (yellow)	Will turn ON when in interlock state, blink under lockout (@ 1Hz), and blink under configuration (@ 4Hz).
(3)	Status/Diagnostic Display	The scanner's status ,configuration/operation, or failure is displayed.
(4)	Warning Output Indicator (orange)	Will turn ON when the warning output is ON and will flash when dust or contamination is detected on the scan window (@ 1 Hz).
(5)	STOP indicator (red)	Will turn ON when safety zone is blocked, OSSD are OFF or under interlock state.
(6)	Dust Ring	Dust detection cover with reflective surface, for dust accumulation detection
(7)	Individual Sector Indicators (ISI)	Will turn ON when an intrusion is detected in the safety zone (default), 8 sectors total. Each sector = 33.75°. Will flash when dust or contamination is detected on the scan window.
(8)	Scan Window	The window where the laser light is emitted and received.
(9)	Communication Connector	Provides for Ethernet interface.*1
(10)	Power Connector	For power connections, 18-pin connector (pigtail).*1
(11)	I/O Block	Connector module
(12)	Center of rotation	Indicates the location of the axis around which the laser irradiates from.
(13)	Sensor	Sensor head; field replaceable.

<sup>\*1:</sup> The communication and power connections can also be mounted on the left side of the I/O block.

Table 1-1 System Components and Indicators



For details on indicators, refer to "Indication Patterns" on page 14.



For details on Status/Diagnostic Display, refer to "OS32C Status Check" on page 139.

# **Application Examples**

The OS32C may be used for personnel safeguarding. Typical applications include work cell area guarding and collision prevention of AGV (Automated Guided Vehicles). The OS32C is a versatile Safety Laser Scanner capable of guarding many types of applications. The application examples in this chapter are for informational and instructional purposes only and not intended to represent complete guarding solutions. Care must be taken to ensure that all aspects of a machine or work cell are reviewed and appropriate guarding techniques are employed.

## Applying the OS32C to fixed stationary applications




Fig. 1-2 Dual Zone Area Guarding

In this application the OS32C is the primary guarding device, using a horizontal protective field for area protection. The OS32C will guard one side of the area based on the robot's position. This application takes advantage of the multi-zone functions of the OS32C. This function allows an operator to enter and set-up on one side "the safe side" shown as Zone A, while the robot performs its tasks on the "hazardous side" shown as Zone B. The warning zones are represented by the lighter colors. The robot's position is determined via external devices that provide discrete inputs to the OS32C.




Fig. 1-3 270 deg. Area Guarding

In this application the OS32C is the primary guarding device, using a 270 degree horizontal protective field for area protection guarding. The production process in this example does not allow for any frontal hard guarding obstructions in front of the work cell. The warning fields (shown as Zone A & Zone B) of the OS32C provides manufacturing personnel with a preliminary warning to prevent them from accidentally stopping the manufacturing process. In some cases an unintentional interruption can result in very high waste costs.





Fig. 1-4 Internal Robot Cell Guarding

In this application the OS32C is the secondary guarding device in conjunction with a safety light curtain. The OS32C is responsible for detecting that the work area is clear before start-up of the robot occurs.



Fig. 1-5 Vertical Guarding Installation

In this application the OS32C is the primary guarding device, using a vertical protective field for point of operation guarding. In some cases the machine's architecture or production flow may not permit the installation of a safety light curtain. The OS32C meets all the requirements of IEC 61496-3 for vertical guarding installations and employs a reference boundary monitoring function.






Fig. 1-6 Dual Zone Vertical Guarding

In this application the OS32C is the primary guarding device, using a vertical protective field for entry presence detection. The OS32C can guard the hazardous area based on the robot's position. When the robot is in the left side, the OS32C guards the left side and changes to the right side along with the robot. This application takes advantage of the multi-zone functions of the OS32C. This function allows an operator to enter and set-up on one side, "the safe side", while the robot performs its tasks on the hazardous side. The robot's position is determined via external devices that provide discrete inputs to the OS32C. The OS32C meets all the requirements of IEC 61496-3 for vertical guarding installations and employs a reference boundary monitoring function.

## Applying the OS32C on Automated Guided Vehicles (AGV)

Unmanned automated vehicles require guarding devices to prevent accidental collisions. The OS32C will scan the path of the AGV and will send a stop signal to the vehicle if it detects an object or person. The OS32C is more adjustable and reliable than conventional pressure-sensitive bumpers. The OS32C's flexibility allows three types of monitoring.

#### ■ Warning Zone 1 Detection

When the Warning Output is assigned to follow Warning Zone 1, it will send a signal to the AGV when Warning Zone 1 is infringed. This will trigger the vehicle to sound an alarm, allowing a person to move away from the vehicle's path.

#### ■ Warning Zone 2 Detection

When the Auxiliary Output is assigned to follow warning zone 2, it will send a signal to the AGV when Warning Zone 2 is infringed. This will trigger the vehicle to slow down, allowing a person to move away from the vehicle's path.

#### ■ Safety Zone Detection

The two safety outputs will send an E-stop to the AGV when the Safety Zone is infringed. This will signal the vehicle to come to a complete stop.




Fig. 1-7 AGV Navigation



Fig. 1-8 Automated Guided Vehicles, Bi-directional (AGV)

In this application two OS32Cs are the primary guarding devices. The two warning fields of the OS32C are used to give personnel extra warning, allowing them to move out of the AGV path. This is essential in achieving maximum travel efficiency.




Fig. 1-9 Automated Guided Vehicles, Multiple Zones (AGV)

In this application the OS32C is the primary guarding device. The drawing illustrates a common AGV guarding configuration where 4 zone sets are used to safely navigate the vehicle around a factory floor. The four zone sets consist of two for forward motion (high speed, low speed), one for left turn and one for right turn. The active safety zone set is selected by the AGV's controls, which are configured for maximum efficiency.




Fig. 1-10 Automated Guided Vehicles (AGV), Two Scanners, Three Sided

In this application two OS32Cs are used as the primary guarding devices, using 270 degree protective fields. They are positioned at the front corners, this scheme allows for two scanners to guard three sides of the AGV. This configuration is appropriate for AGVs that can maneuver in three directions, forward and side-to-side.




Fig. 1-11 Automated Guided Vehicles (AGV), Two Scanners, Four Sided

In this application two OS32Cs are used as the primary guarding devices, using 270 degree protective fields. They are positioned at opposite corners. This scheme allows for two scanners to guard four sides of the AGV. This configuration is appropriate for AGVs that can maneuver in four directions, forward, reverse and side-to-side.

# Rating/Performance

Sensor Type		Type 3 Safety Laser Scanner
Performance Level (PL)/		PL d, Safety Category 3 (ISO 13849-1)
Safety Category		
Functional Safety of		SIL 2, PFH <sub>D</sub> = 8.3 x 10 <sup>-8</sup> (IEC 61508)
Electrical/Elec		
Programmabl		
Safety-related	Systems	
Detection Cap	oability	Configurable via the configuration tool; Non-transparent with a diameter of 30, 40, 50, or 70 mm (1.8% reflectivity or greater)
Monitoring Zo	ne	Monitoring Zone Set Count (Safety Zone + 2 Warning Zones) : 70 sets max.
		Safety Zone: 1.75 m (min. obj. resolution of 30 mm)
Operating Ra	nge	2.5 m (min. obj. resolution of 40 mm)
OS32C-xxx		3.0 m (min. obj. resolution of 50 mm or 70 mm)
		Warning Zone: 10.0 m
		Safety Zone: 1.75 m (min. object resolution of 30mm) 2.5 m (min. object resolution of 40 mm)
Operating Ra	-	3.0 m (min. object resolution of 40 min)
OS32C-xxx-4	М	4.0 m (min. object resolution of 70 mm)
		Warning Zone: 15.0 m
Maximum Ma	asurement Error	100 mm (at range of 3 m or less) *1
Maximum Mea	asurement Enor	110 mm (at range greater than 3 m and up to 4 m) *1
Detection Ang	gle	270°
Angular Reso	lution	0.4 degree
Laser Beam [	Diameter	6 mm at optics cover, 14 mm (typical) at 3 m.
Laser Scan P	lane Height	67 mm from the bottom of the scanner (see "External Dimensional Drawings" on page 110 for more detail)
		Response time from ON> OFF: From 80 ms (2 scans) to 680 ms (up to 17 scans) *8
Response Tin	ne	Response time from OFF> ON: Configurable. See Table 2-5 on page 16.
Zone Switchir	ng Time	From 20 to 320 ms
Line voltage		24 VDC +25%/-30% (ripple p-p 2.5 V max.) *2
Power Consu	motion	Normal operation: 5 W max. *3
rowel Collsu	Приоп	Standby mode: 3.75 W (without output load)
Emission Sou		Infrared Laser Diode (905 nm)
(Wavelength)		
		Class 1 Laser Product: IEC 60825-1:2014, EN 60825-1:2014+A11:2021
Laser Class		Class 1 Laser Product: JIS C 6802: 2014
Lasei Class		Class I: 21 CFR 1040.10, 1040.11
		1类激光产品: GB/T 7247.1-2024
Safety Output	t (OSSD)	PNP transistor x 2, load current of 250 mA max., residual voltage of 2 V max., load capacitance of 2.2 µF max., leak current of 1 mA max *3, *4, *5.
Auxiliary Output (Non-Safety)		NPN/PNP transistor x 1, load current of 100 mA max., residual voltage of 2 V max., leak current of 1 mA max *4, *5, *7
Warning Output (Non-Safety)		NPN/PNP transistor x 1, load current of 100 mA max.,residual voltage of 2 V max., leak current of 1 mA max *4, *5, *7
Operation Mode		Auto Start, Start Interlock, Start/Restart Interlock
	rnal Device	ON: 0 V short (input current of 50 mA), OFF: Open
	toring	
Input Start		ON: 0 V short (input current of 20 mA), OFF: Open
Zone	Select	ON: 24 V short (input current of 5 mA), OFF: Open
Stand	dby	ON: 24 V short (input current of 5 mA max.), OFF: Open

Connection Type	Power Cable: 18-pin mini-connector (pigtail)
	Communication Cable: M12, 4-pin connector
Connection with PC	Communication: Ethernet *6
	OS Supported: Windows XP, Windows 7, Windows 8.1, Windows 10
Indicators	RUN indicator : Green, STOP indicator : Red, Interlock Indicator : Yellow, Warning Output Indicator : Orange
	Status/Diagnostic Display: 2 x 7-segment LEDs, Individual Sector Indicators: Red LED x 8
Protective Circuit	Protection against output load short and reverse power connection
Ambient Temperature	Operation: -10 to 50 °C, Storage: -25 to 70 °C
Ambient Humidity	Operation & Storage: 95%RH max., non-condensing
Ambient Operation Illumination	Incandescent lamp: Illumination on receiving surface 1500 lx max. (an angle of laser scanning plane and disturbance light must be +/-5 degrees or more)
Insulation resistance	20 MΩ or higher (500 VDC)
Dielectric withstand voltage	350 VAC, 1 minute
Enclosure Rating	IP65 (IEC 60529)
Enclosure	Sensor Head: Die-cast aluminum
	Optics Cover: Polycarbonate
	I/O Block: Die-cast aluminum
Dimensions (WxHxD)	133.0 x 104.5 x 142.7 mm (except cable)
Impact Resistance	98 m/s <sup>2</sup> 1000 times for each of X, Y, and Z directions (IEC 60068-2-29)
Vibration	10 to 55 Hz double-amplitude of 0.7 mm, 20 sweepings for X, Y, and Z directions (IEC 60068-2-6)
Weight (Main Unit only)	1.3 kg
Power Cable	Up to 30 m
Communication Cable	Up to 100 m for 100 BASE-TX cable *9
Approvals	Certificated by: TÜV Rheinland EN IEC 61496-1 (Type 3 ESPE), EN IEC 61496-3 (Type 3 AOPDDR), EN 61508 (SIL2)
	Certificated by: UL IEC 61496-1 (Type 3 ESPE), IEC 61496-3 (Type 3 AOPDDR), IEC 61508 (SIL2), UL 508, UL 1998, CAN/CSA-C22.2 No. 14, CAN/CSA-C22.2 No. 0.8
	4

- \*1. An additional measurement error may need to be added due to reflective backgrounds (See p.142 for details).
- \*2. For power source specification, see Power Supply Unit in p.122
- \*3. Rated current of OS32C is 1.025 A max. (OS32C 210 mA + OSSD A load + OSSD B load + Auxiliary output load + Warning output load + Functional Inputs).

Where functional inputs are:

EDM input ... 50 mA Start input ... 20 mA Standby input ... 5 mA

Zone X input ... 5 mA x 8 (eight zone set select inputs)

- \*4. Output voltage is Input voltage 2.0 VDC.
- \*5. Total consumption current of 2 OSSDs, auxiliary output, and warning output must not exceed 700 mA.
- \*6. An Ethernet cable with an M12, 4-pin connector is required.
- \*7. Output polarity (NPN/PNP) is configurable via the configuration tool.
- \*8. Pollution tolerance in RBM mode will increase the scan period, resulting in an increase of the response time. See Table 2-5 for detail.
- \*9. Omron only supplies up to a 15 m Ethernet cable. For longer lengths a connection to a network switch/router is needed.

Table1-2 OS32C Specifications

## **Chapter2 Operating States & Output Modes**

Operating States	14
Operating Mode	17
Automatic Start	17
Start Interlock	17
Start/Restart Interlock	17
Power Reserve Mode	18
Parameter Configuration	19
Safety Critical Parameters	19
Non-Safety Critical Parameters	20
Safety Outputs	21
Auxiliary & Warning Outputs	21
Reference Boundary Monitoring (RBM)	23
Pollution Tolerance Mode (PTM)	24
Zone Set Selection	26
Zone Set Input Selection	26
Zone Set Switching	28

## **Operating States**

The following operating states exist for the OS32C system.

#### 1. OSSD ON State

The two safety outputs are in the ON state, and the machine run (green) indicator is lit. The protected machine is allowed to operate. The state/diagnostic display indicates a state of monitoring zone set selection and a response time.

#### 2. OSSD OFF State

An object exists in a safety zone and it is being detected. The two safety outputs are in the OFF state, and the machine stop (red) indicator and the intrusion indicators in the affected region(s) are lit. The protected machine is not allowed to operate. The status/diagnostic display shows "- -".

#### 3. Interlock State

This state waits for a start input (See p.17 for details.). The two safety outputs are in the OFF state, the red STOP indicator and yellow interlock indicator are lit. The protected machine is not allowed to operate. The status/diagnostic display shows "01".

#### 4. Lockout State

A failure is being detected and the guarded machine is being stopped. The two safety outputs are in the OFF state, the machine stop (red) indicator is lit and yellow interlock indicator is flashing. The protected machine is not allowed to operate. The status/diagnostic display shows the diagnostic code that caused the lockout. The OS32C system will remain in the lockout state until the problem is corrected and a start input is applied (see page 17 Start Interlock for details) or power on the unit is cycled.

#### ■ Indication Patterns

RUN indicator	On	When OSSD is ON		
(Green LED)	Off	When OSSD is OFF		
STOP indicator	On	When OSSD is OFF		
(Red LED)	Off	When OSSD is ON		
Interlock Indicator	On	Interlock State		
(Yellow LED)	Flashing	Lockout State (@ 1Hz), Configuration State (@ 4Hz)		
	Off	Other than the above		
Warning output indicator	On	When any warning zone is intruded		
(Orange LED)	Flashing	When dust or contamination is detected on the scan window (@ 1 Hz)		
	Off	Other than the above		
Status/Diagnostic Display		See "OS32C Status Check" on page 139.		
Individual Sector Indicators (ISI)	On	When an object is in any safety or warning zone. *1, *2		
(Red LED)	Flashing	When dust or contamination is detected on the scan window. *1		
	Off	Zones are clear and window is clean.		

<sup>\*1</sup> The functionality of the intrusion indicators is configurable via the configuration tool.

Table 2-1 Indication Patterns

<sup>\*2</sup> The intrusion indicators in the affected region is lit or flashing.

State	RUN indicator (Green LED)	STOP indicator (Red LED)	Interlock indicator (Yellow LED)	Warning output indicator (Orange LED)	OSSDs
Power On Self Test	On	On	On	On	Off
Machine Stop	Off	On	Off	Depends on configuration and object position	Off
Machine Run (Normal Operation)	On	Off	Off	Depends on configuration and object position	On
Machine Run (Dust on scan window)	On	Off	Off	Flashing (@ 1 Hz)	On
Interlock	Off	On	On	Depnds on configuration and object position	Off
Standby	Off	On	Off	Off	Off
Fault (Dust on scan window)	Off	On	Flashing (@ 1Hz)	Flashing (@ 1 Hz)	Off
Fault (others)	Off	On	Flashing (@ 1Hz)	Off	Off
Configuration	Off	On	Flashing (@ 4Hz)	Off	Off

Table 2-2 OS32C Operating States and Corresponding Outputs

#### ■ Status/Diagnostic Display

When powered up, the OS32C will display, in the following order:

• the configured minimum object resolution for 5 seconds, as indicated in the following table:

Digital Indication	Minimum object resolution
L3	30mm
L4	40mm
L5	50mm
L7	70mm

Table 2-3 Minimum object resolution indication

• the Ethernet configuration of the OS32C for 5 seconds, as indicated in the following table:

Digital Indication	OS32C Ethernet configuration
SP	Static IP addressing
dP	DHCP IP addressing

Table 2-4 Ethernet configuration indication

This will also be displayed for 5 seconds after every time the Ethernet cable is connected to the scanner.

• Normal operation indication: zone number and response time. See next page for details.

#### During normal operation:

The seven-segment display indicates the current zone set and response time of the OSSDs. For example, code 24 indicates zone set 2 with a response time of 160ms.

When the display is inverted, a decimal will be shown in the corner.



The response times longer than 400ms are represented by zero.

#### Left Digit

Monitoring Zone of OS32C	Digital Indication
Zone Set 1	1
Zone Set 2	2
Zone Set 3	3
Zone Set 4	4
Zone Set 5	5
Zone Set 6	6
Zone Set 7	7
Zone Set 8	8
Zone Set 9	9
Zone Set 10	A
Zone Set 11	b
Zone Set 12	С
Zone Set 13	d
Zone Set 14	E
Zone Set 15	F
Zone Set 16 or higher	U

## Right Digit

ON to OFF Response time						
OSSD	s out put	Auxiliary and \			Number of	Digital
(without	(with PTM-RBM	(without	(with PTM-RBM	(Configurable)	Scans	Indication
PTM-RBM)	active)*2	PTM-RBM)	active)*2			
80 ms	94 ms	120 ms	140 ms		2	2
120 ms	140 ms	160 ms	186 ms		3	3
160 ms	186 ms	200 ms	232 ms		4	4
200 ms	232 ms	240 ms	278 ms		5	5
240 ms	278 ms	280 ms	324 ms		6	6
280 ms	324 ms	320 ms	370 ms	The OFF to ON response time = corresponding ON	7	7
320 ms	370 ms	360 ms	416 ms		8	8
360 ms	416 ms	400 ms	462 ms		9	9
400 ms	462 ms	440 ms	508 ms	to OFF response time +	10	0
440 ms	508 ms	480 ms	554 ms	Restart Delay parameter*1	11	0
480 ms	554 ms	520 ms	600 ms		12	0
520 ms	600 ms	560 ms	646 ms		13	0
560 ms	646 ms	600 ms	692 ms		14	0
600 ms	692 ms	640 ms	738 ms		15	0
640 ms	738 ms	680 ms	784 ms		16	0
680 ms	784 ms	720 ms	830 ms		17	0

<sup>\*1.</sup> Restart Delay parameter is configurable from 100ms to 60s with 100ms increment See p.52 for configuring the Restart Delay parameter.

Table 2-5 Status/Diagnostic Display Indication

 $<sup>^{\</sup>star}2$ . See Pollution Tolerance Mode section, p.24, for more information

## **Operating Mode**


#### Automatic Start

After power on, OS32C automatically enters machine run (ON) state if no fault is detected during initialization and self-tests, and if no intrusion is detected within the safety zone. An object entering the safety zone shall turn the OSSDs OFF. Once the safety zone is clear, the sensor will automatically enter the machine run (ON) state.

### Start Interlock

After power on, OS32C automatically enters the interlock state if no fault is detected in its system initialization and self-tests, and if no intrusion is detected within the safety zone. To release the interlock state, the start input must transition to open from 0 V for a minimum of 200ms and then back to 0 V short. Once the interlock state is released and OS32C enters the machine run (ON) state, an object entering the safety zone will turn the OSSDs OFF. Once the safety zone is clear, the sensor will automatically enter the safety output ON state.







## Start/Restart Interlock

After power on, OS32C automatically enters the interlock state if no fault is detected in its system initialization and self-tests, and if no intrusion is detected within the safety zone. To release the interlock state, the start input must transition to open from 0 V for a minimum of 200ms and then back to 0 V short. Once the OS32C has started and enters the machine run (ON) state, an object entering the safety zone will turn the OSSDs OFF. Once the safety zone is clear, the sensor will enter the interlock state.

#### Start/Restart Interlock





#### Power Reserve Mode

Power reserve mode allows the OS32C to enter a state of reduced power consumption. This is a very useful mode when the OS32C is installed on a battery powered AGV. This mode can be configured for Standby Mode:

- •OSSDs, AUX and WARNING outputs will be off.
- ·Laser is off.
- •Individual Sector indicators will be deactivated.
- •Diagnostic display will display "--", which blinks once every 2 seconds.
- •Wake-up time (time it takes for the OS32C to return to normal mode) is less than 0.5s.


To use Standby mode:

- •Enable Standby mode under the Power Reserve property and send this change to the scanner.
- •Wire the standby input to a normally open contact, see Chapter 5 for wiring diagram.

To activate standby mode:

•The closure of a normally open contact needs to connect the standby input line to +24VDC.

#### Power Reserve Mode (Standby Mode)



<sup>\*1.</sup> See Table 2-5 for details.

Note: When the Start/Restart Interlock is configured, a start input is necessary after the Power Reserve Mode is released.

## **Parameter Configuration**

The configuration properties consist of two sections: Safety-Critical Parameters and Non-Safety Critical parameters.

## Safety Critical Parameters

#### ■ External Device Monitoring (EDM)

External device monitoring is an important safety function. It verifies that the external control elements are responding correctly.

The OS32C can operate with this feature enabled or disabled. To use external device monitoring, the OS32C requires that a Normally Closed contact from each Control Element be fed back in for monitoring. If these contacts do not respond as expected the OS32C will enter the lockout state and turn off the safety outputs.

In the safety output ON state, the OS32C expects to see the external device monitoring input open. In the safety output OFF state, the OS32C expects to see the external device monitoring input closed. The external device monitoring inputs must change state within 300ms after a change of the OS32C's safety outputs or lockout will occur.

#### ■ Response Time

The response time of the OS32C is proportional to the number of scans. The safety outputs will change from on to off within a preset response time. The response time can be set from 80 to 680ms. The number of scans may be increased when operating the OS32C in a dirty environment to avoid nuisance trips caused by floating particulate matter.

Application Example	Example of Response Time
Stationary (clean environment)	80ms
Mobile	80 to 240ms
Stationary (Dirty environment)	More than 240ms

Table 2-6 Response Time Examples

## **⚠ WARNING**

If the response time is changed, re-calculation of the safety distance is required. This may require re-configuration of the safety zones or re-installation of the OS32C. If the safety distance is not appropriate for the application, the machine may not stop before the hazardous area is reached, resulting in severe injuries.



#### ■ Minimum Object Resolution

The minimum object resolution (the smallest width of an object the scanner will detect), is configurable by the user. The maximum radius of the safety zone will depend on the minimum object resolution selected:

Minimum object resolution (mm)	Maximum safety zone radius (3m range version) (m)	Maximum safety zone radius (4m range version) (m)
30	1.75	1.75
40	2.5	2.5
50	3.0	3.0
70	3.0	4.0

Table 2-7 Minimum object resolution and maximum safety zone radius

#### ■ Zone Set Selection

The OS32C is capable of monitoring up to seventy zone sets, where a zone set is defined as one safety zone, and two warning zones. These zone sets can be controlled via programmable selectable inputs. The installer has the ability of deciding how many and which inputs to use with the configuration

For more information on Zone Set Switching, see page 28.

#### ■ Zone Set Select Input Combinations

When multiple zones are selected, the zone set select input combination table must be configured. These settings will be determined by the number of zones needed and available inputs.

#### ■ Zone Transition Delay

When multiple zones are used the transition time must be accounted for in the safety distance calculation. This delay is 10 ms. This would show up as an additional component, t3, of T in the Safety Distance calculation on page 107. The t<sub>3</sub>delay does not apply in applications without multiple zones.

## Non-Safety Critical Parameters

#### Auxiliary Output Mode

There are five possible auxiliary output settings: safety output information mode, lockout information mode, warning zone 1 infringed mode, warning zone 2 infringed mode, and window contaminated warning mode.

#### Warning Output Mode

There are five possible warning output settings: safety output information mode, lockout information mode, warning zone 1 infringed mode, warning zone 2 infringed mode, and window contaminated warning mode.

#### ■ Restart Delay (Machine Stop to Machine Run Time Adjustment)

This parameter is configurable when the OS32C has been configured to operate in Automatic Start Mode.



Please see page 16 for more information.

#### ■ Power Reserve Mode



See Power Reserve Mode on page 18.

## **Safety Outputs**

#### **. ∴** WARNING

Functional Earth:

The OS32C system requires a functional earth connection.



Do not connect Functional Earth to a positive ground system. If it is connected to positive ground, the guarded machine to be controlled may NOT stop, resulting in severe operator injury.

To use this product for a category 3 safety system, both of the two safety outputs must be used to build the safety system controls circuit. Configuring the safety control system with only one safety output may result in serious injuries due to output circuit failure.



The OS32C provides two PNP safety outputs, each capable of sourcing 250 mA @ 24 VDC. These two outputs can be connected to the machine's primary control element, or may be used to connect to a control device. The safety outputs will turn on when the safety zone is clear, and the guarded machine can operate. The OS32C will turn off its safety outputs when it detects an intrusion in the safety zone, and the guarded machine stops. In addition, the OS32C will test the safety outputs by switching the outputs off for <600 $\mu$ s every ~5 min. See Fig. 2-1 below.




Fig. 2-1 OSSD Test Pulses

## **Auxiliary & Warning Outputs**

## **MARNING**

Do not use the auxiliary output or warning output for safety applications. A human body may not be detected even if a failure of OS32C occurs, resulting in serious injuries.



The OS32C has a non-safety auxiliary output and a non-safety warning output, max.100mA @ 24VDC. Both the output type (PNP/NPN) and polarity (Active ON/Active OFF) can be configured. These outputs can be configured to operate in one of the following modes:

- Follow OSSD: output will turn ON when the machine stops.
- Indicate FAULT: output will turn ON when a fault has occurred.
- Warning Zone 1 infringed: output will turn ON when an intrusion is detected in warning zone 1.

- Warning Zone 2 infringed: output will turn ON when an intrusion is detected in warning zone 2.
- Window Contaminated Warning: output will turn ON when contamination of the scan window reaches a certain level.

Output Mode	Active ON *1	Active OFF *2
Disable	Output always OFF	Output always OFF
Follow OSSD Mode	Same as OSSDs (output ON when safety zone is clear)	Opposite of OSSDs (output OFF when safety zone is clear)
Indicate FAULT Mode	Output ON when fault occurs	Output OFF when fault occurs
Warning Zone 1 Infringed Mode	Output ON when zone 1 infringed	Output OFF when zone 1 infringed
Warning Zone 2 Infringed Mode	Output ON when zone 2 infringed	Output OFF when zone 2 infringed
Window Contaminated Warning Mode	Output ON when window contaminated	Output OFF when window contamined

<sup>\*1.</sup> When the polarity is Active ON, the output modes will be active when the outputs are ON.

NOTE: When the output mode is set to a mode other than the Indicate FAULT mode, all outputs (OSSDs, auxiliary output and warning output) will be OFF if the OS32C enters a fault state.

Table 2-8 Output Polarity

<sup>\*2.</sup> When the polarity is Active OFF, the output modes will be active when the outputs are OFF.

## Reference Boundary Monitoring (RBM)

#### **!** WARNING

Per the international standard IEC 61496-3, area scanners used in applications where the angle of approach exceeds +/- 30 degrees with respect to the detection plane, must use reference boundary monitoring (RBM) of the detection zone. The tolerance zone for (RBM) must NOT exceed 100mm.



Make sure to remove any retro-reflector from the field of view of the OS32C when in RBM mode.



The OS32C has the ability to reference and monitor the presence of pre-determined areas (beams) within the continuous solid boundary being guarded, i.e. walls, doorways, etc. A surface with openings, such as a wire fence cannot be used for the RBM boundary. Reference boundary monitoring (RBM) is normally used in vertical guarding installations, see Fig. 2-2.

The RBM function allows users to select certain areas on the detection zone (safety or warning) boundary and program them to detect continuous presence. This function is intended to prevent unauthorized changes in the physical position of the OS32C scanner.

- When RBM is enabled for the safety zone, the area (beams) that has been activated will cause a transition to a machine stop state when a distance change is sensed.
- When RBM is enabled for a warning zone, the area (beams) that has been activated will cause a transition of the corresponding auxiliary output when a distance change is sensed.



For complete directions on setting up reference boundary monitoring, see page 76.

The OS32C response time must not exceed 120ms, as the OS32C must detect objects moving at 1.6 meters per second. If the detection zone is infringed or if the detection zone boundaries are changed, the scanner shall turn off the two OSSD outputs




Fig. 2-2 Reference Boundary Monitoring

## **Pollution Tolerance Mode (PTM)**

This function enables a filter that allows the scanner to distinguish between more than one detected reflections. When the scanner receives more than one detected reflection pulses during a measurement scan, the filter will ignore the first reflected pulse which may be caused by dust accumulation on the window or air borne dust particles within the guarded space, preventing many nuisance machine stops caused by pollution particles. The PTM function only applies to the Safety zone.

#### 

The activation of RBM Only mode will increase the response time. This additional time must be taken into consideration when calculating the safety guarding distance.



Refer to Table 2-5 Status/Diagnostic Display Indication for additional response time information.

To activate the RBM Only mode, the user needs to:

•Define the reference boundaries following the "Sculpting & Reference Boundary Monitoring" instruction.

NOTE: The reference boundary must be a continuous solid surface, for the installation to benefit from RBM Only mode. A surface with openings, such as a wire fence cannot be used for the RBM boundary.

•Select RBM Only under Pollution Tolerance Mode within Configuration Properties tab.

This function has three setting modes:

Disable: PTM is not active.

**Window Only**: When this mode is active, it will filter out pulse reflections in the near field, which would be caused by dust or other contaminants on the window. This mode uses multi-pulse sampling which can ignore small reflections emanating from the window.

**RBM Only**: This mode includes all features in Window Only. In addition, it will filter out pulse reflections in the guarded space (safety zone). These pulses could be caused by airborne dust/ or other contaminants. This mode works in conjunction with reference boundary monitoring and depends on a pre-defined reference to provide the filtering (tolerance) function. This RBM Only mode uses multi-pulse sampling for beams configured with reference boundaries, see Fig. 2-3. Areas consisting of beams without a reference will not benefit from this function. See Fig. 2-4 for further explanation.




Fig. 2-3 Full Reference Boundary




Fig. 2-4 Partial Reference Boundary

NOTE: The benefit of PTM-RBM function may vary depending on:

- The strength of the reflection caused by the contamination. This strength depends on the density and reflectivity of the pollution source. For instance, heavy smoke or dense cloud of floating dust may still trigger the scanner.
- The position between the OS32C and the reference boundary. The function is more effective for pollution which is closer to the scanner and less effective when the pollution cloud extends closer to the boundary.

## **Zone Set Selection**

## Zone Set Input Selection

When configured for multiple zones, there are a total of 8 inputs available for zone set selection for the OS32C; it is not necessary to use them all. The minimum requirement for safe operation is 2 total inputs. The user must also configure the total number of inputs (the number of input terminals to be used) and active inputs (the number of inputs to be activated) needed to select a zone set. During operation, the scanner will always monitor for that specific configuration of inputs to be active.

Once the number of inputs and active inputs is configured, the user is able to define and assign the detection zone sets to each combination of inputs. The number of unique active combinations available depends on the number of total inputs and the number of active inputs. Table 2-9 shows the maximum number of zone sets possible for the various configurations. It is not necessary to have a zone assigned to every possible combination. Unassigned combinations are assumed to be invalid. If an invalid combination of inputs is detected, the scanner will fault out with diagnostic code 70. In this case, check zone configuration selection, zone set select input wiring, zone set select input switching time and zone delay configuration.



Zone set select input failure or miss-configuration will result in diagnostic code 70 or 71 (guarded machine stop).

70- Incorrect number of active zone set select inputs.

71- Invalid or undefined zone set select input combination.

		No. of Total Inputs (n)							
		8	7	6	5	4	3	2	
Total No.	1	8	7	6	5	4	3	2	
of Active	2	28	21	15	10	6	3		
Inputs (r)	3	56	35	20	10	4			
	4	70	35	15	5				
	5	56	21	6		_			
İ	6	28	7		Maximum nur	n!			
	7	8		1			r! * (n-r)!		

Table 2-9 Maximum number of combinations, depending on total number of inputs and total number of active inputs.

The examples below are some of the possible configurations that can be accomplished for many applications. Here z1 and z2 are used as abbreviations of zone set select input 1 and 2.




Fig. 2-5 Two-Zone Set Application

The examples above illustrate two different wiring schemes that use two inputs with one active required. This is used for a two-zone set application.




Fig. 2-6 Three-Zone Set Application

The examples above illustrate a wiring scheme that uses three inputs with two active required. This is used for a three-zone set application. Note that the selection of inputs is programmable; the user has the ability to select which inputs to use. These configurations are technically the same, but different inputs are selected as active.




Fig. 2-7 Four-Zone Set Application

The above examples illustrate two different wiring schemes that use four inputs with two active required. The example on the left is configured for a four-zone set application. The example on the right is configured for a six-zone set application.




Fig. 2-8 Eight-Zone Set Application

This example illustrates a wiring scheme that uses five inputs with two active required. This is used for an eight-zone set application.

## Zone Set Switching

■ Introduction to zone set switching

As an example, examine a system configured to use 4 inputs with 2 of them active according to the following table:

		Zone Set S	elect Inputs		
	Z1	Z2	Z3	Z4	
Zone Sets	Zone set 1	LOW	HIGH	HIGH	LOW
Zone Sets	Zone set 2	HIGH	LOW	LOW	HIGH

The following figure represents a transition from ZONE 1 to ZONE 2:




Fig. 2-9 Zone Switching example

## **⚠ WARNING**

If the external zone switching device momentarily exceeds the configured number of active zone set select inputs during the zone switch, an additional Zone Delay may be incurred in the event that wiring of a zone set select input fails. The external zone switching device must properly sequence so the configured number of active inputs is not exceeded in order to guarantee that failed zone set select input wiring will be detected within the normal Zone Switching Time described below.



Let's consider an example Zone set A to Zone set B switching, where A represents any origin zone set number and B represents any destination zone set number.

When switching zone sets, there are three installation dependent parameters:

1) Zone Set Switching Timing - When switching from Zone set A, there is a point in time when protection of that zone set is no longer required, this point will be defined as tendzoneA. When transitioning to Zone set B, there is a point in time when the OSSDs must turn OFF if an object is present in Zone set B, this point will be defined as tpangerZoneB. In order to ensure, tpangerZoneB is met, monitoring of Zone set B must start at least one response time (Tresponse) prior to tpangerZoneB. The time at which monitoring of Zone set B must start will be defined as tstartZoneB, where

tStartZoneB = tDangerZoneB - Tresponse

- 2) Zone Set Select Input Switch Timing The worst case time it can take for switching zone set select inputs. This time starts on the transition on the first input change and ends to the transition on the last input change, this will be defined as T<sub>switches</sub>.
- 3) Zone Set Select Input Switch Tolerance It is required that the zone set select input switching circuitry begin switching the zone set inputs at a precise time relative to when the zone set transition is desired to occur. The tolerance of timing when input state is actually switched, generated by input switching circuitry, will be defined using +/- Ttol.

The simplest monitoring zone set switching timing in an installation is tendzoneA < tstartzoneB. In this case, the interval between tendzoneA and tendzoneA does not require any monitoring, thus switching from zone set A to zone set B is straightforward. But when tendzoneA = tstartzoneB or tendzoneA > tstartzoneB, both zone set A and zone set B may need to be monitored simultaneously. In such case, refer to How to Guarantee Protection of Original Zone Set.




Fig. 2-10 Switch from Zone set A to Zone set B.

The Zone Set Input Switch Timing must be configured to consider delay time of input switching circuitry and ensure proper monitoring and safety. The configuration parameter Zone Set Switching Delay (T<sub>delay</sub>) needs a value larger than T<sub>switches</sub> in increments of 20 ms (T<sub>sample</sub>). In the following example, T<sub>delay</sub> is configured to 80ms or more.




Fig. 2-11 Zone Delay configuration.

## **MARNING**

If an insufficient Zone Delay is used for the actual worst case zone set select input switching time of the installation, an unintended zone set may be temporarily enabled, resulting in temporarily monitoring the wrong zone.



Also, it must be ensured that after a zone switch there is a minimum "hold time" before the next zone switch can take place. That time is  $2 * T_{\text{sample}}$ .

The Zone Input Switch Tolerance( $T_{tol}$ ) is the tolerance on when the zone switching circuitry is actually able to start the switching of the inputs.

Besides T<sub>tol</sub> and T<sub>delay</sub>, there is an additional delay of up to T<sub>sample</sub> before the change on the zone set select inputs is recognized.

Therefore, assuming switching of the inputs starts at  $t_{start}$ , the system is guaranteed to switch zones between  $t_{min} = t_{start} + T_{delay} - T_{tol}$  and  $t_{max} = t_{start} + T_{delay} + T_{tol} + T_{sample}$ .




Fig. 2-12 Zone set select input switching and zone set switch.

#### ■ How To Configure Input Switch Circuitry Timing

Relative to t<sub>start</sub>, the longest time it will take to begin monitoring Zone set B is t<sub>max</sub>. When you take into account the scanner's response time required to actually detect an object present in Zone set B, the longest time to turning off the OSSDs relative to t<sub>start</sub> can be shown as:

$$t_{\text{maxToOff}} = t_{\text{max}} + T_{\text{response}}$$

The critical timing guarantee to be met when changing zone sets is toangerZoneB. The input switching circuitry should begin switching the zone set select inputs prior to toangerZoneB to ensure Zone B is activated early enough to detect an object previously present in the zone set. The amount of time prior to toangerZoneB to start switching can be derived from tmaxToOff by equating it to toangerZoneB.

$$t_{start} = t_{DangerZoneB} - (T_{response} + T_{delay} + T_{tol} + T_{sample})$$

This means the switching circuitry must be configured to begin switching the inputs T<sub>maxReaction</sub> before t<sub>DangerZoneB</sub> to ensure safe monitoring of Zone set B, where

## **⚠ WARNING**

If  $t_{\text{start}}$  (switching start time) is configured without consideration of  $T_{\text{maxReaction}}$  (total maximum reaction time), object detection within the new safety zone after switching and turning OFF of the safety outputs may be delayed.






Fig. 2-13 Object detection in Zone set B.

From the diagram, there is a period of time, T<sub>extend</sub>. Between t<sub>min</sub> and t<sub>EndZoneA</sub>, where the system may have switched to Zone set B already but it needs to protect Zone set A. This is covered in the following section.

#### ■ How to Guarantee Protection of Original Zone Set

Additional measures may be necessary to ensure that Zone set A maintains adequate monitoring up to tendZoneA.

With tstart established relative to tDangerZoneB, we must compare tEndZoneA and tmin.

#### Case 1. Zone set switching after the monitoring of zone set A is no longer required (tendzoneA ≤ tmin)

When  $t_{EndZoneA} \le t_{min}$ , no further modifications are necessary. Zone set A will be properly monitored for the duration that is needed.

Case 2. Zone set may be switched before the monitoring of zone set A is no longer required ( $t_{EndZoneA} > t_{min}$ ) When  $t_{EndZoneA} > t_{min}$ , measures must be taken to ensure that Zone set A is protected even when the monitoring zone is switched to zone set B before  $t_{EndZoneA}$ . A simple measure is to modify safety distance (S) used when defining Zone set A such that it includes an additional component ( $Z_{extra}$ ) defined by the maximum approach speed (K) and a worst case extension time ( $T_{extend}$ ) to account for

the time that Zone set A may not be monitored.

$$Z_{\text{extra}} = K * T_{\text{extend}} = K * (t_{\text{EndZoneA}} - t_{\text{min}})$$

Expanding monitoring zone using this additional parameter Z<sub>extra</sub> enables the OS32C to detect an object in advance that may enter the actual monitoring zone of zone set A during zone set switching. In other words, expanding the monitoring zone means that the timing of t<sub>EndZoneA</sub> is shifted to t<sub>min</sub>.




Fig. 2-14 Zone A extension.

The extension of the safety distance around the entire protection zone will guarantee the safe operation of the scanner. However, most installations may benefit from using the smallest possible monitoring zone perimeter to maximize usable work space. For other measures, refer to Additional Zone Set Switching Strategies on page 155.

# **Chapter3 Basic Operation of Configuration Tool**

Getting Started	35
Installing Configuration Tool	35
How to Start	36
Description of Screen	37
Menu	37
Tool Bars	39
Information Bar	40
Offline Mode	40
Connection to the OS32C	41
Connecting the PC and the OS32C	41
Forced DHCP mode	42
Changing the IP address of the PC (Windows XP)	42
Changing the IP address of the PC (Windows 7)	44
Changing the IP address of the PC (Windows 8.1 and Windows 10)	lows 44
Logging on to the OS32C	45
Detecting the OS32C on the network	45
Logging On	46
Logging OFF	46
Changing Password	46
Forgot the Password?	47
Changing Ethernet Configuration of OS32C	48
Receiving OS32C Configuration Information	49
Configuring New OS32C Property and Monitoring Zone	49
Default Configuration Settings	49
Creating a New Configuration	50
Import & Export Zone Coordinate Data	57
File Format	57
Importing Zone Coordinate Data	60
Exporting Zone Coordinate Data	62
Zone Set Selection and Configuration	64
Add a Zone	64
Copy and Paste Zones	65
Delete a Zone	67
Zone Set Input Selection	68
Editing Properties	69
Editing Monitor Zones	73
Sculpting & Reference Boundary Monitoring	76
Monitor Mode	81
Record System Monitoring	82
Playback System Monitoring	84
Read Fault Log	85

Nindow Calibration	86
Changing Options of Configuration Tool	88
Caution on Safety Zone Configuration	89
Reset to Default Configuration	90

## **Getting Started**

The configuration and installation of an OS32C is a simple process. Here are the basic steps needed to get started. Refer to the appropriate section of Chapter 3 for more information on any of these steps.

- · Install the configuration tool
- Connect the OS32C to the same network as the computer
- · Start the configuration tool
- Discover scanners on the network
- · Log on to the OS32C
  - Select Access Level
  - Enter password
- · Create new configuration
  - Safety-critical parameters (EDM, response time, operating mode, zone sets, minimum object resolution etc.)
  - Non-safety-critical parameters (auxiliary output, warning output, power consumption mode, etc)
  - Zone configuration
- · Send configuration to the OS32C

## **Installing Configuration Tool**

Installation of the configuration tool for the OS32C requires the following:

- Pentium 4 class 1.5GHz CPU or equivalent
- Windows XP, Windows 7, Windows 8.1 or Windows 10
- 512MB of RAM
- 10MB of available hard disk space
- Monitor with resolution of 1024 x 768 pixels or better.

Install the configuration tool based on the following steps:

- 1. Terminate all applications running.
- **2.** Insert CD-ROM of the configuration tool to your CD drive.
- **3.** Double-click the CD-ROM icon in My Computer to run Setup.exe.
- **4.** Follow instructions of the installer program.
- **5.** A program icon appears where you specified during installation.



To install the configuration tool on Windows XP Professional, Windows 7, Windows 8.1 or Windows 10, a user account of Supervisor access level (Administrators) is required.



You can download the current version of configuration tool from the website below. https://automation.omron.com/en/us/products/family/OS32C

## **How to Start**

Select Start, All Programs, OS32C Configuration Tool, and OS32C Configuration Tool (if you have not changed the program folder name).




Fig. 3-1 OS32C Configuration Tool

## **Description of Screen**

The configuration tool consists of the following:

## Menu

#### File

New	Used to create new configuration of OS32C
Open	Opens a configuration information file saved on PC
Save	Saves created configuration information on PC, or overwrites the existing configuration file if it was edited
Save As	Saves created configuration information on PC
Print Configuration	Prints OS32C configuration information
Print Screen Snapshot	Prints the zone information screen only with current window zoom
Exit	Terminates the configuration tool

Table 3-1

#### Edit

Undo		Undo last action
Redo		Redo last action
Delete Selected Po	pints	Delete selected point(s) (Applies to polygon shaped zone)
Select a Group of Points		Select a group of points (Applies to polygon shaped zone)
Copy Zone		Copy the zone currently selected (in the Foreground pull-down menu).
Paste Zone		Paste a copied zone to the zone currently selected (in the Foreground pull-down menu).
	Circular Segment	Convert zone being edited to a circular segment
Convert Shape to	Polygon	Convert zone being edited to a polygon
	Rectangle 180°	Convert zone being edited to a rectangle
Import Zone Data		Import zone shape data from a textfile.
Discard Imported Zone		Discard imported zone shape data.
Export Zone Data		Export zone shape data to a textfile.

Table 3-2

#### View

Tool Bar	Main Tool Bar	Shows or hides the Main Tool Bar
	Edit Tool Bar	Shows or hides the Edit Tool Bar
Status Bar		Shows or hides the status bar
View All		Shows the zone information screen with minimum zoom
View Center		Shows the zone information screen with OS32C in the center
Panning		Enables/Disables view panning (Allow a user to click on the displayed zone and move their mouse to adjust their view of the zone).
Zoom In		Magnifies the zone information screen
Zoom Out		Minimizes the zone information screen
Zoom Window		Magnifies a specified range of the zone information screen
Show/Hide Warr	ning Zone 1	Shows or hides warning zone 1 in the zone information screen
Show/Hide Warning Zone 2		Shows or hides warning zone 2 in the zone information screen
Polar Coordinate	е	View the monitoring zone using the polar coordinate system
Cartesian Coordinate		View the monitoring zone using the cartesian coordinate system
Show/Hide Grid		Shows or hides grid
Show/Hide Scale		Shows or hides the scaling
Change Measurement Unit		Change unit of measure. (mm, cm, or inches)
Flip view horizontally		Changes the PC screen view in a horizontal direction
Flip view vertically		Changes the PC screen view in a vertical direction
Reset flip view		Reset the PC screen view to the default orientation

Table 3-3

## Configuration

Edit Properties		Shows the configuration properties screen
Edit Zone		Switches to the monitoring zone configuration mode
Add Zone Set		Add a new zone to the configuration
Sculpting		Enable/Disable sculpting mode
Receive from Sen	sor	Receives current configuration information from the OS32C
	All Changes	Sends only the changed item(s) (safety and non-safety) to OS32C for registration (available at Supervisor access level only)
Send to Sensor	Entire Configuration	Sends all setup items (safety and non-safety) to OS32C for registration (available at Supervisor access level only)
/Enter CFG Mode	All Changes (Non-Safety Only)	Sends only the changed item(s) of non-safety parameter(s) to OS32C for registration. The user can select this option at Supervisor and Maintenance access levels.
	Entire Configuration (Non-Safety Only)	Sends all setup items of non-safety parameter(s) to OS32C for registration. The user can select this option at Supervisor and Maintenance access levels.
Register Changes/Exit CFG Mode		Register the changed item(s) previously sent to OS32C and exit configuration mode.
Discard Changes/Exit CFG Mode		Discard all changed item(s) previously sent to OS32C and/or exit configuration mode.
Configuration checksum		View checksum for the current configuration
Reset to Default Configuration		Reset the scanner back to manufacture default configuration (available at Supervisor access level only)

Table 3-4

#### Reference Boundary Monitoring

telefolies Bearlaary Merinering		
Disable Setting	Disable reference boundary monitoring for the selected zone.	
Set Point as Reference Boundary	Set selected point(s) as reference boundary monitoring points.	
Set Point as Non-reference Boundary	Un-set the selected point(s) as reference boundary monitoring point(s).	
Set All as Reference Boundary	Set all points in the zone for reference boundary monitoring.	
Set All as Non-reference Boundary	Set none of the points in the zone for reference boundary monitoring.	
Set Zone Tolerance	Set the reference boundary monitoring tolerance for a zone.	
Save Reference Boundary Setting	Apply reference boundary monitoring settings to the zone.	
Cancel Reference Boundary Setting	Delete reference boundary monitoring settings.	

Table 3-5

#### Utilities

Discover Sensors		Find sensors on the network
Log On		Used to log on to the OS32C
Log Off		Used to log off from the OS32C
Change Sensor Nar	me	Change the name of the OS32C
Sensor Ethernet Configuration		Change the IP address of the OS32C
Change Password		Used to change the password
Read Encrypted Password		Shows the encrypted password in case of lost password
Dood Foult Los	Sensor	Displays the fault log of the sensor block
Read Fault Log	I/O Block	Display the fault log of the I/O block
System Information		Display the system and ethernet configuration of the OS32C
Window Calibration		Used after the window is replaced
System Monitoring		Shows current OS32C scanning zone information on the zone information screen in real-time
Record System Monitoring		Record OS32C scanning zone information
Playback System Monitoring		Playback previously recorded OS32C scanning zone information
Options		Change configuration tool options

Table 3-6

## **Tool Bars**



Fig. 3-2

(1)	Create a new configuration	Used to create new configuration of OS32C
(2)	Open configuration from file	Opens a configuration information file saved on PC
(3)	Save configuration to file	Saves created configuration information on PC
(4)	Print configuration	Prints OS32C configuration information
(5)	System Monitoring	Shows current scanning zone information on the zone information screen in real-time
(6)	Sculpting	Enable/disable sculpting mode
(7)	Record system monitoring	Record OS32C scanning zone information
(8)	Playback system monitoring	Playback previously recorded OS32C scanning zone information

Table 3-7



Fig. 3-3

(1)	Change measurement unit	Change unit of measure (mm, cm, or inches)
	-	, , , , ,
(2)	Zoom in	Magnifies the zone information screen
(3)	Zoom out	Minimizes the zone information screen
(4)	Zoom window	Magnifies a specific area of the zone information screen
(5)	View center	Shows the zone information screen with the OS32C in the center
(6)	View all	Shows the zone information screen with minimum zoom
(7)	Toggle view panning	Enables/Disables view panning (Allow a user to click on the displayed zone and move their mouse to adjust their view of the zone).
(8)	Edit zone	Enables/Disables the editing of zones
(9)	Convert shape to	Convert zone being edited to a circular segment, polygon, or rectangle
(10)	Undo	Undo last action
(11)	Redo	Redo last action
(12)	Add Zone Set	Add a new zone to the configuration
(13)	Copy zone	Copy the zone currently selected (in the foreground).
(14)	Paste zone	Paste a copied zone to the zone currently selected (in the foreground).
(15)	Flip view horizontally	Changes the PC screen view in a horizontal direction
(16)	Flip view vertically	Changes the PC screen view in a vertical direction
(17)	Reset flip view	Reset the PC screen view to the default orientation
(18)	Toggle rotation tool bar	Show/Hide the rotation tool bar

Table 3-8

## Information Bar




Table 3-9

#### Offline Mode

In offline mode, a user can create, configure, and save a configuration to the PC, as well as load and edit existing configurations on the PC. To enter offline mode, follow the steps shown below:

- **1.** After the configuration tool is launched, the window shown below is displayed.
- 2. Click Cancel.
- $oldsymbol{3}$  . The configuration tool is launched in offline mode.



Fig. 3-5 Offine Configuration

## Connection to the OS32C

This section describes how to connect a PC with the configuration tool and the OS32C.

The configuration tool is connected to the OS32C via Ethernet. An Ethernet cable with an M12, 4-pin connector is required.



See page 119 for more details.

The default Ethernet configuration of the OS32C is DHCP mode (configuration to automatically obtain an IP address).

When connecting a PC to the OS32C, different types of connections are available depending on the user's environment. See the following examples according to your connection environment.

## Connecting the PC and the OS32C

- 1. Physically connect the OS32C to the PC.
  - •For a direct connection, use an Ethernet cable to connect the OS32C directly to the Ethernet port of the PC.
    - -- or --
  - •Use an Ethernet cable to connect the OS32C to the local area network of the PC.



On a network that limits the connection by MAC address authentication, etc., modify the settings to allow the OS32C to connect to the network.

- 2. Configure the Ethernet settings of the PC and the OS32C so that they can communicate with each other. There are two ways to do this:
  - •Configure both the PC and the OS32C to DHCP mode.

Set both the PC and the scanner to DHCP mode (both devices are set to obtain an IP address automatically). If no DHCP server is present on the network, it will take approximately 40 seconds to establish the connection after connecting the PC to the OS32C. While the connection is being established, the Local Area Connection icon on the system tray will look like this:



Fig. 3-6 Connecting Icon

The configuration tool will not be able to connect to the OS32C while this icon is displayed.

A Limited Connection icon will be displayed after the connection icon on the system tray disappears. The configuration tool will now be able to connect to the OS32C.



Fig. 3-7 Limited Connectivity

-- or --

•Configure both the PC and the OS32C to different fixed IP addresses on the same network.

A PC can be connected to the OS32C by configuring the PC to a different fixed IP address within the same network as the IP address of the OS32C.

When connecting multiple OS32s to the network, it is recommended that a different fixed IP address be used for each OS32C.



- Keep in mind that every time a change is made to the scanner, a reset of the scanner will be required, which means the connection session between PC and scanner will have to be re-established.
- Consider the amount of time required for a reset of the OS32C when deciding which Ethernet settings to
  use for the PC and the OS32C. When both PC and OS32C are set to DHCP mode, the time required for
  resetting the scanner and re-establishing the ethernet connection between the two devices can be up to
  55 seconds. When both PC and OS32C are configured with fixed IP addresses, the time required for
  resetting the scanner and re-establishing the ethernet connection can be up to 15 seconds.
- When a device with the same IP address as the OS32C exists, a connection failure may occur. Be careful
  not to have any duplicate IP addresses when connecting multiple OS32Cs to the network.

## Forced DHCP mode

The OS32C can be temporarily forced into DHCP mode upon startup, regardless of the Ethernet configuration settings of the OS32C.

- **1.** Connect a PC directly to the scanner.
- **2.** Press and hold the **Start** button while powering up the OS32C.
- **3.** If the Start input is detected upon startup, the LEDs start blinking (this particular blinking does not happen with a normal startup).
- **4.** Once the blinking starts, release the Start button before 5 seconds have elapsed. If the release occurs before 5 seconds, the OS32C enters forced DHCP mode.
- Disconnect and reconnect the Ethernet cable to start automatic IP address acquisition.
- **6.** Using the forced DHCP mode connects the PC with the DHCP mode and OS32C with the fixed IP address setting.



As forced DHCP mode is a temporary mode, power cycle the OS32C to return the scanner to its fixed IP address.

## Changing the IP address of the PC (Windows XP)

- 1. From the Control Panel, open Network Connections.
- **2.** Right-click the Local Area Connection and select **Properties**.
- 3. Scroll-down and select Internet Protocol (TCP/IP).

**4.** With Internet Protocol (TCP/IP) highlighted, click Properties.




Fig. 3-8 Local Area Connection Properties

5. To set the PC to DHCP mode, select Obtain an IP Address automatically.
To set the PC to a fixed IP address, select Use the following IP address and specify the desired IP address.




Fig. 3-9 TCP/IP Properties

**6.** When selecting **Obtain DNS server address automatically**, an alternate configuration can be set. To set a fixed IP address for the alternate configuration, select **Use the following IP address** from the Alternate Configuration tab. Set an IP address correctly according to the network environment. If you do not set the IP address, select **Automatic private IP address**.




Fig. 3-10 Alternate Configuration

## ■ Changing the IP address of the PC (Windows 7)

- 1. Click the Start button, then click Control Panel.
- **2.** In the search box, type **adapter**.
- Under Network and Sharing Center, click View network connections.
- **4.** Right-click on the connection to be changed, then select **Properties**. If prompted for an administrator password, enter the password and confirm.
- **5.** Select the **Networking** tab.
- **6.** Select Internet Protocol Version 4 (TCP/IPv4) then click Properties.
- To set the PC to DHCP mode, select Obtain an IP Address automatically.
  To set the PC to a fixed IP address, select Use the following IP address and specify the desired IP address.

## Changing the IP address of the PC (Windows 8.1 and Windows 10)

- 1. At the Search box (lower left corner of the desktop), type **Network status**.
- 2. Select **Network status** from the search result.
- 3. Select Change adapter options.
- **4.** In the **Network Connections** window, right-click on the connection to be changed, then select **Properties**. If prompted for an administrator password, enter the password and confirm.
- **5.** Select the **Networking** tab.
- **6.** Select Internet Protocol Version 4 (TCP/IPv4) then click Properties.
- 7. To set the PC to DHCP mode, select Obtain an IP Address automatically.
  To set the PC to a fixed IP address, select Use the following IP address and specify the desired IP address.
- **8.** Press the **OK** button to close the window.

## Logging on to the OS32C

There are 3 types of access levels:

Operator Access Level (Operator)

To log on to the OS32C with this access level, a password is not required. This access level cannot make changes to OS32C configurations. Only verification and monitoring of existing configuration is available.

• Maintenance Access Level (Maintenance)

To log on to the OS32C with this access level, a password is required. This access level allows a user to modify the non-safety parameters only. This includes the warning zone shapes as well as the non-safety critical parameters on page 52.

Supervisor Access Level (Supervisor)

To log on to the OS32C with this access level, a password is required. This access level allows a user to check, change and monitor OS32C configuration information.

NOTE: When planning to remotely log on to an OS32C that is located on a different subnet from the subnet of the PC the following steps are needed during initial setup:

- -The OS32C must have a dedicated password, the default password must be changed.
- -The OS32C should be configured with a specific static IP address.

This will allow remote logon with full read/write access to the OS32C configuration.

## ■ Detecting the OS32C on the network

To connect to the OS32C using the configuration tool, the user needs to find the IP address of the OS32C on the network. Select **Discover Sensors** from the **Utilities** menu.

Since the configuration tool is connected to the OS32C via Ethernet, Windows Security Alert is displayed when Windows firewall is activated. Select **Unblock**. The alert will not be displayed once it is unblocked.



Fig. 3-11 Windows Security Alert

## Logging On

- 1. From Utilities menu, select Log On.
- 2. The Log On screen is displayed. Select an IP address of the OS32C to be connected.



Fig. 3-12 Logging On

- **3.** Select **User access level** and enter a password. The initial password for the maintenance access level is "mainusr". The initial password for the supervisor access level is "supeusr".
- 4. Click Continue.
- **5.** When connected, the IP address and User access level of the OS32C are displayed.



Fig. 3-13 Logged On to Sensor

## Logging OFF

From the Utilities menu, select Log OFF and click OK.

## Changing Password

To limit access by an unauthorized user, the password may be changed. The user needs to log on to the OS32C with the desired access level to change the password. At Supervisor access level, passwords for Supervisor and Maintenance access levels can be changed. At Maintenance access level, only password of this access level can be changed. No password change is permitted at Operator access level. The following steps describe this process:

- 1. Log on to OS32C with the desired access level.
- 2. From the Utilities menu, select Change Password.
- **3.** Enter the current password.
- **4.** From **Change Password**, select an access level you want to change.
- **5.** Enter the new password.
- **6.** Enter the new password again for confirmation.
- 7. Click Change Password.

**8.** A confirmation message is displayed. Click **Yes** to change the password.



Fig. 3-14 Change User Password



The password must contain at least 4 but no more than 7 alphanumeric characters. The password is case-sensitive.

## Forgot the Password?

If the password has been lost/forgotten, follow the steps shown below to acquire the password. This procedure must be executed under the operator access level.

- **1.** Log on with the Operator access level.
- 2. From the Utilities menu, select Read Encrypted Password.
  3. Select Maintenance or Supervisor and click Read Password.
- **4.** The encrypted password is displayed on the screen.
- **5.** Contact Omron's sales representative with this character string.

## **Changing Ethernet Configuration of OS32C**

- 1. From the **Utilities** menu, select **Ethernet Configuration**.
- 2. To configure the OS32C to DHCP mode, select **Obtain an IP Address automatically**. To configure the OS32C to a fixed IP address, select **Use the following IP address** to specify an IP address. Set an IP address correctly according to the network environment.




Fig. 3-15 Ethernet IP Address

- 3. Click Write to Sensor.
- **4.** Confirm the change in Ethernet configuration. Click NO to abort the change.
- **5.** The following window is displayed. Read the message and decide if you want to continue to use the current IP address or start using the new address now.




Fig. 3-16 Ethernet Configuration

# **Receiving OS32C Configuration Information**

The configuration tool receives and displays current configuration information immediately upon connection to the OS32C. Configuration information can be received manually as well. From **Configuration** menu, click **Receive from Sensor**. Configuration information is retrieved from the sensor.

## **Configuring New OS32C Property and Monitoring Zone**

#### **. MARNING**

To use the protective function of OS32C, a safety zone must be properly defined and configured.



If the response time is changed, re-calculation of the safety distance is required. This may require re-configuration of the safety zones or re-installation of the OS32C. If the safety distance is not appropriate for the application, the machine may not stop before the hazardous area is reached, resulting in severe injuries.



This section describes how to configure a new monitoring zone or change the operating properties of the OS32C using the configuration tool.

## Default Configuration Settings

Safety Critical Parameters		
External Device Monitoring	Disable	
Response time (ms)	80	
Monitoring zone	Zone 1	
Zone delay (ms)	60	
Operating mode	Automatic Start	
Minimum Object Resolution (mm)	70	
Pollution tolerance mode	Window Only	
Non-Safety Critical Parameters		
Restart delay (ms)	400	
Auxiliary output mode	Follow OSSD	
Auxiliary output type	PNP	
Auxiliary output polarity	Active ON	
Warning output mode	Follow OSSD	
Warning output type	PNP	
Warning output polarity	Active ON	
Power reserve mode	Disable	
Seven-segment display	Enable - Non-Inverted	
ISI option	Enable	
ISI mode	Follow safety zone	
Warning zone selection by EIP (OS32C-xxx-DM)	Disable	
Safety Zone		
Shape	Circular segment	
Radius (cm)	100	

Scan angle (degrees)	270	
Warning zone 1		
Shape	Circular segment	
Radius (cm)	200	
Scan angle (degrees)	270	
Warning zone 2		
Shape	Circular segment	
Radius (cm)	300	
Scan angle (degrees)	270	

Table 3-10 Default Settings

# Creating a New Configuration

To change the configuration of the OS32C, a user must log on to the OS32C with the supervisor access level.

- 1. From File menu, select New.
- 2. Enter a description for the configuration (up to 127 characters) and select applicable sensor model.




Fig. 3-17 Configuration Description

**3.** New configuration screen is displayed.




Fig. 3-18 New Configuration Parameters for OS32C-xxx and OS32C-xxx-4M




Fig.3-18b New Configuration Parameters for OS32C-xxx-DM and OS32C-xxx-DM-4M

- Safety Critical Parameters
- 1. External Device Monitoring (EDM): When enabled the OS32C can monitor the N.C. contacts of the external control relays. These relays are controlled by the

OSSD safety outputs.

2. Response Time : Configures a time period for OS32C safety output from ON to

OFF. The available range is from 80ms to 680ms in increments

of 40ms.

3. Monitoring Zone : To configure only one zone set, select **Single zone**. To

configure more than one zone, select Multiple zone.

4. Zone Delay : Select the desired Zone Delay. The available range is 20ms to

320ms in increments of 20ms.

5. Operating Mode : A user can select from **Automatic Start**, **Start Interlock**, or

Start/Restart Interlock.

6. Minimum Object Resolution : Select the minimum object size to be detected by the scanner.

Select from 3.0cm, 4.0cm, 5.0cm, and 7.0cm.



The minimum object resolution is displayed on the seven segment display for 5 seconds on power up. Refer to "Status/ Diagnostic Display" in Chapter 2 for more detail.

7. Pollution Tolerance Mode (PTM)

: A user can select from Disable, Window Only, and RBM Only.

Non-Safety-Critical Parameters

1. Restart Delay : Select the desired OFF-to-ON delay when wiring the OS32C in

Automatic Start. Available range is 100ms to 60s, in increments

of 100ms.

2. Auxiliary Output Mode : Select either Disable Follow OSSD, Indicate FAULT,

Warning Zone 1 infringed, Warning Zone 2 infringed, or

Window contaminated.

3. Auxiliary output type : Select **PNP** or **NPN**.

4. Auxiliary output polarity : Select **Active ON** or **Active OFF**.

5. Warning Output Mode : Select either Disable ☐ Follow OSSD, Indicate FAULT,

Warning Zone 1 infringed, Warning Zone 2 infringed, or

Window contaminated.

6. Warning output type : Select **PNP** or **NPN**.

7. Warning output polarity : Select **Active ON** or **Active OFF**.

8. Power reserve mode : Select either **Disabled** or **Standby** mode.

9. Seven-segment display : Select Enable - Non-inverted, Disable, or Enable - Inverted.

When the display is inverted, a decimal will be displayed in the corner. This display can be disabled to save power. Note: even if the seven-segment display is disabled, the 4-digit code for

programming a scanner will still be displayed.

10. ISI option : Select **Enable** or **Disable**. When enabled, the ISIs will turn ON

to indicate the sector(s) where an intrusion has occured in a safety or warning zone (depends on the ISI mode, see below).

11. ISI mode : Select **Follow safety zone** to have the ISIs light up to indicate

the sectors where an intrusion has occurred in the safety zone. Select **Follow warning zone** to have the ISIs light up to indicate the sector(s) where an intrusion has occured in a

warning zone.

12. Warning zone selection by EIP : Select Enable or Disable. When enabled, user can change the

warning zone selection via EtherNet/ IP. This parameter is

available for OS32C-DM version only.

13. Default configuration : Clicking this button resets the parameters to be configured

back to manufacturing default configuration.



The seven segment display can be inverted by selecting **Enable - Inverted** when the OS32C is installed upside down.

**4.** After configuration of parameters is finished, click **Next**.




Fig. 3-19 Zone Shape

Zone Shape: Select from Circular segment, Polygon, Semi-circle (180°), Rectangle (180°), and Polygon (180°). Selecting Polygon automatically creates a shape with six segments. This shape can be changed after finishing the wizard.

- **5.** Click **Next**. If **Multiple zones** is selected, proceed to select zone shapes for the other zone(s).
- **6.** The screen shown below is displayed. (In this example, a rectangle was selected for the safety zone, a polygon was selected for warning zone 1, and a circular segment was selected for warning zone 2).




Fig. 3-20 Confirming Configuration



Safety and warning zones must be configured so that they are at least 100mm away from the wall at the range of 3 m or less and at least 110 mm at the range greater than 3 m.

7. Different response times can be set to different zone sets and/or each individual zone within a zone set.

To configure zone specific response times, click **Edit** response time from the configuration properties screen (Fig. 3-20).

Response time configuration window is displayed.




Fig. 3-21 Response Time setting

- Select zone set to configure response times.
- Select desired response time for each individual zone per zone set.
- Click "Apply to this zone set" to apply the new response time changes to the selected zone set. Or select multiple zone sets and click "Apply to selected zone sets" to apply the new response time changes to all selected zone sets.
- Click "View the setting for all zone sets" to verify the current response time setting for all available zones.
- Click Save to accept or Cancel to ignore all changes made.

#### **MARNING**


If the response time is changed, re-calculation of the safety distance is required. This may require re-configuration of the safety zones or re-installation of the OS32C. If the safety distance is not appropriate for the application, the machine may not stop before the hazardous area is reached, resulting in severe injuries.



## Saving OS32C Configuration to PC

You can save a configuration to the PC.

1. Simply go to File, Save As, and pick the location where you want to save your configuration.







Fig. 3-22 Save Configuration

The file will be saved as a '.cf3' format.



The configuration data file extension is \*.cf2 until Configuration Tool Version 1.8.0 and \*.cf3 from Version 2.0.0.

2. To open the saved configuration, go to File, Open and locate the file you wanted to use.






Fig. 3-23 Open Configuration

## **Import & Export Zone Coordinate Data**

This section describes how to modify a monitoring zone by importing coordinates from a comma delimited text file. Monitoring zone coordinate data can also be exported to a text file for later use.

#### **⚠** WARNING

Monitoring zone parameters are subject to a number of constraints that include projective consistency, maximum radius, and angle limits. As a result, the imported zone may not correspond exactly to the zone defined in the file. The user must visually verify the imported zone when the import process is complete. Refer to Checkout and Test Procedure Log on page 162.



#### File Format

In order for the OS32C Configuration Tool to properly import zone coordinate data, the data in the text file (.txt) must be in the correct format:




Fig. 3-24 File format

File ID: The first line of the file must always be 32001

Measurement unit: The second line of the text file indicates the measurement unit and must be set to 0, 1, or 2 where

0 = mm

1 = cm

2 = inches

Shape Type: The third line of the file must be set to 0, 1, or 2 where

0 = circular segment

1 = polygon

2 = rectangle

DZS ID: 1 to 70. Boundary data will be imported to the specified DZS.

Zone ID: 1 = safety zone, 2 = warning zone 1, 3 = warning zone 2

Reserved: Line 5 of the text file is reserved for future use. Set this line to 0

<u>Coordinate Data:</u> This data must start on line 6 of the text file and can span multiple lines, depending on the zone shape:

Circular segment:

Data format: <radius>,<starting angle (degrees)>,<ending angle(degrees)>

Where the specified zone shape begins at <starting angle(degrees)> and moves in a counter-clockwise direction and ends at <ending angle(degrees)>. Specifying a negative angle is permitted. If the described zone falls within the area between 225° and 315°, the configuration tool will offer to correct the zone so that the imported zone falls within the minimum and maximum angular boundaries of the scanner.




Fig. 3-25 Circular segment

Here is an example of a file specifying a circular segment with 2000mm radius starting at 340° and ending at 180°, It is designated to be written to the safety zone of zone set one.

Line Number	
1	32001
2	0
3	0
4	1, 1
5	0
6	2000,340, 180
7	

Fig. 3-26 Textfile for circular segment

This text file would result in the following zone shape:




Fig. 3-27 Circular segment from textfile

<u>Polygon:</u> This is specified by a list of XY coordinates of each vertex of the polygon. A minimum of 3 vertices must be specified, up to a maximum number of 677.

Data format: <x-coordinate>,<y-coordinate>

Here is an example of a file specifying a polygon with 5 vertices:

Line Number	
1	32001
2	2
3	1
4	1, 1
5	0
6	-54.30,-23.78
7	-38.04,1.59
8	-23.10, 31.50
9	23.32,38.84
10	34.90,18.22
11	

Fig. 3-28 Textfile for polygon shape

#### Rectangle:

Data format: <left width coordinate>,<right coordinate>,<depth> Where:

Left width = -X direction (in the 2nd quadrant)
Right width coordinate = +X direction (1st quadrant)
Depth = +Y direction

Here is an example of a file specifying a rectangle with the width from -200.0cm to 125.5cm and a depth of 200.4cm:




Fig. 3-29 Textfile for rectangle shape

This text file would result in the following zone shape:




Fig. 3-30 Rectangle shape from textfile

### Importing Zone Coordinate Data

- 1. Start the OS32C Configuration Tool
- 2. Create a new configuration or load an existing one
- **3.** Select the destination zone where the zone coordinate data will be imported to, by selecting the zone number and the desired safety or warning zone:



Fig. 3-31 Select Zone

**4.** From the **Configuration** menu select **Edit Zone**:



Fig. 3-32 Edit Zone

## **5.** From the **Edit** menu select **Import Zone Data**:




Fig. 3-33 Import Zone Data

- **6.** Locate and select the file with the data to be imported.
- 7. The configuration tool will import the data from the text file and check the validity of the data.

  If the data in the text file is not valid the configuration tool will prompt the user to correct the text file and try again.

The configuration tool will verify the zone data in the text file:

- is within minimum and maximum range of the zone being imported to
- is within the range allowed by the selected minimum object resolution
- has valid angular boundaries (does not fall within the area between 225° and 315°)

If these criteria are not met, the configuration tool will alert the user and offer to make corrections to the specified zone in order to meet the requirements. Example error message:




Fig. 3-34 Confirm configuration tool suggested correction

**8.** The following message will indicate if any zones will be over-written. Example: If the current configuration already contains DZS #2 and the text file also contains DZS #2 to be imported. The process will overwrite the existing zones from DZS #2.




Fig. 3-35 Zones over-written

The following message will indicate the number of new zones to be added. If the current configuration contains one DZS (3 zones) and the text file contains data for 69 DZS's (207 zones). The process will create new DZS's to import the data.




Fig. 3-36 Zones to be added

Once the configuration tool has imported and displayed the zone, verify that the imported zone displayed is correct. Click OK to accept the imported zone shape and use this shape for the zone selected in step 3. Go to **Edit** and select **Discard Imported Zone**.




Fig. 3-37 Confirm imported zones

### Exporting Zone Coordinate Data

- 1 Start the OS32C Configuration Tool
- $oldsymbol{2}$  . Create a new configuration or load an existing one
- **3.** Select the zone to be exported, by selecting the zone number and the desired safety or warning zone:



Fig. 3-38 Select zone

**4.** From the **Configuration** menu select **Edit Zone** 



Fig. 3-39 Edit Zone

## **5.** From the **Edit** menu select **Export Zone Data**:




Fig. 3-40 Export Zone Data

- **6.** Locate and select the file where the zone data is to be written to, or enter a new filename.
- **7.** The configuration tool will export the zone dimensions/coordinates and save the data to the file specified in the previous step.
- 8. Click OK after the configuration tool has completed exporting the data.



Fig. 3-41 Exporting zone data completed.

RBM ZONES cannot be exported into a text file, if they are included the following message will appear.




Fig. 3-42 RBM export not allowed

# **Zone Set Selection and Configuration**

Once the number of zone sets is defined, the configuration tool is used to program the OS32C. Zone sets can be added one at a time.

#### Add a Zone

**1.** Before adding a new zone, make sure **Multiple Zone** has been selected for the **Monitoring Zone** parameter.




Fig. 3-43 Multi-zones

2. From the Configuration menu, select Add Zone Set.




Fig. 3-44 Add Zone

**3.** Confirm the zone shapes for the new zone.



Fig. 3-45 Confirm Zone Shapes

### Copy and Paste Zones

- Copy & Paste a Single Zone
- **1.** From the **Configuration** menu, select **Edit zone**.
- 2. Select the zone to be copied (bring it to the foreground)
- **3.** Copy the zone by either:
  - a) selecting the Edit menu, then select Copy Zone, or
  - b) clicking the copy button on the toolbar.
- **4.** Select the zone to paste to (bring it to the foreground)
- **5.** Paste the zone by either:
  - a) selecting the Edit menu, then selecting Paste Zone, or
  - b) clicking the paste button on the toolbar.



- Safety zones can only be copied to other safety zones. Warning zones can only be copied to other warning zones.
- If reference boundary monitoring has been configured for a zone, it will not be copied over.

#### ■ Copy & Paste a Zone Set

To copy and paste a zone set (a safety zone and its corresponding two warning zones):

- 1. Select the destination zone number (bring to foreground).
- Click on Define Zones tab.
   While holding down the Ctrl key, use the left mouse button to drag and drop the desired zone set from the **Defined Zones** tab, onto the destination zone.




Fig. 3-46 Drag and drop

In the above figure, zone set 2 is to be copied to zone set 1.



This method of drag and drop to copy and paste zone sets can also be used to copy and paste single zones (safety or warning).

#### **Delete a Zone**

- On the **Defined Zones** tab, right-click on the zone to be deleted.
   Select **Delete Zone**.




Fig. 3-47 Delete Zone

## **Zone Set Input Selection**

Once you have determined the number of zone sets required for your application, you will need to determine the number of inputs you will use and the zone set select input states associated with each zone set. Fig. 3-48 illustrates the use of five inputs and how they apply to the five selected zones.

Left click on a light bulb to toggle it on/off to customize the zone input combos.

Click Verify Combos to check that zone input combos are valid and that there are no duplicates.

Click **Default Combo** to revert zone input combos to default combos.



The combination of required inputs can be customized by the installer. This configuration uses the recommended **Default** combinations.




Fig. 3-48 Zone Set Select

# **Editing Properties**

This section describes how to edit the properties of the OS32C such as response time and operating mode.

#### **A** CAUTION

When transferring data from the PC to the OS32C and more than one OS32C is connected to the network, it is necessary to visually check the diagnostic code on the status/diagnostic display. It is recommended that the OS32C be installed in a position where the status/diagnostic display will be visible.



Before sending the changes to the sensor, verify that the safety parameters are configured as intended for the application.



- 1. From Configuration menu, click Edit Properties.
- **2.** A configuration properties screen is displayed.




Fig. 3-49 Edit Properties

- **3.** Edit the item to be changed.
- 4. After finishing the edits, from Configuration menu click Send to Sensor/Enter CFG Mode, All Changes.

**5.** The screen shown below is displayed. Click **Yes** to confirm.




Fig. 3-50 Save Configuration to Sensor

**6.** When the configuration tool detects multiple scanners on a network, the user will be prompted to enter a 4-digit code from the seven-segment display of the scanner being configured. The order in which each two-digit pair is entered does not matter, and must be done within 120 seconds.



Fig. 3-51 Visual Scanner Identification

When the configuration tool detects only one scanner on the network, the user will be prompted to confirm that the computer is connected to only one scanner. When this happens, the user will not need to enter the 4-digit Visual Sensor Identification code when making changes to the scanner.



Fig. 3-52 Directly connected

**7.** A confirmation message is displayed, showing the changed configuration parameters. After careful review click **Confirm** to accept.




Fig. 3-53 Configuration Confirmation

**8.** A message shown below is displayed for confirmation of zone configuration edits. Clicking **Refresh Scan Zone** displays new scanning zone information of the OS32C on the screen. Click **Yes** to confirm the configured zone. If a configured zone has not changed, this message will not appear.



Fig. 3-54 Confirming Zone Configuration

**9.** After transmission is finished, the window shown below is displayed. Click **Yes** to confirm. If you do not want to register the configuration, click **No**.




Fig. 3-55 Write Configuration

10. The screen shown below is displayed while the OS32C resets.



Fig. 3-56 Reset

The configuration is now complete.



If writing cannot be done, wiring may be wrong. Refer to Chapter 5 to correct wiring.

# **Editing Monitor Zones**

This section describes how to edit and register the changes made to the zone configurations to the OS32C.

- 1. From Configuration menu, click Edit Zones.
- **2.** From **Zone Set** of the tool bar, select a zone set to edit. Then select a zone to edit from **Foreground**. (In this example, Safety zone and Zone 1 are selected.)




Fig. 3-57 Edit Zones



When a scanner enters zone configuration mode, the zone scanned by the OS32C is displayed. If you do not want to display scanning zone information in the zone configuration mode, select **Options** from the **Utility** menu, and unselect **Shows scan zone in edit mode**.

- **3.** A monitoring zone can be edited by:
  - a) Moving a point
     Click a point of the circular segment, polygon, or rectangle you want to move and drag it where you want to place it.
  - b) Changing a zone shapeFrom Edit menu, select Convert Shape To. Select the new shape
  - c) Sculpting

    / Sculpting & Reference Boundary Monitoring p.76
  - d) Changing the scan angle

    To change the scan/detection angle of a zone:

- 1. Select the zone to be changed.
- 2. From the Configuration menu, select Edit Zone.
- 3. Adjust the scan angle by moving either of the outermost points of the zone. In each of the figures below, the two bottom-most points can be used to adjust the scan angle of the zone. The scan angle can be as small as 45 deg. or as large as 270 deg.




Fig. 3-58 Circular Segment




Fig. 3-59 Polygon Shape

For polygon and sculpted shapes, the user can add or remove points from the zone shapes:

- a) To add a point: double-click on the zone to add a point.
- b) To add a point by specifying a coordinate:
  - i) Right-click on the zone and select Creating a point by coordinate




Fig. 3-60 Create a Point by Coordinate

ii) Specify the x-y coordinates for the location of the new point



Fig. 3-61 Specify x-y coordinates

- iii) Click OK.
- c) To change the location of a point by specifying a coordinate:
  - i) Right-click on the zone and select Editing by coordinate




Fig. 3-62 Edit a Point by Coordinate

ii) Select the point to be modified by selecting the point number from the pull-down menu. The selected point will be circled.




Fig. 3-63 Specify x-y Coordinate

- iii) Specify the new desired x-y coordinates for the selected point.
- iv) Click OK.
- d) To remove points:
  - i) From the Edit menu select **Select a Group of Points**. (This menu can also be accessed by right-clicking on the zone).
  - ii) Use the mouse to select the desired point(s).
  - iii) From the Edit menu select Delete Selected Points.
- **4.** When zone edit is finished, click **Edit Zones** from **Configuration** menu and verify if the checkbox is being unselected. Now zone configuration is complete.
- 5. Send the configured zone information to the OS32C for registration. From Configuration menu, click Send to Sensor/Enter CFG Mode, All Changes. Configure by following instructions on a displayed message.
- **6.** Reset the OS32C by following the prompts.

Configuration is now complete.



Safety and warning zones must be configured so that they maintain a distance of 100mm from the wall or fixtures at the range of 3 m or less and at least 110 mm at the range greater than 3 m.

# **Sculpting & Reference Boundary Monitoring**

The scanning zone information from the OS32C can be used for zone configuration. The desired safety zone can be traced within the scanning range of the OS32C. Zone configuration based on this data is called sculpting.

To configure a zone with sculpting, follow the steps shown below.

- 1. From the Configuration menu, select Sculpting.
- 2. The sculpting data displayed on the screen is based on the scanning information sent from the OS32C. Move an object (such as a test piece) around the perimeter of the zone under configuration. The position where the object is detected closest to the OS32C is used as the sculpting data.




Fig. 3-64 Sculpting Mode

**3.** To redo the configuration, exit sculpting mode by clicking the **Cancel** button on the **Save Sculpting Data** window, and re-entering sculpting mode.



Fig. 3-65 Save Sculpting Data Window

**4.** If sculpting data displayed on the screen is correct, select the zone to which the configured sculpting data is to be assigned by using the pull-down menus in the **Save Sculpting Data** window. Click the **Save or Edit Zone** button.

- **5.** To enable Reference Bounding Monitoring (RBM), select the desired zone for RBM and then click the **Start RBM Sculpting** button.
- **6.** The scanner will then take approximately 50 seconds to measure the boundary. It is important not to change the boundary during this time since the scanner will be re-scanning the area and taking an average of the distances.




Fig. 3-66 Learning the Boundary




Fig. 3-67 Learning the Boundary Complete

- **7.** Select the points to be used for RBM:
  - a. To select all the points in the zone for RBM
    - •Right-click on the display screen and select Set All as Reference Boundary.




Fig. 3-68 Set All as Reference Boundary

- b. To select a group of points to be used for RBM:
  - •Right-click on the display screen and select **Select a Group of Points**.




Fig. 3-69 Select Group of Points

•Right-click on the display screen again and select Set Point as Reference Boundary.




Fig. 3-70 Set Points as Reference Boundary Points

- ·Repeat as needed.
- c. To cancel RBM for the zone,
  - •Right-click on the display screen and select **Set All as Non-Reference Boundary** and select **Save Reference Boundary Setting**.




Fig. 3-71 Cancel RBM Settings

**8.** When done selecting the points for RBM, right-click on the display screen and select **Save Reference Boundary Setting**.




Fig. 3-72 Save Reference Boundary Setting

**9.** Now that the Reference Boundary is set, click OK at the prompt shown below.




Fig. 3-73

**10.** Specify the allowed tolerance for RBM. This parameter can be configured from 5.0 to 10.0 cm.




Fig. 3-74 RBM Tolerance

11. Send the created zone information to the OS32C for registration. From the Configuration menu, click Send to Sensor/Enter CFG Mode, All Changes. Configure by following the instructions displayed.




Fig. 3-75 Send to Sensor

**12.** Follow the prompt to reset the OS32C. Now configuration is complete.



- Safety and warning zones must be configured so that they maintain a distance of 100mm from the wall or fixtures at the range of 3 m or less and at least 110 mm at the range greater than 3 m.
- While executing the [Sculpting] command, a warning zone cannot be set with the range exceeding 10 meters (when using the OS32C-XX-4M warning zones can not exceed 15 meters). Use [Edit Zones] or [Convert Shape To] command to modify the shape of the warning zone.
- **13.** A message will appear during monitoring mode, indicating that the zone contains Reference Boundary Regions.




Fig. 3-76 Reference Boundary Monitoring indication

#### **Monitor Mode**

The configuration tool can display scanning zone information of the OS32C in real-time without stopping the machine. The monitor mode can be used by logging on to the OS32C with either operator, maintenance, or supervisor access level.

To start the monitor mode, select **System Monitoring** from the **Utilities** menu. To terminate, follow the same step and deselect **System Monitoring**.




Fig. 3-77 System Monitoring

The outmost border indicates a scanning zone of the OS32C on the monitoring screen. A zone marked in pink indicates the intruded area in the warning zone 1, a zone marked in yellow indicates the intruded area in the warning zone 2, while a zone marked in red indicates the intruded area in the safety zone. The zone selected in **Foreground** is displayed as purple line.

Under the monitor mode, the OS32C state is displayed on the main tool bar.

During the monitor mode you will also see the status of the OSSDs, Warning and Auxiliary outputs, the Zone selection input status and the Seven-segment display on the rotation tool bar.



Fig. 3-78 System monitoring status

### **Record System Monitoring**

Live system monitoring can be recorded to a file. This option is only available after successfully logging on to the scanner in either operator or supervisor mode. The user can specify where the recording is to be saved as well as the recording duration. In addition, Triggered recording will take a snap shot recording of up to 200 frames (8 seconds) when an intrusion occurs.



- Recording will not be interrupted if the PC goes into screensaver mode.
- Minimum recording duration is 5 seconds. Maximum recording duration is determined by the type of storage device. NTFS type storage devices will have a 96 hour limit. FAT32 type storage devices will have a limit of 4 hours.
- Recording to a rewritable CD is not recommended because it will not be able to write data quickly enough.

To record the live monitoring:

- 1. From the Utilities menu, select Record System Monitoring.
- 2. Select the preferred recording type. Specify the desired duration or number of frames for the recording and where the recording is to be saved.

When selecting Triggered by system event, make sure to select at least one type of trigger.




Fig. 3-79 Full recording




Fig. 3-80 Event Triggered Recording



In Event Trigger Mode, the recorded number of frames is divided into one half before and one half after the triggered event.

- 3. Click OK.
- **4.** Using the recording controls, the recording duration can be extended in increments of 15, 30 or 40 s, or 1 to 5 min. Recording can also be stopped at anytime.



Fig. 3-81 Recording controls

**5.** If no event is detected during the Event Triggered Recording, no monitoring data will be written to the file. When user selects the file to playback, following message is displayed.



Fig. 3-82 No monitoring data playback

## **Playback System Monitoring**

Playback of previously recorded system monitoring files(\*.rc2) can be viewed at any time using the configuration tool.

To playback a previously recorded file:

- 1. From the Utilities menu, select Playback System Monitoring.
- Select the previously saved file to play back.
   Use the playback controls as needed to play, pause, fast forward, rewind, exit, etc.




Fig. 3-83 Playback controls

Click on the scrollbar to fast forward or backward by 10 frames Click on the arrow at each end of the scrollbar to move by one scan at a time Click on the 📥 🔖 to move forward or backward to the next stop event

# **Read Fault Log**

There are separate fault logs for the sensor block and for the IO block. Each fault log contains the most recent 100 faults that have occurred. Fault entries are shown with the most recent faults first, so fault entry #1 is the oldest fault.

To retrieve a fault log:

- 1. From the Utilities menu, select Read Fault Log.
- 2. Select sensor block or IO Block.
- **3.** Print or save the error log to a text file. The example below is shown in printed form. When saved to a text file, the data can later be exported to a spreadsheet.




Fig. 3-84 Fault Log

### **Window Calibration**

If the scan window of the OS32C is replaced, window calibration needs to be performed. Do not execute window calibration except when the scan window is replaced.

The window calibration procedure measures the contamination level of the OS32C scan window to reset the threshold values of window transmittance, which serves as a reference for window contamination warning detection. To execute this procedure, the user must log on with the supervisor access level.

### **⚠** WARNING

The calibration procedure must only be performed by qualified personnel. Before performing window calibration of the new scan window, make sure the window is clean and free from scratch, dust, and finger print. The window calibration procedure must be performed at ambient temperature 5 to 35°C. Failure to inspect the window or set the proper environmental condition during window calibration procedure may cause a reduction in the detection capability of the scanner.



The following steps describe this process:

- 1. From Utilities menu, select Window Calibration.
- **2.** A screen shown below is displayed. Click **OK** to confirm.




Fig. 3-85 Window Calibration

**3.** When window calibration starts, the window shown below is displayed.



Fig. 3-86 Calibration Starts

**4.** When calibration is successfully completed, the window shown below is displayed. Click **Save** to confirm.




Fig. 3-87 Calibration Success

Confirm that the window calibration data has changed, and wait for the OS32C to reset. Calibration is complete.

The window shown below may be displayed even after replacing the scan window, due to dust or finger prints on the scan window or dust detection surface during replacement. Clean the inside and outside of the scan window and surface of the dust detection surface using a soft cloth.




Fig. 3-88 Calibration Value too Low

# **Changing Options of Configuration Tool**

This section describes how to change options of the configuration tool.

- 1. From Utilities menu, click Options.
- **2.** The Options screen is displayed.




Fig. 3-89 Changing Configuration Tool Options

- **3.** Edit an item you want to change.
- 4. After configuration is finished, click Apply.
- **5.** A screen shown below is displayed. Click **OK**.




Fig. 3-90 Apply Option Changes

## **Caution on Safety Zone Configuration**

Due to the scanner's minimum object resolution criteria, it is possible to configure zones that are not considered valid. These zone configurations may contain a protrusion or intrusion that is narrower than 70mm in width within the field of view. This type of invalid zone configuration can only occur within a distance of 4 meters from the scanner.

Narrow protruding areas less than 70mm wide are NOT valid zone perimeters. A scanner configured with such a safety zone would see a presence within this area (if in monitor mode), but would not initiate a machine stop. The following pictures shows a possible zone configuration that contains a protrusion that is narrower then 70mm in width, since this protrusion is less than 70mm in width it will not detect a 70mm object. Refer to Fig. 3-91




Fig. 3-91 Detection Zone in Protruding Part

Narrow intruding areas less than 70mm wide are NOT valid zone perimeters. A scanner configured with such a safety zone would see a presence within this area (if in monitor mode), but would not initiate a machine stop. The following pictures shows a possible zone configuration that contains an intrusion that is narrower than 70mm in width, In this case the scanner has two fields of view and the object must be entirely in the left or right field of view to be detected, therefore this narrow intrusion of less than 70mm in width is not a valid zone. Refer to Fig. 3-92.




Fig. 3-92 Detection Zone in Intruding Parts

# **Reset to Default Configuration**

This section describes how to reset the scanner back to manufacturing default configuration. Note: This feature is available in Configuration Tool version 2.0.12 and up.

- 1. Log on to OS32C with supervisor level
- 2. From the Configuration menu, select Reset to Default Configuration




Fig. 3-93 Reset to Default Configuration

**3.** A screen shown below is displayed. Click **Yes** to proceed or **No** to escape.




Fig. 3-94 Confirm reset

**4.** When the configuration tool detects only one scanner on the network, the user will be prompted to confirm if the computer is connected directly to the scanner. When this happens, click **Yes** to confirm.



Fig. 3-95 Directly connected

If the configuration tool detects multiple scanners in a network, the user will be prompted to enter a 4-digit code from the seven-segment display of the scanner being reset. The order in which each 2-digit pair is entered does not matter.




Fig. 3-96 Visual Scanner Identification

**5.** The scanner will take approximately 80 seconds to reset the scanner back to manufacture default configuration



Fig. 3-97 Reset

**6.** Following screen will be displayed when the reset process is completed. Click **Yes** to retrieve the default configuration from the scanner.




Fig. 3-98 Reset completed

# **Chapter4 Installation**

Mounting Considerations	94
Configuring Multiple OS32C Scanners	94
Distance from Wall	96
Stationary Installation and Configuration	97
Installation for Stationary Area Scanning	97
Configuration	98
Configuration Example: Installation on a Machine (1)	99
Configuration Example: Installation on a Machine (2)	101
Configuration Example: Entry Access Protection	101
Configuration Example: Hand Detection Protection	103
Mobile Installation and Configuration	105
Applying OS32C on Automated Guided Vehicles (AGV)	105
Configuration for Automated Guided Vehicles (AGV)	107
Configuration Example: Use of an AGV	108
AGV Standards	109
External Dimensional Drawings	110
Mounting Stand	118
Ethernet Cable	119
XS5 OMRON Smartclick™ Connection	120

### **Mounting Considerations**

### **⚠** WARNING

The OS32C must not be mounted behind glass or within a secondary enclosure. Failure to do so will cause a reduction in detection capability, which can cause serious injury or death.



### **CAUTION**

Operation of the OS32C may be affected by light in the environment, such as incandescent light, strobe light and light from a photosensor using infrared light.



Operation of the OS32C may be affected by substances in the environment, such as fog, smoke, steam and other small particles.



The following considerations should be taken into account when determining the mounting location for the OS32C. It is possible for ambient light to interfere with normal operation of the OS32C. Ambient light interference DOES NOT lead to a loss of safety, it may, however, cause false nuisance stops of the guarded equipment.

Some installations may require that the OS32C be mounted in direct exposure to ambient light. In these situations you must assure that the separation between the scan plane of the OS32C and the light source be greater than +/-5°.




Fig. 4-1 Angle between scan plane and light source

# **Configuring Multiple OS32C Scanners**

The possibility exists that two OS32C may interfere with each other. To avoid this when using multiple OS32C in the same location, please review the following mounting recommendations.

- •Adjust the scanners to offset the scanning plane by tilting the OS32Cs.
- •Adjust the scanners to offset the scanning plane by mounting the OS32Cs at different heights.
- •Adjust the scanners to different scanning planes and additional sampling scans (response time) on the OS32Cs.
- •Install a barrier to block the direct path of possible signal crossing.




Fig. 4-2 Offset Scanning Level by Tilting




Fig. 4-3 Offset Parallel Scanning Levels by Different Installation Height



When installing the OS32Cs side by side, it is more effective to set their mounting heights differently. When adjusting the OS32C tilted, it may be more effective to adjust the OS32C downward depending on the condition of the outside light source (natural light or halogen light).




Fig. 4-4 Separation using a screen



Use of a screen may increase the effect of reflection depending on its material. Select one with matte black finish that is resistant to reflection.

### **Distance from Wall**

The safety or warning zones must be configured so that they maintain a distance of 100mm from the wall or tooling fixture at the range of 3 m or less and at least 110 mm at the range greater than 3 m.

If sculpting is performed, the distance is automatically configured with a stand-off distance of 100mm from walls at the range of 3 m or less and at least 110 mm at the range greater than 3 m.




Fig. 4-5 Distance from Wall

# **Stationary Installation and Configuration**

### Installation for Stationary Area Scanning

#### ■ Position

The OS32C must always be installed in a position that the safety zone can cover the danger area being scanned.

Area which cannot be scanned (e.g. behind obstacles) must be secured by taking appropriate additional measures (e.g. barriers).

The reset switch for clearing interlock must be positioned in such a way that the entire monitoring zone is in view and the operating element cannot be reached from inside the monitored zone.

#### ■ Installation Height (Detection Level)

The installation mounting height of the OS32C is very important, and the following considerations should be taken into account to determine the mounting height.

The OS32C must be mounted in such a way to prevent access to the hazardous area, personnel should not be able to crawl under, stand behind or climb over the protective field. According to ISO 13855 (described later), for an installation height exceeding 300 mm, the possibility of creeping under the protective field must be taken into account. In addition, due to the scanner's scan plane angle deviation, it is not recommended that it be mounted below 150 mm.

Always mount the OS32C so that it is protected from moisture and dirt. Mount the scanner so that the indicators are visible. Avoid locations where the OS32C is exposed to excessive shock and vibration.




Fig. 4-6 Installation Height

### Configuration

When using the OS32C to detect the hazardous area, the Start/Restart Interlock mode should be selected; the regulations applying to the machine must also be complied with.

### ■ Safety Distance (Required Depth of Safety Zone)

Always configure the safety zone in such a way that the machine comes to a standstill in a time less than that taken to reach the danger point of the machine after infringing (interrupting) the safety zone. The standard ISO 13855 must be used to calculate the minimum safety distance; according to ISO 13855, the minimum safety distance, S, from the danger zone area to the outer edge of the safety zone is calculated as follows:

$$S = (K \times T) + C + Z$$

#### where:

- S = Minimum safety distance in mm measured from the danger area to the outer contour of the safety zone.
- K = Movement or approach speed in mm/s (constant K = 1600 mm/s)
- T = Delay between interruption of the safety zone and standstill of the machine in seconds consisting of the sum of t<sub>1</sub>, t<sub>2</sub> and t<sub>3</sub>:
  - $t_1$  = Response time of the OS32C
  - t<sub>2</sub> = Rundown time of the machine (mechanical rundown, reaction time of control system)
  - t<sub>3</sub> = additional time delay for use when multiple zones are used (t<sub>3</sub> = 10 ms.)
- C = Safety constant with C = 1200 mm 0.4 x H (C  $\geq$  850); where
  - H = Distance of detection level from reference level in mm
- $Z = Additional safety factors (maximum measurement error) (<math>Z = Z_1 + Z_2$ ),
  - $Z_1$  = The OS32C's maximum measurement error (100 mm at a range of 3 m or less and 110 mm at a range of greater than 3 m)
  - $Z_2$  = Additional error by reflective background (  $\angle$  Additional Error due to Reflective Background p.142)

#### Documentation of Configuration Parameters

The person responsible for the set-up must record the configuration parameters, print out and sign the report.

- Connect the printer to the PC.
- •Select the menu "File/Print Configuration" in the configuration tool.
- •The report is printed out.
- Sign and date the report and file it in a known location which is always accessible.

### Configuration Example: Installation on a Machine (1)

An example of the installation of OS32C without undercut on the machine is shown below.




Fig. 4-7 Installation on a Machine

### ■ Specifications

K = 1600 mm/s: Movement or approach speed (mm/s)

 $T = t_1 + t_2$ 

 $t_1 = 0.08s$ : Response time of OS32C (s)

t<sub>2</sub> = 0.2s: Stop time including response time of machine (s)

C = 1200 mm - 0.4xH (C ≥ 850 mm): safety factor (mm)

H = 300 mm: Distance of detected level from reference level (mm)

 $Z = Z_1 + Z_2$ 

 $Z_1$  = 110 mm: OS32C's measurement error (mm)

(100 mm at a range of 3 m or less and 110 mm at a range of greater than 3 m)

 $Z_2 = 0$  mm: Additional error by reflective background (mm)

### ■ Calculation Example of Safety Distance S

 $S = (K \times T) + C + Z$ 

= 1600 mm/s x (0.08 s+0.2 s) + (1200 mm - (0.4 x 300 mm)) + 110 mm \*

= 448 mm + 1080 mm +110 mm \*

= 1638 mm

There are several different ways to install the OS32C as shown in Fig. 4-8. Each length of SFdistance (the potential dead space indicated in Fig. 4-7 between the OS32C and the danger zone) is different.




Fig. 4-8 Dimensions of SFdistance

Take additional precautions to prevent intrusion to the dead zone after determining how to mount the OS32C.

#### ■ Additional Error Z<sub>2</sub> due to Reflective Background

- (1) High-reflective background material or object is present in the scanning plane and within 1.2m beyond the safety zone.
- (e.g. acrylic panel, stainless steel, reflective tape, mirror)
- (2) Low-reflective background material or object is present in the scanning plane and within 1.2m beyond the safety zone.
- (e.g. paint-finished equipment)

If any of the conditions listed above apply to your application, an additional error factor Z2 should be added to the safety zone.



Additional Error due to Reflective Background p.142

<sup>\*100</sup> mm at a range of 3 m or less and 110 mm at a range of greater than 3 m

### Configuration Example: Installation on a Machine (2)

An example of installing a cover on the machine with undercut to mount the OS32C is shown below. The OS32C needs to be installed so that the operator cannot stand between the safety zone and danger zone.

Set a cover or undercut on the machine as shown in Fig. 4-9 so that the operator cannot stand on the dead zone.




Fig. 4-9 Installation on a machine with cover

Put a cover on the OS32C as shown in Fig. 4-9 to cover the dead zone and prevent entry to the "Undercut U and SFdistance"

The calculation example of safety distance S and SFdistance are the same as Configuration Example: Installation on a Machine (1).

### Configuration Example: Entry Access Protection

An application example for perpendicular approach to the scanning plane is shown below (entry access protection for a vertical plane protection zone)

Intrusion body detection protection

- •Reference Boundary Monitoring (RBM) must be applied when the OS32C is used for Entry Access Protection guarding as specified in IEC 61496-3.
  - Refer to page 23 for more information on RBM.
- •To ensure adequate detection a response time of 80 mS is required. If the response time exceeds 80mS, a 70 mm object with a speed of 1.6 m/s may not be detected under certain circumstances.
- •Additional counter measures for protection must be provided if there is a space between the protection zone and the machine hazard point.




Fig. 4-10 Perpendicular Approach Installation

- $S = (K \times T) + C$
- S = Minimum safety distance in mm measured from the danger area to the outer contour of the safety zone.
- K = Movement or approach speed in mm/s (constant K = 1600 mm/s)
- T = Delay between interruption of the safety zone and standstill of the machine in seconds consisting of the sum of t<sub>1</sub> and t<sub>2</sub>.
- $t_1$  = Response time of the OS32C
- t<sub>2</sub> = Rundown time of the machine (mechanical rundown, reaction time of control system).
- C = Additional supplemental distance in millimeters

### ■ Example of safety distance calculation

- K = 1600 mm/s approach speed constant
- $T = t_1 + t_2 = 0.58s$  Overall response time
- t<sub>1</sub> = 0.08 seconds OS32C response time (adjustable)
- $t_2$  = 0.5 seconds Max. time required to full stop of the machine
- C = 850mm
- $S = K \times T + C = 1600 \times 0.58 + 850 = 1778 \text{ mm}$

### Configuration Example: Hand Detection Protection

An application example for perpendicular approach to the scanning plane is shown below (hand intrusion detection protection for a vertical plane protection zone)

- Intrusion hand detection protection
- Reference Boundary Monitoring (RBM) must be applied when the OS32C is used for Entry Access Protection guarding as specified in IEC 61496-3.
- Refer to page 23 for more information on RBM.
- The OS32C can be configured for 30mm and 40mm resolution for these types of applications. To ensure adequate detection, a response time of 80 ms is required.
- Additional counter measures for protection must be provided if there is a space between the protection zone and the machine hazard point.
- The maximum protective field range is determined by the selected resolution, see Table 2-7.
- The appropriate safety distance must be followed to ensure that the hazard point can NOT be reached by the operator before it completely stops.




Fig. 4-11 Hand Detection Protection

 $S = (K \times T) + C$ 

S = Minimum safety distance in mm measured from the danger area to the detection point, line, plane or zone.

K = Movement or approach speed in mm/s (constant K = 1600 mm/s)

T = Delay between interruption of the safety zone and standstill of the machine in seconds consisting of the sum of  $t_1$  and  $t_2$ .

t<sub>1</sub> = Response time of the OS32C

t<sub>2</sub> = Rundown time of the machine (mechanical rundown, reaction time of control system).

C = Additional supplemental distance in millimeters (8(d-14 mm))

d = the minimum object resolution of the OS32C system in millimeters.

### ■ Example of safety distance calculation for 30mm resolution

K = 1600 mm/s approach speed constant

 $T = t_1+t_2 = 0.58s$  Overall response time

t<sub>1</sub> = 0.08 seconds OS32C response time (adjustable)

 $t_2$  = 0.5 seconds Max. time required to full stop of the machine

C = 8(30-14 mm)

 $S = K \times T + C = 1600 \times 0.58 + 128 = 1056 \text{ mm}$ 

If the calculated value is more than 500mm, use it for your application installation. The minimum value of S should not be less than 500mm.

# **Mobile Installation and Configuration**

### Applying OS32C on Automated Guided Vehicles (AGV)

AGVs equipped with an OS32C should only be used on private or company property and not allowed to operate on public streets. The OS32C must only be used in AGV applications where the vehicle is equipped with an electric motor. In addition to the following guidelines, it is important that you follow the AGV manufacturer's recommendations.

#### ■ Positioning Height

The OS32C must be mounted so that it provides a horizontal safety scan plane in the path of the AGV.

The height of the scan plane must not exceed 200mm. It is recommended that the installation height of the scan plane be 150mm so that objects with a height of 150mm can be detected. After installation, the entire hazardous area must be tested to verify detection of the 150mm object.




Fig. 4-12 Installation on Automated Guided Vehicle

#### Protruding Front End Mounting

When the application requires installation on the vehicle's front end, it is necessary to eliminate dead zones. These inactive zones can be minimized by recessed installation of the OS32C. On vehicles capable of speeds greater than 0.3m/sec within 3 seconds, the dead zone must be minimized to prevent the operator from standing in the non-detection zone. Additional guarding safety measures must be taken, i.e. hard guarding or pressure sensitive bumper.




Fig. 4-13 Projecting Installation at Front of Vehicle

### ■ Recessed Front End Mounting

Although a recessed installation reduces the size of the dead zone, in some cases this technique creates dead angles. If the OS32C is mounted too deep within the vehicle, the OS32C will not be able to properly scan the hazardous area. These areas are referred to as Dead Angles, as shown in Fig. 4-14. On vehicles capable of speeds greater than 0.3m/sec within 3 seconds, additional safety measures must be taken.




Fig. 4-14 Installation with Bodywork of AGV

#### ■ Installation of OS32C

There are several different ways to mount the OS32C as shown in Fig. 4-15. The DFdistance (the minimum required clearance when installing the OS32C in a recessed location) needs to be considered depending on the mounting method.

Also, take additional precautions to prevent intrusion into the dead zone.




Fig. 4-15 Dimensions of DFdistance

### Configuration for Automated Guided Vehicles (AGV)

■ Safety Distance (Safety zone depth required for safety zone)

For calculating the minimum safety distance for AGV, the standard IEC 61496-3 can be used. The safety distance, S, for use with an AGV should be calculated using the following formula:

S = Minimum safety distance in mm measured from the danger area to the outer contour of the safety zone.

S<sub>p</sub> = Maximum stopping distance for AGV (mm)

Z = Additional safety factors (maximum measurement error)

With the conditions above, the minimum safety distance S is calculated as follows:

$$S = S_p + Z$$

$$S_P = (V_{max.} x T) + S_{brake}$$

$$Z = Z_1 + Z_2 + Z_{gc} + Z_{bf}$$

V<sub>max</sub> = Maximum speed of AGV in mm/s

T = Response time consisting of sum of t<sub>1</sub>, t<sub>2</sub> and t<sub>3</sub>:

t<sub>1</sub> = Response time of OS32C

t<sub>2</sub> = Response time of AGV

 $t_3$  = additional time delay for use when multiple zones are used ( $t_3$  = 10 ms.)


Sbrake = Braking distance of AGV in mm based on manufacturer's document

 $Z_1$  = OS32C's measurement error (100 mm at range of 3 m or less and 110 mm at range of greater than 3 m)

 $Z_2$  = Additional error by reflective background (  $\angle$  Additional Error due to Reflective Background p.142)

 $Z_{gc}$  = Safety factor for lack of clearance between under surface of AGV and ground (  $\angle$  Fig. 4-16).

Z<sub>bf</sub> = Safe factor for reduction of brake force of the AGV through wear and usage.






Fig. 4-16 Safety Factor for Low Ground Clearance

#### ■ Safety Distance (Width Required for Safety Zone)

S<sub>w</sub> = Minimum safety distance of safety zone width (mm)

 $V_w = Width of AGV (mm)$ 

Z = Additional safety factors (maximum measurement error)

With the conditions above, the minimum safety distance  $S_w$  of safety zone width is calculated as follows:

 $Sw = Vw + 2 \times Z$ 

 $Z = Z_1 + Z_2 + Z_{gc} + Z_{bf}$ 

 $Z_1$  = OS32C's measurement error (100 mm at range of 3 m or less and 110 mm at range of greater than 3 m)

 $Z_2$  = Additional error by reflective background (  $\angle$  Additional Error due to Reflective Background p.142)

 $Z_{gc}$  = Safety factor for lack of clearance between under surface of AGV and ground (  $\angle$  Fig. 4-16).

Z<sub>bf</sub> = Safe factor for reduction of brake force of the AGV through wear and usage.

### Configuration Example: Use of an AGV




Fig. 4-17 Installation on AGV

#### Specifications

S<sub>P</sub> = 1600 mm: Maximum stopping distance of AGV

Vw = 1100 mm: Width of AGV

Z<sub>1</sub> = 110 mm: OS32C's measurement error \*

 $Z_2 = 0$  mm: Additional error by reflective background (no reflective background)

 $Z_{gc}$  = 50 mm: Safety factor for lack of clearance between under surface of AGV and ground  $Z_{bf}$  = 100 mm: Safe factor for reduction of brake force of the AGV through wear and usage

Installation position = Centered

#### ■ Calculation Example of Safety Distance (Safety Zone Depth)

$$S = S_P + Z$$

$$= S_P + Z_1 + Z_2 + Z_{gc} + Z_{bf}$$

= 1600 mm + 110 mm \* + 0 mm + 50 mm + 100 mm

= 1860 mm

### ■ Calculation Example of Safety Distance (Safety Zone Width)

$$S_W = V_W + 2 \times Z$$

$$= VW + 2 x (Z_1 + Z_2 + Z_{gc} + Z_{bf})$$

= 1100 mm + 2 x (110 mm \* + 0 mm + 50 mm + 100 mm)

= 1620 mm

<sup>\*100</sup> mm at range of 3 m or less and 110 mm at range of greater than 3 m

### ■ Additional Error Z₂ due to Reflective Backgrounds

If one of the conditions listed below applies to your application, an additional error factor  $Z_2$  should be added to the safety zone.

- (1) High-reflective background material or object is present in the scanning plane and within 1.2m beyond the safety zone.
  - (e.g. acrylic panel, stainless steel, reflective tape, mirror)
- (2) Low-reflective background material or object is present in the scanning plane and within 1.2m beyond the safety zone.
  - (e.g. paint-finished equipment)



Additional Error due to Reflective Background p.142

### AGV Standards

Safety and Machine standards vary from country to country and machine to machine.

The following related standards may be referenced:

- •ASME/ANSI B56.5-1993
- •EN 1493
- •EN ISO 3691-4
- •IEC/EN IEC 61496-3

# **External Dimensional Drawings**

■ OS32C with Back Location Cable Entry /with EIP and Back Location Cable Entry (OS32C-BP/OS32C-BP-4M/OS32C-BP-DM/OS32C-BP-DM-4M)




Fig. 4-18 OS32C with Back Cable Entry Dimensional Drawing

■ OS32C with Side Location Cable Entry /with EIP and Side Location Cable Entry (OS32C-SP1/OS32C-SP1-4M/OS32C-SP1-DM/OS32C-SP1-DM-4M)




Fig. 4-19 OS32C with Side Cable Entry Dimensional Drawing

### ■ OS32C with Top Guard Kit Dimensional Drawing




Fig. 4-20 Dimensional drawing of OS32C with Top Guard Kit OS32C-BKT4

### ■ OS32C with Top Guard Kit Assembly Drawing




Fig. 4-21 Assembly drawing of OS32C with Top Guard Kit OS32C-BKT4

### ■ OS32C with Simple Mounting Bracket Assembly Drawing





Fig. 4-22 Assembly drawing of OS32C with simple mounting bracket OS32C-BKT3

### ■ OS32C with Simple Mounting Bracket Dimensional Drawing



<sup>\*</sup> In order to comply with IEC 61496-3, when the OS32C is mounted where the scanner position could change (e.g. as the result of an impact), additional mechanical means, such as serrated or toothed lock washers, must be employed in the mounting hardware.

Fig. 4-23 Dimensional drawing of OS32C with simple mounting bracket OS32C-BKT3

### ■ OS32C with Simple Mounting Bracket and Top Guard Kit Dimensional Drawing





Fig. 4-24 Dimensional drawing of OS32C with OS32C-BKT3 and OS32C-BKT4

#### ■ OS32C with Simple Mounting Bracket and Top Guard Kit Assembly Drawing



<sup>\*</sup> In order to comply with IEC 61496-3, when the OS32C is mounted where the scanner position could change (e.g. as the result of an impact), additional mechanical means, such as serrated or toothed lock washers, must be employed in the mounting hardware.

Fig. 4-25 Assembly drawing of OS32C with OS32C-BKT3 and OS32C-BKT4

### ■ OS32C with Bottom/Side Mounting Brackets




Fig. 4-26 External dimensional drawing of OS32C with OS32C-BKT1

### ■ OS32C with Bottom/Side Mounting Brackets Assembly Drawing




Fig. 4-27 Assembly drawing of OS32C with OS32C-BKT1

### ■ OS32C with Bottom/Side Mounting Brackets and Top Guard Kit




Fig. 4-28 Dimensional drawing of OS32C with OS32C-BKT1 and OS32C-BKT4

### ■ OS32C with Bottom/Side Mounting Brackets and Top Guard Kit Assembly Drawing




Fig. 4-29 Assembly drawing of OS32C with OS32C-BKT1 and OS32C-BKT4

### ■ OS32C with XY Axis Rotation Mounting Kit Dimensional Drawing




Fig. 4-30 Dimensional drawing of OS32C with OS32C-BKT1 and OS32C-BKT2

#### OS32C with XY Axis Rotation Mounting Kit Assembly Drawing





Fig. 4-31 Assembly drawing of OS32C with OS32C-BKT1 and OS32-BKT2

### ■ OS32C with XY Axis Rotation Mounting Kit and Top Guard Dimensional Drawing



DIMENSIONS: mm [Inches]

Fig. 4-32 Dimensional drawing of OS32C with OS32C-BKT1 and OS32C-BKT2 and OS32C-BKT4

### ■ OS32C with XY Axis Rotation Mounting Kit and Top Guard Assembly Drawing




Fig. 4-33 Assembly drawing of OS32C with OS32C-BKT1 and OS32C-BKT2 and OS32C-BKT4

must be employed in the mounting hardware.

# ■ Mounting Stand




Fig. 4-34 Mounting Stand Kit




Fig. 4-35 Mounting Stand Assembly OS32C-MT

CHECK!

When using a mounting stand, use an OS32C with side cable entry. The OS32C with back cable entry cannot be used.

### ■ Tightening Torque

Refer to table below for tightening torque:

Bolt Diameter	Tightening Torque	
M3.5	1.4 N•m	
M5	3.4 N•m	
M6	3.6 N•m	
M8	3.6 N•m	

Table 4-1

#### ■ Power Cable





Fig. 4-36 External dimensional drawing of power cable

### Ethernet Cable



#### \* SIZES ARE AS BELOW

Model Number	Length in m
OS32C-ECBL-02M	2m
OS32C-ECBL-05M	5m
OS32C-ECBL-15M	15m

Fig. 4-37 External dimensional drawing of ethernet cable

### ■ XS5 OMRON Smartclick<sup>™</sup> Connection

- Connecting the XS5 Plug and Socket
- (1) Align the projection on the plug with the polarity key on the socket, then insert the plug all the way in.




Fig. 4-38 Aligning to polarity key

(2) Hold the knurled grip, then insert the plug into the socket.




Fig. 4-39 Inserting into the socket

(3) Turn the knurled grips of the plug clockwise approximately 45 degrees.

A click will indicate that the Connectors are locked. The locking condition can also be confirmed by the alignment marks on the plug and socket.




Fig. 4-40 Aligning the XS5 Plug

# **Chapter5 Wiring**

Power Supply Unit	122
Additional Wiring Information	123
Input/Output Signal	124
Example of Safety Circuit	125
Basic Connection with Single OS32C unit	125
Connecting to AGV Controls	126
Connecting to the Controller G9SA-301	127

# **Power Supply Unit**

### **MARNING MARNING**

Do not connect the OS32C voltage lines to DC power supplies with more than 30V or less than 16.8 V. In addition, the OS32C should not be connected to AC voltages. Either of the above will result in electrical shock or product malfunction.



For OS32C to meet IEC 61496-1 and UL 508, its DC power supply unit must satisfy all of the following conditions:



- •Line voltage rated within (24VDC +25%/-30%)
- Complying with EMC directives (industrial environments)
- •Double-insulation or reinforced insulation between primary and secondary circuits
- •Automatic return for overcurrent protection
- •Output retention time of 20 ms or longer
- •Satisfying output characteristics requirements of Class 2 circuit or limited voltage/current circuit define in UL 508.
- •Power supply complying with regulations and standards of EMC and safety of electrical equipment in a country or a region where the OS32C is used. (Example: In EU, a power supply must comply with the EMC and Low Voltage Directives.)

To prevent an electrical shock, use double-insulation or reinforced insulation from hazardous voltage (such as AC230V).



Cable extension must be within a specified length. Otherwise it may result in a failure of the safety functions.





Sharing the power supply with other devices may cause the OS32C to be affected by noise or voltage drop. It is recommended that the safety-related devices use a dedicated power supply, not shared with other devices.

# **Additional Wiring Information**

### **⚠** WARNING

Protection of Cable at Installation:

Care should be taken when installing the OS32C cable. The cable must be properly routed and secured to ensure that damage does not occur.



Signal Connector Isolation:

The connectors used during installation <u>must</u> provide sufficient signal separation in order to prevent a short circuit condition of the input power and system signals.



Functional Earth:

The OS32C system requires a functional earth connection.



Do not connect Functional Earth to a positive ground system. If it is connected to positive ground, the guarded machine to be controlled may NOT stop, resulting in severe operator injury.

## **⚠** CAUTION

When wiring the OS32C to external devices, make sure to follow the color and coding schemes per EN 60204-1.



# **Input/Output Signal**

The tables below reference the connections on the OS32C. They are identified by the pin number, input type, and input name.



Fig. 5-1 Power Control 18-Pin Mini-Type Connector

The table below cross-references the Power/Control connector pin out and to the mating cable conductor color and signal description.

Connector	Pin	Conductor Colors	Signal Name
	1	Orange/White	Zone Select 1
	2	Orange/Black	Zone Select 2
	3	Gray	Zone Select 3
	4	Pink	Zone Select 4
	5	Black	Start
	6	Violet	Standby input
	7	Blue	Auxiliary Output
	8	Red/Black	Warning Output
19 Dina Mini Tuna Cannastar	9	Red	OSSD A
18 Pins Mini-Type Connector	10	Yellow	OSSD B
	11	Blue/White	Zone Select 8
	12	White	+24V
	13	White/Black	Zone Select 5
	14	Brown	0V
	15	Brown/White	EDM
	16	Tan	Zone Select 6
	17	Orange	Zone Select 7
	18	Green	Functional earth

Table5-1 Power and Input/Output Connections





Fig. 5-2 Ethernet Port

Pin	Signal Name	
1	+TX	
2	+RX	
3	-TX	
4	-RX	

Table5-2 PC Interface Connections M-12, 4-Pin, Female

# **Example of Safety Circuit**



- \*1. If the External Device Monitoring is not used, connect brown/white wires to 0V, and then disable the External Device Monitoring with the configuration tool.
- \*2. The Start Input must be a Normally Closed switch.
- \*3. For zone select switch setting, see Zone Set Input Selection. When using only one zone, no connection is needed for the zone select inputs.

Fig. 5-3 Basic Connection with Single OS32C unit

# Connecting to the AGV Controls Category 3, Performance Level d (ISO13849-1)





Fig. 5-4 Connecting to AGV Controls



The circuit configuration of the stop/deceleration control must meet the requirements of category 3.

### Connecting to the controller G9SA-301

Category 3, Performance Level d (ISO13849-1)



KM1, KM2: Forced guided relay (G7SA) or magnetic contactor

ED1: Solid state contactor (G3J)

: 3-Phase Motor

: Start Input (use for releasing lockout)

: Zone Select Switch S2 : Reset Switch S3 : Standby Switch S4 E1: 24 VDC Power

PLC: Programmable Controller (This is for monitoring only and unrelated to a safety system)

### OS32C/G9SA Configurations

OS32C: Automatic start, G9SA-301: Manual reset

- \*1. If the External Device Monitoring is not used, connect brow n/white wires to 0V, and then disable the External Device Monitoring with the configuration tool.
- \*2. Use NC-contact for a start input.
- \*3. For zone select switch setting, see Zone Set Input Selection. When using only one zone, no connection is needed for the zone select inputs.

Fig. 5-5 Connecting to the Controller G9SA-301

# **Chapter6 Checkout**

Checkout and Test Procedures		
Testing Safety Zone	131	
Detection Capability	133	

## **Checkout and Test Procedures**

### **MARNING MARNING**

The tests outlined in this Test Procedure (See "Checkout and Test Procedure Log" in p.162) must be performed at time of installation, according to the employer's regular inspection program and after any maintenance, tooling change, set up, adjustment, or modification to the OS32C system or the guarded machine. Where a guarded machine is used by multiple operators or shifts, it is suggested that the test procedure be performed at each shift or operation change and also if there is a change in the OS32C operating mode or defined zone sets. Testing ensures that the safety laser scanner and the machine control system are working properly to stop the machine. Failure to test properly could result in serious injury to personnel.



An OS32C system should only be installed, verified and maintained by a qualified person. A qualified person is defined as "an individual who understands, is trained on, and demonstrates competence with the construction, operation or maintenance of the machinery and the hazards involved." (ANSI/PMMI B155.1-2006)



## Checkout and Test Procedures

Refer to p.162 in Appendix for step-by-step instruction and checkout inspection log.

Once the OS32C has been mounted, configured, and properly connected to the machine control system, qualified personnel must perform the Checkout Procedure detailed in the test procedures. A copy of the checkout results should be kept with the records for the guarded machine's maintenance records.

There is a configuration checksum that can be used when commissioning a piece of equipment. This configuration signature represents a configuration's safety zone(s) and property settings. The checksum can be viewed using the configuration tool. From the **Configuration** menu, select **Configuration Checksum** to view the checksums.

There are three checksum values:

- 1. Configuration Checksum: this is the checksum for the entire configuration. This checksum is updated when any changes are made to the configuration, including safety and non-safety critical parameters.
- 2. Safety Configuration Checksum: this checksum value is updated when changes are made to the safety zones or the safety-critical parameters. Please see page 51 for the list of safety-critical parameters.
- 3. Non-Safety Configuration Checksum: this checksum value is updated when changes are made to the warning zones or the non-safety-critical parameters. Please see page 52 for the list of non-safety-critical parameters.

# **Testing Safety Zone**

### **⚠** WARNING

If the OS32C is operating in automatic start mode, make sure that the machine stops and does not restart when the test object is in the safety zone. Check its operation by approach of a test object into a safety zone. It is recommended that this test be performed after a shift change or 24 hours of operation.



To test the OS32C's detection capability, guide the test object along the perimeter of the safety detection zone as shown in Figures 6-1 and 6-2. The hazardous motion of the guarded equipment must stop immediately (within the pre-determined accepted stop times). While in Automatic Start Mode, the OS32C MUST remain in the machine stop state throughout the entire test.

To test the OS32C, use a test object with a diameter appropriate for the selected resolution. (A test object does not come with the OS32C)

### ■ Testing a Horizontal Safety Zone




Fig. 6-1 Testing a Horizontal Safety Zone

Verify that all indicators and displays are operating properly and correspond to their defined functions of the OS32C. Inspect the OS32C housing and the exit window for signs of damage or manipulation.

If the OS32C is used in a stationary guarding application, ensure that the safety zone(s) are clearly marked on the floor. For mobile applications, make sure that the vehicle stops moving within the limits set in the initial configuration.

If the OS32C fails any of these tests, lock out the guarded equipment and contact the factory supervisor immediately.

### ■ Testing a Vertical Safety Zone




Fig. 6-2 Testing a vertical safety zone

Verify that all indicators and displays are operating properly and correspond to their defined functions of the OS32C. Inspect the OS32C housing and the exit window for signs of damage or manipulation.

Front View

If the OS32C is used in a hand/arm guarding application, ensure that the OS32C resolution is configured for 30mm or 40mm only.

If the OS32C fails this test, lock out the guarded equipment and contact the factory supervisor immediately.

# **Detection Capability**

The OS32C has an adjustable minimum object resolution of 30mm, 40mm, 50mm, or 70mm. Depending on the configured minimum object resolution selected by the user, this means the OS32C will detect an object (30/40/50/70)mm or larger in diameter that is completely within the field of view. The figure below shows an example for when the minimum object resolution is configured for 70mm.




Fig. 6-3 Field of View



The maximum radius of the safety zone will depend on the minimum object resolution selected:

	Minimum object resolution (mm)	Maximum safety zone radius (3m range version)(m)	Maximum safety zone radius (4m range version)(m)
Ī	30	1.75	1.75
Ī	40	2.5	2.5
	50	3.0	3.4
	70	3.0	4.0

Table 6-1 Minimum object resolution and maximum safety zone radius

### ■ Zone of Limited Detection Capability

The OS32C has a Zone of Limited Detection Capability that extends 5cm from the front window, or up to 9 cm from the center of rotation. Objects with very low reflectance in this area may not be detected.




Fig. 6-4 Limited Detection Zone

## **⚠** WARNING

The installer is responsible for assessing the risk and to ensure that the zone of limited detection does not create a safety hazard. If a hazard exists additional countermeasure must be taken, this may require additional guarding measures.



# **Chapter7 Appendix**

Troubleshooting	136
Troubleshooting	136
OS32C Status Check	139
Additional Error due to Reflective Background	142
Conditions of Background Influence	142
Using Other Safety Device in Combination	144
Sensor Replacement	145
Checking the Firmware Version	145
Sensor and I/O Block Replacement	147
How to Recover from a Fault Code 60	148
Scan Window Replacement Procedure	151
Window Replacement Procedure	151
OS32C Maintenance	153
Warning Zone Object Resolution	154
Additional Zone Set Switching Strategies	155
Glossary	159
Accessories	161
Checkout and Test Procedure Log	162
Declaration of Conformity	163
Revision History	167

# **Troubleshooting**

## Troubleshooting

■ Safety output OFF state while there is no intrusion by an object This may happen due to:

#### 1. Mutual interference

This may happen if light from another scanner (OS32C) or other type of photoelectric sensor such as a safety light curtain, is transmitted into the OS32C. In such a case, install the sensor so that its scanning plane does not receive light from the other sensor.



When positioning the OS32C downward, the OS32C may be affected by reflection from the floor surface. Effect of reflection may increase depending on the material of the screen. Be sure to check surrounding environment before installing the OS32C.



For mounting, see Chapter 4 Installation.




Fig. 7-1

#### 2. Incorrect monitoring zone configuration

A safety zone may have been configured too close to any objects. Since the maximum measurement error of the OS32C is 100 mm (at range of 3 m or less) or 110 mm (at range greater than 3 m and up to 4 m), the safety zone must be configured at least 100 mm or 110 mm away from any objects depending on the safety zone distance. An additional measurement error may need to be added due to reflective backgrounds.



Additional Error due to Reflective Background p.142

#### 3. Incorrect zone delay setting

The OS32C will turn OFF if the zone set select input pattern does not fit to any of the patterns configured with the configuration tool within the configured zone delay time. Set the zone delay time to adjust to the specified zone set select input pattern within the given zone delay time.



Zone Set Switching p.28

#### 4. Bright light/Stroboscopic light

Ambient light including high density factory lighting and strobe flash may directly affect the OS32C. An angle of +/-5 degrees must be maintained from the laser scanning plane.



Mounting Considerations p.94

#### 5. Dirty environment

Dirty environment, for instance fog, smoke, steam or other small flying particles may cause the incorrect switching of a Machine Stop state. The influence of the incorrect switching may be decreased if the response time can be increased. To avoid the operation failure, keep the monitoring area clean.



The scanner has higher immunity to small particles or dust when configured for 50mm and 70mm object resolutions.



Installation p.93

### **⚠** WARNING

If the response time is changed re-calculation of the safety distance is required. This may require re-configuration of the safety zones or re-installation of the OS32C. If the safety distance is not appropriate for the application the machine may not stop before the hazardous area is reached resulting in severe injuries.



#### 6. Dirty window

Check if the scan window or dust detection surface (on the base of the window). If the status/diagnostic display shows diagnostic code 80, the scan window should be cleaned with a soft cloth.

### Slow response of the safety output turning ON

This may happen due to unexpected turning OFF of the safety outputs for the reasons described above.

#### ■ Constant Safety Output OFF

#### 1. Dirty window

If the status/diagnostic display shows diagnostic code 80, and if the error cannot be reset by cleaning of the scan window, replacement of the scan window may be needed.



Do not put any sealant on the optics cover. If the scan window of the OS32C is replaced, a window calibration needs to be performed by the configuration tool. See Chapter 3 Window Calibration.

### 2. Safety zone layout change

Verify that no objects are intruding in the configured safety zone. If the OS32C is detecting something, the intrusion indicator will turn ON. The configuration tool can also be used to monitor the scanning information of the OS32C.

- If the configuration tool cannot receive configuration from the OS32C
  - The communication cable is not properly connected.
     Check connections of the communication cable and the ethernet cable.
  - 2. An OS32C has been set to a fixed IP address and the user loses the address. The user will need to set both the PC and the scanner to DHCP mode so that they can communicate with each other, before the user can set the scanner to a new fixed IP address.



See page 42. to force the scanner into DHCP mode.

### ■ Configuration Tool was unable to find sensors on the network

- (1) Check power and ethernet cables
- (2) Check the IP address settings of the PC and the scanner. Make sure both are on the same network.



### ■ Communication Time Out

- (1) Check power and ethernet cables.
- (2) Check the IP address settings of the PC and the scanner. Make sure both are on the same network.



## OS32C Status Check

The OS32C has the status/diagnostic display on the front, which indicates configuration/error status of the OS32C.

## ■ Diagnostic Codes

Status	Diagnostic Code	Description	Corrective Action
Normal Operation	88	Power up indication	-
		Normal operation (guarded machine stop)	-
	 blinking at 0.5 Hz	Standby mode (guarded machine stop)	-
	01	Interlock state (waiting for start input)	-
	02	Configuration mode (guarded machine stop)	-
	80	Window contamination indication (guarded machine stop) The window or dust ring is dirty or scratched.	Clean the window and the dust ring or replace as necessary
	83	Window transmittance error indication (guarded machine stop) • The window is dirty or scratched • The window calibration is not performed after window replacement • The window calibration was performed with the contaminated window and then the window was cleaned, the window transmittance is higher than that measured in the calibration	Clean the window or check for scratches     Clean the window and perform the window calibration
	84	Blinded beams indication (guarded machine stop)	Check for mutual interference with another scanner (see mounting considerations on the user manual), nearby retro-reflectors or strong interfering light sources. Mounting Considerations p.94
	70	Incorrect number of active zone set select inputs (guarded machine stop)	Check zone set select input wiring, zone configuration selection, zone set select input switching time and zone delay configuration
	71	Invalid or undefined zone set select input combination but correct number of active zone set select inputs (guarded machine stop)	Check zone set select input wiring, zone configuration selection, zone set select input switching time and zone delay configuration
		Table 2-5	-
Safety output fault	30	Safety output fault	Check output connection and wiring.
	32	Safety output A is short-circuited to 24V	
	33	Safety output B is short-circuited to 24V	
	34	Safety output A is short-circuited to 0V	
	35	Safety output B is short-circuited to 0V	

Status	Diagnostic Code	Description	Corrective Action
External device monitoring fault	40	EDM (external device monitoring) fault	Check output external device monitoring connection and wiring.
	41	External device monitoring fault before OSSD turning ON	Check the NC-contact status of the external device is changing state before the OSSDs turning ON.
	42	External device monitoring fault after OSSD turning ON	Check the NC-contact status of the external device is changing state after the OSSDs turning ON.
	43	External device monitoring fault during OS32C power on	Check the OS32Cs output configuration,connections and wiring.
Other fault	50	General fault - caused by internal problem or extreme environmental condition	Check environment for excessive vibration, shock or electrical noise; check that the window assembly is undamaged and securely attached. Or replace as necessary.
	51	Mutual interference	Check for mutual interference with another scanner (see mounting considerations on the user manual), nearby retro reflectors or strong interfering light sources.
			Mounting Considerations p.94
	52	Internal fault	Replace as necessary.
	53	Internal blinded beams	Check for mutual interference with another scanner (see mounting considerations on the user manual), nearby retro-reflectors or strong interfering light sources.
			Mounting Considerations p.94
	54	Internal fault	Check for strong interfering light sources or replace as necessary.
			Mounting Considerations p.94
	56	Internal fault caused by electrical noise	Check environment for electrical noise or replace as necessary.
	57 58	Internal fault	Replace as necessary.
	59	Motor fault	Check environment for excessive vibration or shock.
	60	Invalid configuration in unit	Double check current configuration or reset the scanner back to manufacture default configuration.  Reset to Default Configuration p.90
	72	Incorrect number of active zone set select inputs (hard fault code after diagnostic code 70 above persists for more than 10 minutes)	Check zone set select input wiring and zone configuration selection.
	73	Invalid or undefined zone set select input combination, but correct number of active zone set select inputs. (hard fault code after diagnostic code 71 persists for more than 10 minutes)	Check zone set select input wiring and zone configuration selection.
	74	Standby input or zone set select inputs voltage too high	Check zone set select inputs or standby input wired at more than system power (24 VDC).

Status	Diagnostic Code	Description	Corrective Action
Other fault	75	Scanner chassis connected to power (24 VDC)	Scanner chassis should be grounded to 0 VDC
	81	Window condensation (fault code after diagnostic code 83 persists for more than 30 minutes)	Cycle power on unit and allow to run with diagnostic code 83, internal generated heat will reduce condensation. (if possible reduce moisture in the environment)
	82	Window not detected or entire dust detection surface is dirty or blocked.	Check that the window is properly mounted and clean the dust detection surface.
	90	Internal temperature fault - The scanner internal temperature exceeds the operating limit.	Add more ventilation.

Table 7-1 Diagnostic Code References

## Additional Error due to Reflective Background

### **! WARNING**

An additional measurement error may need to be added due to reflective backgrounds. See Specifications of additional Errors by Background.



## Conditions of Background Influence

The OS32C's measurement precision can be affected by the background reflection of an object.

- (1) High-reflective background material or object is present in the scanning plane and within 1.2m beyond the safety zone.
  - (e.g. acryl panel, stainless steel, reflective tape, mirror)
- (2) Low-reflective background material or object is present in the scanning plane and within 1.2m beyond the safety zone.
  - (e.g. paint-finished equipment)

If any of the conditions listed above apply to your application, an additional error factor (Z<sub>2</sub>) should be added to the calculated safety zone size.

- M = Result of safety zone calculation from safety distance
- Z = Additional safety factors (maximum measurement error), Z =  $Z_1 + Z_2$ 
  - $Z_1$  = The OS32C's maximum measurement error (100 mm at range of 3 m or less and 110 mm at range of greater than 3 m)
  - Z<sub>2</sub> = Additional Error by Reflective Background




Fig. 7-2

Use the following steps to calculate the additional error  $Z_2$  from the safety zone distance M. Take OS32C's measurement error  $Z_1$  and the additional error  $Z_2$  into account to setup safety zone with the configuration tool.

### ■ Procedure

- f 1 . Use Fig. 7-3 to calculate the additional error  $Z_2$  for the safety zone distance M.
- 2. Measure a distance to a reflective background or object assuming M+Z<sub>1</sub>+Z<sub>2</sub> as the edge of the safety zone.
- **3.** If the dimension above satisfies the condition (1) or (2), add Z<sub>1</sub> and Z<sub>2</sub> to the value for the safety zone range. If neither condition is satisfied, add Z<sub>1</sub> without adding Z<sub>2</sub>.




Fig. 7-3 Additional error by background influence

## Using Other Safety Device in Combination

If the OS32C is used for presence detection only, instead of intrusion detection, it is not necessary to take the additional error  $Z_2$  into account. Figures 7-4 and 7-5 show examples using OS32C for presence detection only.



Configure the safety zone with a distance of at least 100 mm or 110 mm (see page 96), taking only OS32C's measurement error  $Z_1$  = 100 mm (at range of 3 m or less) or 110 mm (at range greater than 3 m and up to 4 m) into account.




Fig. 7-4 Installing Safety Light Curtain on Entra7-4nce




Fig. 7-5 Installing Door on Entrance

## **Sensor Replacement**

## Checking the Firmware Version

The firmware version can be found by logging on to the OS32C. It is located in the Utilities menu, under the System Information section.




Fig. 7-6 Locating System Information




Fig. 7-7 Sensor System Information

When replacing the sensor follow the recommendations below:

- Replace a sensor with Firmware Version 4.2 or higher, with a sensor with Firmware Version 4.2 or higher.
- Replace a sensor with Firmware Versions 3.2 to 3.18, with a sensor with Firmware Version 3.2 or higher.
- Replace a sensor with Firmware Version 3.0, only with a sensor with Firmware Version 3.0.
- When replacing a sensor with Firmware Version 2.16 or 2.18, we recommend replacing both the sensor and I/O block.



In addition, the OS32C model needs to be considered. Verify that you replace the sensor with the same operating range sensor model (3 m vs 4 m).

In some cases, minor differences in firmware version will need for some parameters to be changed. The affected parameters will be listed for you to review and approve as shown in Fig. 7-8.




Fig. 7-8 Reviewing affected parameters

## Sensor and I/O Block Replacement

## **⚠** CAUTION

Take precautions to prevent dirt, dust or debris from entering the sensor and I/O block connectors. It is recommended that this be done on a clean workstation as contaminants may degrade the performance of the OS32C.



When either the sensor block or the I/O block is replaced, the Checkout and Test Procedure on page 125 must be performed.




Fig. 7-9 Sensor Block Replacement

Required Tool: 3mm Allen wrench

- **1.** Remove power from the OS32C.
- **2.** Remove the four screws and washers that secure the sensor block to the I/O block.
- $oldsymbol{3}_{oldsymbol{ ext{ iny Replace}}}$  Replace the old sensor block or I/O block with the new one.
- **4.** Replace the four screws with flat and lock washers in an alternating patterns. It is recommended that the screws be tightened to a torque of 1.5 to 2.0 N•m (13.28 to 17.1 lb-in).

### How to Recover from a Fault Code 60

If the replacement sensor does not have the same firmware as the failed sensor, it can still be used. In some cases the combined sensor and I/O block system will fault with a code 60. This indicates that there is some incompatibility between the existing configuration in the I/O block and the firmware in the sensor. Below are the required steps to recover from the fault 60.

- **1.** Log on to the scanner as supervisor access level.
- 2. From the Configuration menu, select Reset to Default Configuration.




Fig. 7-10 Reset to Default Configuration

**3.** A screen shown below is displayed. Click **Yes** to proceed or **No** to escape.



Fig. 7-11 Confirm reset

**4.** When the configuration tool detects only one scanner on the network, the user will be prompted to confirm if the computer is connected directly to the scanner. When this happens, click **Yes** to confirm.



Fig. 7-12 Directly connected

If the configuration tool detects multiple scanners in a network, the user will be prompted to enter a 4-digit code from the seven-segment display of the scanner being reset. The order in which each 2-digit pair is entered does not matter.




Fig. 7-13 Visual Scanner Identification

**5.** The scanner will take approximately 80 seconds to reset the scanner back to manufacture default configuration




Fig. 7-14 Reset

**6.** Following screen will be displayed when the reset process is completed. Click **Yes** to retrieve the default configuration from the scanner.



Fig. 7-15 Reset completed

 $oldsymbol{7}$  . Create a new configuration or use a previously saved configuration file to download to the scanner.

# **Scan Window Replacement Procedure**

## Window Replacement Procedure

## **⚠** WARNING

Do not modify the main unit of the OS32C. Do not replace or fix any component of the OS32C other than the ones specified in this manual. Doing so may result in a failure of the safety functions.



If there is any damage to the scan window such as a crack, replace it as soon as possible. Otherwise it may result in a failure of the protective mechanism. Take preventive measures when performing replacement work so that dust does not enter the OS32C.



Always detach all cables from the OS32C before replacing the scan window. Otherwise the motor may start rotating, resulting in injuries.



The window replacement procedure must only be performed by qualified personnel in a clean environment at ambient temperature (5 to 35°C) to prevent the internal optical surface from contamination. Make sure the inside and the outside of the replacement window is clean and free from scratch, dust, and finger print.



## **⚠** CAUTION

Adhesion of dust to the scan window may cause a false operation. The OS32C will require periodic cleaning of the scan window and dust detection surface.



### ■ Window Replacement Kit OS32C-WIN-KT

Kit contents

•Scan Window



•Gasket (pre-installed in window) 1



Required Tool: 2mm Allen wrench

•Screw for window (M3) 4

•Flat Washer 4

NOTE: The window replacement kit OS32C-WIN-KT can be used on any sensor block.




Fig. 7-16 Window Replacement

Window replacement of the OS32C can be accomplished without factory support. Follow the procedure below:

- 1. Remove power from the OS32C. Remove all the cables connected to the OS32C.
- **2.** Using a clean cotton cloth, gently wipe off any dirt or dust from the front of the unit that may inadvertently enter the internal space of the OS32C while the window is removed. (Do not use standard compressed shop air to blow off dust from inside the unit)
- **3.** Remove the four screws and washers on the sides of the window.
- **4.** Remove the existing window by using a small flat-head screwdriver to gently pry up the window's edge.
- **5.** Verify that the gasket is properly seated onto the new window. Gently press around the gasket surface with your thumb. To remove airbone particles from the inside of the unit only use low pressure compressed air that is suitable for optics and sensitive electronics.
- **6.** Install the new window. Make sure the arrow on top of the new window points towards the front of the scanner. Care should be taken to ensure that the inside and outside of the window is clean and free of fingerprints.
- **7.** While applying even pressure to the top of the window, evenly tighten the four screws with flat washers in an alternating pattern ( Fig. 7-16). It is recommended that the screws be tightened to a torque of 0.56 N•m (5.0 lb-in).
  - Excess pressure on the edges of the window may result in cracking of the material.
- **8.** Perform window calibration. After the window is replaced, the scanner may display diagnostic code 50 if window calibration is not performed.
  - Window Calibration p.86

## OS32C Maintenance

The OS32C will require periodic cleaning of the scan window and dust detection surface on the base of the window. The interval of the cleanings will depend on the environment in which the OS32C is used. It is recommended that the window be cleaned using a common glass/plastic cleaner. The window should be sprayed and wiped down with a soft cloth to prevent damage to the surface.




Fig. 7-17 Window Maintenance

# **Warning Zone Object Resolution**

The user can configure up to two warning zones for each zone set with the OS32C. The warning zone should be configured to be larger than the safety zone so that it can send a warning signal before the intrusion approaches into the safety zone.

The OS32C warning zone object resolution is determined by the nominal object resolution and the reflectance value. It varies depending on the distance from the scanner.




Fig. 7-18 Warning zone object resolution

# **Additional Zone Set Switching Strategies**

The following information provides additional strategies to specify protection zones that guarantee protection of zone set A when zone set may switch before monitoring of zone set A is no longer required when switching from zone set A to zone set B (tendzoneA). These examples focus on the dangerous area that exists during zone set transitions, limiting the extended protection zone Zextra to only the areas that need it as opposed to a general extension as described in section 2.

The following diagram uses the same example zone set layout as in the example in section 2, Fig. 2-14. Based on transition related timing parameters previously discussed, this diagram identifies the actual remaining danger area during zone set switching (during T<sub>extend</sub>).



The danger area identified in this diagram is only for example, the actual shape of the danger area will vary based on the installation.




Fig. 7-19 Danger area during zone set switching

There are 3 options for ensuring the Danger Area is adequately guarded during the transition, described in the following examples.

### Example 1. Extend Zone Set A Safety Distance relative to the danger area during zone set switching.

In this option, the extra safety distance Z<sub>extra</sub> is also used to extend Zone set A, but in this case it is only considered relative to the danger area during zone set switching, not the entire monitoring area protected by Zone set A. The resulting zone will adequately protect the danger area during zone set switching, even in the event of zone set switching having completed at t<sub>min</sub>.




Fig. 7-20 Zone set A extension on limited danger area (example 1).

#### Example 2. Extend Zone Set B to protect the danger area during zone set switching in Zone Set A.

In this option, no change is made to Zone set A. Instead, the definition of Zone set B is extended to protect the danger area during zone set switching in zone set A. For this expansion, only the normal safety distance to define zone set A should be considered. This solution may not be practical if Zone set A and Zone set B are basically independent, but in cases where Zone set A and Zone set B naturally overlap and/or the danger is due to a device that simply moves from Zone set A to Zone set B, this option may be used.




Fig. 7-21 Zone set B extension on limited danger area (example 2).

#### Example 3. Create a third zone specifically for relaying the transition.

A third zone set (in the following diagram, Zone set C) is defined that is the combination of both Zone set A and Zone set B. Using this mechanism, the zone set change is achieved by first changing from Zone set A to Zone set C (which effectively begins monitoring Zone set B while continuing to monitor Zone set A) and then changing from Zone set C to Zone set B. This allows the timing of the two different zone set switches to be more flexible and easier to design.




Fig. 7-22 The third zone set that relays switching (example 3).

The first switch (Zone set A to Zone set C) should be setup to meet the same criteria defined previously for specifying tstart relative to tDangerZoneB, in this case tDangerZoneC.

The second switch (Zone set C to Zone set B) should be setup so that tendzoneA, which is relative to the first switch, is guaranteed to be earlier than t<sub>min</sub> relative to t<sub>start</sub> of this second switch.

# **Glossary**

Term	Definition
Automatic Start	An object entering the safety zone turns the OSSDs OFF. Once the safety zone is clear, the sensor will automatically enter the safety output ON state.
Auxiliary Output	This is a non-safety output. It may be configured to provide safety output information or lockout information.
Edit Monitoring Zones	When enabled the edit zones mode will allow the current configurations of the safety and warning zones to be modified. The monitoring zones are graphically displayed for editing. This feature can only be used with an access logon level of supervisor user or higher.
External Device Monitoring	The function to detect a fault, such as the welding of the NC-contacts of the machine's primary control element.
Interlock	OSSD OFF status is maintained until safety is ensured and the start input is applied.
Lockout	A failure is detected and the guarded machine is stopped. The OS32C system will remain in the lockout state until the problem is corrected and a start input is applied.
Maintenance Access Level	This access level allows a user to edit only the non-safety parameters of the OS32C. A password is required to log on to the OS32C with this access level.
Minimum Object Resolution	The minimum width of an object that will be detected by the scanner. This is a user configurable setting with resolutions of 30mm, 40mm, 50mm, and 70mm. The default setting is 70mm.
Monitor Mode	In this mode, the continuously measured data from the OS32C is displayed on the screen in real-time.
Monitoring Zone	The cumulative area of the safety and 2 warning zones.
Monitoring Zone Set	There are 70 selections for this property. A user can select a zone set in the zone set configuration window.
Non-Safety Critical Parameters	These are settings that are not related to the safe installation of the OS32C: Auxiliary output, warning output, restart delay, and standby mode.
Offline Mode	A user can create, edit, and save a configuration to a PC without connecting to the OS32C. The loading and editing of existing configurations on the PC can be done offline as well.
Operator Access Level	This access level cannot change the OS32C settings. Only verification and monitoring of the existing configuration information is available. Password input is not required.
OSSD (Output Signal Switching Device)	This provides ON output when no object is interrupting the sensor in the safety zone. It is used for safety applications.
Pollution Tolerance Mode (PTM)	This function enables a filter that allows the scanner to distinguish between more than one detected reflections caused by reflective pollution particles.
Reference Boundary Monitoring	When activated, the scanner will monitor the boundary of a given detection zone (safety or warning). The detection zone will be considered violated if the boundary range requirements are not within a certain tolerance.
Response Time	The maximum time between the actuation of the sensor function and the switching of the safety outputs of the OS32C. The response time ranges from 80ms (2 scans) to 680ms (17 scans), in increments of 40ms.
Safety Critical Parameters	These are the settings that configure the safe installation of the OS32C: External device monitoring, response time, operating mode, zone set selection, zone set select input combos, zone transition delay, minimum object resolution, and reference boundary monitoring.
Safety Zone	A user-defined protection area to which intrusion of an object stops the guarded machine. When an object enters this area, the safety outputs of OS32C turns OFF within a predefined response time. This zone is a safety-critical property.
Sculpting	Within a scanning range of OS32C, a position where closest to OS32C can be automatically configured as a zone. A distance subtracting 100mm from that to an object is configured.
Start	If start interlock or restart interlock is configured, applying the start input releases the interlock state. It can be also used to release lockout.
Start Interlock	After OS32C is started, the interlock state is maintained. Once the interlock is released by the start input, an object entering the safety zone shall turn OSSD OFF. Once the safety zone is clear, the sensor will automatically enter the safety output ON state.
Start/Restart Interlock	After the OS32C is started, the interlock state is maintained. After the interlock is released by the start input, an object entering the safety zone shall turn OSSD OFF and the interlock state is maintained.

Term	Definition
Supervisor Access Level	To log on to the OS32C with this access level, a password is required. This access level allows a user to edit OS32C configuration information and send it to the OS32C.
Warning Zone	When an object enters the warning zone, warning zone infringed will be reported. This zone allows for a larger scanning area than the safety zone and can be used to activate a warning function. This zone is a non-safety-critical property.
Window Contaminated Warning	This output can be assigned to the warning output and will turn ON when contamination of the scan window reaches a certain level.
Window Calibration	This is required for replacement of the window. Window calibration resets the threshold value of window transmittance. This threshold value is used for Window contamination warning.
Zone Set Select	Up to 70 zone sets can be switched according to the wiring for zone set selection. Refer to "Zone Set Selection" on page 19.

### **Accessories**

Description	Model
Complete OS32C Systems	
OS32C laser scanner with 3m range and back location cable entry	OS32C-BP
OS32C laser scanner with 4m range and back location cable entry	OS32C-BP-4M
OS32C laser scanner with 3m range, EtherNet/IP and back location cable entry	OS32C-BP-DM
OS32C laser scanner with 4m range, EtherNet/IP and back location cable entry	OS32C-BP-DM-4M
OS32C laser scanner with 3m range and side location cable entry	OS32C-SP1
OS32C laser scanner with 4m range and side location cable entry	OS32C-SP1-4M
OS32C laser scanner with 3m range, EtherNet/IP and side location cable entry	OS32C-SP1-DM
OS32C laser scanner with 4m range, EtherNet/IP and side location cable entry	OS32C-SP1-DM-4M
Spare OS32C Sensor Block	
Spare sensor block with 3m range, without I/O block	OS32C-SN
Spare sensor block with 4m range, without I/O block	OS32C-SN-4M
Spare sensor block with 3m range, EtherNet/IP, without I/O block	OS32C-SN-DM
Spare sensor block with 4m range, EtherNet/IP, without I/O block	OS32C-SN-DM-4M
Spare OS32C I/O Blocks	
Spare I/O block with cable access from the back	OS32C-CBBP
Spare I/O block with cable access from the left side	OS32C-CBSP1
Power Cables	
3m cable for power and I/O	OS32C-CBL-03M
10m cable for power and I/O	OS32C-CBL-10M
20m cable for power and I/O	OS32C-CBL-20M
30m cable for power and I/O	OS32C-CBL-30M
Ethernet Cables	
2m cable for scanner configuration	OS32C-ECBL-02M
5m cable for scanner configuration	OS32C-ECBL-05M
15m cable for scanner configuration	OS32C-ECBL-15M
Mounting Brackets	
Bottom/Side Mounting Bracket	OS32C-BKT1
XY Axis Rotation Bracket (must be used with OS32C-BKT1)	OS32C-BKT2
Simple mounting bracket	OS32C-BKT3
Protective cover for window	OS32C-BKT4
OS32C mounting stand (for use with OS32C-SP1) *1	OS32C-MT
OS32C hardware kit to mount BKT1, BKT2, BKT3 to OS32C-MT *2	OS32C-HDT
Miscellaneous	
Window replacement kit	OS32C-WIN-KT
Printed user manual English(paper)	OS32C-MANUAL-EN
Printed user manual Japanese (paper)	OS32C-MANUAL-JP
Spare CD (Configuration Tool + user manual)	OS32C-CD

<sup>\*1</sup> When using a mounting stand, use an OS32C with side location cable entry. The OS32C with back location cable entry cannot be mounted. Use with XY axis rotation bracket (OS32C-BKT2).

<sup>\*2</sup> Use this when mounting a bracket to the mounting stand.

## **Checkout and Test Procedure Log**

The following test procedure must be performed by qualified personnel:

- during initial OS32C system installation
- •after any maintenance, adjustments or modifications to the OS32C or the machine it is guarding
- •at least every three months or more frequently depending on machine usage and employer guidelines

Testing ensures that the OS32C system and machine control system work together to properly stop the machine. Failure to properly test the equipment could result in serious injury to personnel.

### **⚠ WARNING**

If the safety system or the machine fails any of these tests, do not run the machine. Immediately tag or lock out the machine to prevent its use and notify the appropriate supervisor.



Machine Identification:	Date:
Technician Signature:	Checksum (if applicable):

Item	Condition	Comments
Disable the guarded machine. Apply power to the OS32C system.	Pass Fail	
2. Verify that the guarded machine is suitable for use with the OS32C	Pass	
system. See "Introduction" for more information	Fail	
3. Visually inspect the machine to ensure that all access to the danger point is through the OS32C safety zone. If access to any danger point is possible without being detected by OS32C, additional protective measures must be taken such as barriers. Verify that all other guarding devices and barriers are installed and operating properly.	Pass Fail	
4. Verify that the correct minimum object resolution has been selected in accordance with the application type.	Pass Fail	
5. Verify that the maximum safety zone distance of the OS32C system is equal to or greater than the calculated safety zone distance from the danger point. Make sure that the operator cannot stand between the safety zone and the danger zone. See Chapter 4 for calculation of the safety distance.	Pass Fail	
6. Verify that the scanner can only be reset from a position outside and with a view of the monitoring zone.	Pass Fail	
7. Check for signs of external damage to the OS32C system, the guarded machine, the electrical cables and wiring.	Pass Fail	
8. Verify that the connections between the control system of the guarded machine and the OS32C are correct.	Pass Fail	
9. Start the machine. While the machine is in motion, intrude into the safety zone with the test object. The machine should stop immediately. Move the test object inside the perimeter of the safety zone. The machine should remain stopped. Caution: Never insert the test object into the dangerous parts of the machine.	Pass Fail	
10. Verify that the machine braking system is working properly. If the machine does not stop fast enough, adjust the braking system or increase the safety zone distance.	Pass Fail	
11. Record the results of this procedure in the machine log.	Pass Fail	

## **Declaration of Conformity**

No. DECL-000080 Rev. J

Original



### **EU DECLARATION OF CONFORMITY**

1. Product Models/Products:

OS32C Series Laser Scanner

2. Name and address of the manufacturer:

**OMRON Corporation** 

Shiokoji Horikawa Shimogyo-ku, Kyoto, 600-8530 Japan

- 3. This declaration of conformity is issued under the sole responsibility of the manufacturer.
- 4. Objects of the declaration:

OS32C series, Electro Sensitive Protective Equipment (ESPE); Active Optoelectric Protective Device responsive to Diffuse Reflections (AOPDDR), Type 3, designed to detect persons as part of a safety related system

5. The objects of the declaration described above are in conformity with the relevant Union harmonisation legislation:

2006/42/EC Machinery Directive, 2014/30/EU EMC Directive, 2011/65/EU RoHS Directive

6. References to the relevant harmonised standards used or references to the other technical specifications in relation to which conformity is declared:

<u>Machinery Directive: IEC 61496-3:2018, IEC 61496-1:2012 + corr.1:2015, EN 62061:2015, EN ISO 13849-1:2015, IEC 61508 Parts 1 - 7:2010</u>

EMC Directive: EN 61496-1:2012 + corr.1:2015, CISPR 11:2015+AMD1:2016

+AMD2:2019 (Class A)
RoHS Directive: EN IEC 63000:2018

7. Name, address, and identification number of Notified Body, Number of EC Type Examination

Machinery Directive:

Notified body: TÜV Rheinland Industrie Service GmbH

Address: Alboinstr. 56, 12103 Berlin, Germany

Notified Body identification No.: 0035

Certificate for EU Type Examination: 01/205/5005.04/20

1/2 GQ-151845A1

No. DECL-000080 Rev. J

Signed and on behalf of: OMRON Corporation

Place and date of issue: Kyoto Japan //. Sep. 202

Signature:

Name: Jaehyoung Yu

Function: Industrial Automation Company, Safety Division

General Manager

Name and address of contact in EU

OMRON Europe B.V.

**Quality & Environment Department** 

Attn: J.J.P.W. Vogelaar, European Quality & Environment Manager Zilverenberg 2, 5234 GM, 's-Hertogenbosch, The Netherlands

No. 23342-400 Rev. A

Original



#### **UK DECLARATION OF CONFORMITY**

1. Product Models/Products:

OS32C Series Laser Scanner

2. Name and address of the manufacturer:

**OMRON Corporation** 

Shiokoji Horikawa Shimogyo-ku, Kyoto, 600-8530 Japan

- 3. This declaration of conformity is issued under the sole responsibility of the manufacturer.
- 4. Objects of the declaration:

OS32C series, Electro Sensitive Protective Equipment (ESPE); Active Optoelectric Protective Device responsive to Diffuse Reflections (AOPDDR), Type 3, designed to detect persons as part of a safety related system

5. The objects of the declaration described above are in conformity with the relevant UK statutory requirements:

S.I. 2008 No. 1597
S.I. 2016 No. 1091
S.I. 2012 No. 3032
Supply of Machinery (Safety) Regulations 2008
Electromagnetic Compatibility Regulations 2016
Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

6. References to the relevant designated standards used or references to the other technical specifications in relation to which conformity is declared:

S.I. 2008 No. 1597	Supply of Machinery (Safety) Regulations 2008	
- IEC 61496-3:2018, IEC 61496-1:2012 + corr.1:2015, EN 62061:2015, EN ISO 13849-		
1:2015, IEC 61508 Parts 1-7:2010		
S.I. 2016 No. 1091	Electromagnetic Compatibility Regulations 2016	
- EN 61496-1:2012 + corr.1:2015, CISPR 11:2015+AMD1:2016+AMD2:2019 (Class A)		
S.I. 2012 No. 3032	Restriction of the Use of Certain Hazardous Substances in Electrical and	
	Electronic Equipment Regulations 2012	
- EN IEC 6	53000:2018	

7. Name, address, and identification number of Notified Body, Number of UK Type Examination:

S.I. 2008 No. 1597 Supply of Machinery (Safety) Regulations 2008:

Notified body: TUV Rheinland UK Ltd.

Address: Friars Gate (Third Floor), 1011 Stratford Road, Shirley, Solihull B90 4BN, United Kingdom Notified Body Identification No.: 2571

Certificate for EU Type Examination: 01/205U/5005.00/22

1/2 IAB-SSG-041B

No. 23342-400 Rev. A

Signed and on behalf of:

OMRON Corporation

Place and date of issue:

0. 18th Aug. 2022

Signature:

A VI

Name:

Ryo Shimizu

Function:

Industrial Automation Company, Safety Division

General Manager

Name and address of contact in UK


OMRON ELECTRONICS LTD.

Attn: G. Harper, Manager, Customer Care

Opal Drive, Fox Milne, MK15 0DG, Milton Keynes, United Kingdom

# **Revision History**

A manual revision code appears as a suffix to the manual number at the bottom of the front and back covers of this manual.



Revision code	Date	Revised contents
01	April 2010	First edition
02	November 2010	Minor corrections
03	March 2011	- Support for configurable minimum object resolutions - Copy & paste zones and zone sets - Record system monitoring - Playback system monitoring - Support for Windows 7 - Display configuration file name in config tool header - Additional zone shapes available: 180° semi-circle, 180° rectangle, and 180° polygon - Support for inverting 7-segment display - Troubleshooting tips in fault log - Config tool support for switching between default OS32C configuration and the user's current working configuration - Configuration checksum
04	May 2011	Minor corrections
05	November 2011	- Added zone of limited detection - Minor corrections
06	December 2012	- Support for EtherNet/IP and Measurement Data features - Added Maintenance access level - Added non-safety checksum - Added zone coordinate import/export function
07	February 2013	Minor corrections
08	October 2013	<ul><li>- Added multiple zone coordinate import/export function</li><li>- Added multiple languages: French, German, Italian, Spanish</li><li>- Added screen orientation rotation</li></ul>
09	April 2014	- Added 4 meter safety range and 15 meter warning range information - Added Pollution Tolerance modes (PTM) information - Added variable response time settings information - Added status information during monitor mode - Added warning messages for window calibration and window replacement procedure - Added caution message for OS32C mounting - Added warning zone object resolution
10	March 2015	Added instruction to reset the scanner back to manufacture default configuration     Minor correction
11	February 2018	- Added sensor replacement information     - Support for Windows 8.1 and Windows 10 added and support for Windows 2000 and Windows Vista removed     - Minor corrections
12	February 2020	- Updated <i>Terms and Conditions Agreement</i> Added descriptions to Diagnostic Codes 80, 83 and 52 to 59.
13	May 2020	- Remove OSTI from front cover and changed Rev. to Rev. N - Replaced Declaration of conformity in Chapter 7 - Change Rev. Code to -13
14	December 2020	- Replaced Declaration of conformity in Chapter 7
15	September 2022	- Added Declaration of conformity in Chapter 7 Minor corrections

### **Appendix**

Revision code	Date	Revised contents
16 January 2025	January 2025	- Replaced Declaration of conformity in Chapter 7
	- Minor corrections	

### **OMRON Corporation** Industrial Automation Company

Kyoto, JAPAN Contact : www.ia.omron.com

Regional Headquarters

OMRON EUROPE B.V.

Wegalaan 67-69, 2132 JD Hoofddorp The Netherlands

Tel: (31) 2356-81-300 Fax: (31) 2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

438B Alexandra Road, #08-01/02 Alexandra Technopark, Singapore 119968 Tel: (65) 6835-3011 Fax: (65) 6835-2711 OMRON ELECTRONICS LLC

2895 Greenspoint Parkway, Suite 200 Hoffman Estates, IL 60169 U.S.A. Tel: (1) 847-843-7900 Fax: (1) 847-843-7787

OMRON (CHINA) CO., LTD.

Room 2211, Bank of China Tower, 200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222 Fax: (86) 21-5037-2200 Authorized Distributor:

©OMRON Corporation 2010-2025 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

Printed in Japan Cat. No. Z296-E1-16 0125(0410)